

NEXT


BRONX / GREY BRONX CONSOLE

M61912 / E04462

Assembly instructions

Actual product size

H100 x W50 x D25cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

BRONX / GREY BRONX CONSOLE

M61912 / E04462

Assembly instructions

BEFORE YOU START

Number of people required to assemble


One person is required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.



NEXT

BRONX / GREY BRONX CONSOLE

M61912 / E04462

Assembly instructions

GETTING TO KNOW YOUR PRODUCT



X2









NEXT








BRONX / GREY BRONX CONSOLE


M61912 / E04462

Assembly instructions


Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	22.5x23cm		2	1
2	24.5x72.5cm		1	1
3	25x46.5cm		1	1
4	4x46.5cm		1	1
5	25x98cm		1	1
6	23.5x73cm		2	1
7	25x46.5cm		1	1
8	25x98cm		1	1


Ref	Dimensions	Visual	Qty	Ctn
9	19.5x47.5cm		1	1
10	25x50cm		1	1
11	21x22.5cm		1	1
12	22x71.5cm		1	1
13	18.5x19.5cm		4	1
14	18.5x22cm		4	1
15	20x20.5cm		2	1




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.



Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.



The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)

NEXT


BRONX / GREY BRONX CONSOLE

M61912 / E04462

Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
D6	Ø8 x 30mm	16 pre assembled	2
B2	Ø15 x 10mm	16 pre assembled	2
B3	Ø15 x 12mm	26 pre assembled	2
B8	Ø8 x 38mm	42 pre assembled	2
D3	Ø6 x 30mm	8 pre assembled	1
S41	Ø4 x 16mm	1	1
U139	Ø4.5 x 15mm	8	1
U119	Ø4 x 14mm	4	1
S42	Ø4 x 16mm	2	1




Fixtures and fittings supplied (not to scale)




Ref	Dimensions	Qty	Spare Qty	Visual
E39	N/A	1	N/A	
T38	N/A	8	1	
O1	Ø21mm	22	2	
C11	N/A	2	N/A	

Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
M1	N/A	1	N/A	
T35	N/A	4	N/A	
N1	N/A	1	N/A	
P3	N/A	4	N/A	


1







T35	N/A	4	
U119	Ø4 x 14mm	4	  not supplied

X2

2



M1	N/A	1	
S42	Ø4 x 16mm	2	  not supplied




NEXT

BRONX / GREY BRONX CONSOLE

M61912 / E04462

Assembly instructions

3



C11	N/A	2	
U139	Ø4.5 x 15mm	8	PH2 not supplied


NEXT

BRONX / GREY BRONX CONSOLE


M61912 / E04462

Assembly instructions

4



5




NEXT

BRONX / GREY BRONX CONSOLE


M61912 / E04462

Assembly instructions

6



7




NEXT

BRONX / GREY BRONX CONSOLE


M61912 / E04462

Assembly instructions

8



9




NEXT

BRONX / GREY BRONX CONSOLE


M61912 / E04462

Assembly instructions

10



11




NEXT

BRONX / GREY BRONX CONSOLE


M61912 / E04462

Assembly instructions

12



13




NEXT

BRONX / GREY BRONX CONSOLE


M61912 / E04462

Assembly instructions

14



15




NEXT

BRONX / GREY BRONX CONSOLE

M61912 / E04462





Assembly instructions

16



A=B

17



T38

N/A

8



not supplied




18




We recommend the use of the wall attachment bracket/strap provided for safety reasons. Move unit into desired position. Secure the 1X"L" metal brackets to the wall with an appropriate screw and wall plug for your wall type (not provided).

Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type.

If in doubt please consult a qualified trades person.





N1	N/A	1	
S41	Ø4 x 16mm	1	  not supplied

NEXT


BRONX / GREY BRONX CONSOLE
M61912 / E04462
Assembly instructions






19



P3	N/A	4	
----	-----	---	---

20



E39	N/A	1	    
-----	-----	---	---

NEXT

BRONX / GREY BRONX CONSOLE



M61912 / E04462

Assembly instructions




21

To align the door, please adjust the hinges as shown below.

Install hinge




Remove hinge






Adjust Hinge Position




LATERAL



VERTICAL



FRONT- TO-BACK




NEXT

BRONX / GREY BRONX CONSOLE

M61912 / E04462


Assembly instructions

22



X2

23



X2


NEXT

BRONX / GREY BRONX CONSOLE

M61912 / E04462


Assembly instructions

24



X2

25



Please apply the stickers provided to cover the camlocks as shown on the diagram as an example.

WHEN LOOSENING THE CAM

TURN THE CAM IN A COUNTERCLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITION SHOWN IN THE DIAGRAMS BELOW



MAXIMUM LOCK



TURN TO UNLOCK



UNLOCKED

O1

Ø21mm

22




NEXT

BRONX / GREY BRONX CONSOLE M61912 / E04462

Actual product size

H100 x W50 x D25cm



NEXT

BRONX / GREY BRONX CONSOLE
M61912 / E04462

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk