2025.6.18

COSMOPOLITAN IS A TRADEMARK OF HEARST COMMUNICATIONS, INC.
©2025 HEARST COMMUNICATIONS, INC. ALL RIGHTS RESERVED.
THIS PRODUCT IS DESIGNED AND MANUFACTURED UNDER LICENSE BY AROVO B.V.

COSMOPOLITAN
RECHARGEABLE HAIR STRAIGHTENER BRUSH
Article nr.: 527334
Batch nr.: 2025-8936
Made in China

Manufactured by The Great Product Exchange Ltd
Royal Chambers, 110 Station Parade, Harrogate
North Yorkshire, HG1 1EP, United Kingdom
www.thegreatbritishexchange.com

Part of Arovo B.V., Doblijn 26, 1046 BN Amsterdam
The Netherlands, www.arovo.com

COSMOPOLITAN

Rechargeable Hair Straightener Brush

INSTRUCTION MANUAL

ENGLISH

RECHARGEABLE HAIR STRAIGHTENER BRUSH

IMPORTANT SAFETY CAUTIONS
The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury, or fire. The manufacturer cannot be held responsible for any injury or property damage cause by failure to comply with the safety cautions and regulations. It is important to read all these instructions carefully before using the product, and to save them for future reference or new users.

EXPLANATION SYMBOLS

	Read operators manual.
	Do not use over or near washbasins, bathtubs, showers or other vessels containing water.
CE	Declaration of Conformity. Products marked with this symbol comply with all the applicable Community regulations of the European Economic Area.
	Protection class II device in which protection against electric shock is not based solely on the basic insulation but in which there are additional safety features such as double or enhanced insulation. It is independent of the protection measures of the fixed installation.
	The packaging can be reused or recycled. Please dispose properly of any packaging material no longer required.
	If you notice any transport damage during unpacking, please contact your dealer without delay.
	This symbol indicates that the power input/output for the product is direct current.

WARNINGS
- WARNING: Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children without supervision.
- Do not keep or use the appliance in humid areas.
- Keep out of reach of children.
- Do not use the appliance with wet hands or let water drop on the appliance. It may cause electric shock and injury.
- Do not operate the electrical appliance with wet hands or if the appliance is wet.
- Do not place in, or drop water or other liquids onto the appliance. If the appliance falls into water, unplug immediately. Do not reach into the water.
- Do not operate the appliance in the presence of explosive and/or flammable fumes and/or liquids.
- Do not attempt to repair or disassemble the appliance. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons, in order to avoid any risks.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped into water.
- Keep cord away from the heated surfaces.
- Keep heated surfaces away from contact with all skin areas. Do not let eyes or bare skin touch heated surfaces.
- Do not place the heated unit directly on any surface while it is hot or still plugged in.
- Never leave the appliance unattended when plugged in. Never use while drowsy or sleepy.
- Do not store the appliance immediately after use. Wait until it is completely cool before storing.
- For additional protection, we advise you to install a residual current device (RCD) with a rated residual operating current not exceeding 30mA in the electrical circuit supplying the bathroom. Ask your installer for advice.

- Do not use the appliance for purposes other than styling human hair.
- Keep the appliance away from non-heat-resistance surfaces and never cover the appliance with anything (e.g. clothing or towels) when it is hot.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk even when the appliance is switched off.
- Do not touch the plug with wet hands.
- CAUTION: Maintain the appliance dry.
- Do not use the appliance with damp hands or feet, or when barefooted.
- Do not use or store the appliance outdoors.
- Do not leave the appliance out in the rain or exposed to moisture. If water gets into the appliance, this will increase the risk of electric shock.
- This appliance is for household use only, not professional, industrial use.
- Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down.
- Do not force the power cord. Never use the power cord to lift up, carry or unplug the appliance.
- The product may only be charger in a dry and indoor location. To charge the product, only use a power supply that is classified as class II. Also, only use the USB-C-C charging cable provided.
- Do not use or charge the appliance near water. The appliance must not come into contact with water or other liquids while it is connected to the power supply.
- Do not submerge the product in water or other liquids while it is charging, as this poses a risk of electric shock.
- If the appliance falls into water while it is charging, do not reach for it! Unplug the mains adapter from the wall socket immediately. Allow the appliance, charging cable and mains adapter to dry out completely before connecting to the power supply again.
- The appliance must not be charged outdoors or in rooms with high humidity.
- To charge the appliance, only connect it to a properly installed wall socket with a mains voltage that complies with the technical specifications of the mains adapter.
- Remove the mains adapter from the wall socket if malfunctions occur during use, once the appliance is fully charged, during thunderstorms or before cleaning the appliance. To do so, always pull out the mains adapter and not the charging cable.
- Position the charging cable so that the appliance cannot be accidentally pulled down by it.
- The USB-C-C charging cable must not be kinked or squeezed. Keep the cable away from hot surfaces and sharp edges.
- Do not use or charge the appliance when the charging cable or mains adapter become damaged.
- The appliance contains a permanently installed lithium-ion rechargeable battery. Do not throw the appliance into a fire. Risk of explosion!
- The battery is non replaceable. Do not throw the battery into fire in case of battery explosion or release of toxic and hazardous substances. Do not short-circuit the battery to prevent fire caused by battery combustion.
- In the event of any batteries leaking, do not allow any liquid to come into contact with the skin or eyes. If contact has been made, wash the affected area with copious amount of water and seek medical advice.
- Do not store your device with metal objects, such as coins, keys and necklaces. Your device may overheat.
- Incorrect handling of the batteries can lead to an explosion or acid burns.
- Avoid contact of the fluid in the battery with skin, eyes and mucous membranes.
- Do not charge the appliance overnight.
- The appliance heats up quickly and the heating plates on the brush get extremely hot during use. Make sure to keep enough distance between the heating plates and your scalp, ears and face. Do not touch the heating plates on the brush.
- Do not use for longer than 2 hours at a time.
- Class II appliances must only be supplied at safety extra low voltage (SELV) corresponding to the marking on the appliance.
- Use only with ⊡ or 6V/2.C, 1A supply unit.

GENERAL FEATURES
1. Ceramic coated straightener brush teeth
2. On/off button
3. Indicator lights for temperature settings
4. USB-C-C charging port

TECHNICAL DATA
- 3 temperature settings: 160°C~180°C-200°C
- Electrical heating element
- Ceramic coated brush teeth
- 1m USB-C-C charging cable
- Charging voltage: 5.1V⎓1A
- Working voltage: 7.2V
- Rating power: 29W
- Rechargeable battery type: 21700 lithium-ion, DC 3.7V⎓4900mAh
- Charging time: approx. 5 hours
- Max. operation time: approx. 25-35 minutes (with battery fully charged)

IN THE BOX
The packaging should contain:
- Rechargeable hair straightener brush
- User guide: read these instructions before use.

CHARGING THE BATTERY
- Before using the appliance for the first time, the battery must be fully charged. The appliance cannot be switched on while charging.
1. Connect the USB-C-C charging cable to the appliance and a suitable mains adapter (adapter not included).
2. Plug the mains adapter into a wall socket. The charging process will begin automatically. When the product is charging, the red light of the charging indicator turns on and flashes. The product cannot be used while being charged.
3. When the appliance is charged, remove the mains adapter from the wall socket and disconnect the USB-C-C charging cable from the appliance. The hair straightener brush is now ready to use.
- The charging process takes about 5 hours. You can use the appliance for approximately 25-35 minutes when the battery is fully charged. If the product power is higher than 20%, the power indicator light is always on. Once the product power is lower than 20%, the power indicator turns orange. If the product power is lower than 10%, the power indicator flashes orange.
- To preserve the battery's full capacity, the battery should be recharged every 2 to 3 months, even if the appliance is not being used.
- Charge the battery at a temperature of +10°C to +40°C.

USE
What to do before first use:
- Remove the packaging material and inspect the device for damage.
- Do not operate the device if it is damaged in any way. Return it to your seller immediately.
- Only connect the appliance to a mains socket with the mains voltage indicated on the rating plate.
- When disconnecting the power cord from the power outlet, pull only on the plug. Never pull on the cord.
- During the first few minutes of the first use, you may notice a little smoke and a slight smell. This is normal and will soon disappear.
- Be aware that some surfaces may become hot. Do not touch and supervise others accordingly. The unit is VERY HOT when in use.
- Take care to avoid contact between the hot surface and bare skin, particularly around the ears, face and neck when in use.

INTENDED USE
- Warning! Only use the device indoors.
- The appliance is only intended for styling human hair.
- Any improper use can be dangerous!
- NEVER LEAVE YOUR APPLIANCE ON AND UNATTENDED!

HOW TO USE THE STRAIGHTENER BRUSH
1. Make sure your hair is dry. Comb your hair through to get rid of any knots.
2. Press the on/off button for 3 seconds to switch on the product, the product will have a default temperature of 180°C. According to different hair types, press the temperature gear key to select the appropriate temperature. When the product is warming up/cooling down, the white LED light is flashing. When the product reaches the set temperature, the white LED light of the current temperature and the one below is always on.
- Temperature options: 160°C: Bleached, damaged or fine hair; 180°C: Normal or slightly curly hair; 200°C: Thick, curly and coarse hair.
3. Separate the hair evenly, hold and pull it tightly. Hold the comb teeth 1-3cm from the root and slowly pull the straightener brush down to the hair tips. Repeat with all sections of your hair until you reach the desired straight hair look.
4. For inward curls, hold the hair with your hand and roll it slowly inwards around the comb. Leave the straightener brush in your hair for 3-5 seconds and repeat this movement 3 to 5 times to achieve the desired curly hair style. For outward curls, hold the hair with your hand and move it slowly outward. Leave the straightener brush in your hair for 3-5 seconds and repeat this movement 3 to 5 times.
5. Turn off the straightener brush by pressing the on/off button for 3 seconds. Make sure the appliance cools down fully.

CLEANING
Unplug the appliance and allow it to cool down. Use a soft, slightly damp cloth to wipe the appliance surfaces. Do not allow water or any other liquid to get into the unit. Care should be taken not to touch this part of the appliance when it is switched on or just after it has been turned off. ALLOW AT LEAST 30 MINUTES TO COOL DOWN BEFORE PUTTING AWAY.

STORAGE
Unplug the appliance, allow it to cool and store in its box or in a dry place. Never store it while it is hot or still plugged in. Never wrap the cord tightly around the appliance. Never hang the unit by the cord. Store the cord loosely coiled. Do not put any stress on the cord where it enters the unit, as it could cause the cord to fray and break.

CORRECT DISPOSAL OF THIS PRODUCT

	The crossed through bin with ground bar symbol means that this product shall not be disposed of with normal household waste. Electronic and Electrical Equipment not included in the selective sorting process are potentially dangerous for the environment and human health due to the presence of hazardous substances. Please dispose of responsibly at an approved waste or recycling facility.
	Please remove the battery before disposing of the device/unit. Do not dispose of old batteries with your household waste, but at a battery collection station at a recycling site or in a shop. Consult your municipal authority or your dealer for information about disposal.

WARRANTY
The manufacturer provides warranty in accordance with the legislation of the customer's own country of residence, of 3 years, starting from the date on which the appliance is sold to the end user.
- The warranty only covers defects in material or workmanship.
- The repairs under warranty may only be carried out by an authorized service center. When making a claim under the warranty, the original bill of purchase (with purchase date) must be submitted.
- The warranty will not apply in cases of:
1. Normal wear and tear
2. Incorrect use, e.g., overloading of the appliance, use of non-approved accessories
3. Use of force, damage caused by external influences
4. Damage caused by non-observance of the user manual, e.g., connection to an unsuitable main supply or non-compliance with the instructions on cleaning
5. Partially or completely dismantled appliances
6. The accessories are not covered by the terms of the warranty because they are subject to wear.
If you need more information or support, please contact us via: www.arovo.com/contact

In accordance with our policy of continual product improvement, we reserve the right to make technical and visual changes without notice. The current version of this instruction manual can be found under www.arovo.com/manuals

EU DECLARATION OF CONFORMITY

We, **The Great Product Exchange Ltd, Royal Chambers, 110 Station Parade, Harrogate North Yorkshire, HG1 1EP, United Kingdom, www.thegreatbritishexchange.com**

Part of Arovo B.V., Dobljn 26, 1046 BN Amsterdam, The Netherlands, www.arovo.com

declare under our own responsibility that the product:

Article number: **527334**

Article name: **COSMOPOLITAN RECHARGEABLE HAIR STRAIGHTENER BRUSH**

Barcode: **8721098346338 (BLUE) - 8721098345799 (PEACH)**

a) The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:
ROHS: 2011/65/EU
REACH: EC 1907/2006

b) Meets the conditions laid down in the following harmonised standards:
EN IEC 55014-1:2021
EN IEC 55014-2:2021

Michael van Dijk - Quality manager
June 6, 2025
Amsterdam - The Netherlands

AROVO.
Dobljn 26
1046 BN Amsterdam
The Netherlands
+31 (0) 85 273 88 86

The current version of this Declaration of Conformity can be found under www.arovo.com