## **PREPARATION**

The surface must be clean and dry, free from grease, rust and dirt. Protect adjoining surfaces from overspray.

Due to the mirror finish of this paint, use a damp cloth to make sure the surface is clean and free from finger prints.

## **BEFORE SPRAYING**

Shake can for at least three minutes before use and regularly during use. Lower temperatures and high humidity will slow the drying.

Avoid spraying when air or surface temperature is below 10°C or above 30°C.

## **SPRAY APPLICATION**

Hold can upright 15 to 25cm from the surface. To ensure surface compatibility, test spray on an inconspicuous area.

Spray with smooth, even strokes parallel to the surface.

Apply 2 full even coats with twenty minutes in between each coat. Allow for drying time of 20 minutes between each coat.

Coverage: Up to 2.5m2 per can, depending on surface and colour used.

Dry Time: Touch dry in 24 hours under normal conditions.

## **AFTER SPRAYING**

Prevent blocking by turning the can upside down and spraying until clear gas emerges. Also wipe front of nozzle clean.

Clean up overspray with water while wet and white spirits when dry.

To keep your finished items looking their best, ensure your hands are clean and free of grease and oil when you handle them.