

**PREPARATION**

The surface must be clean and dry, free from grease, rust and dirt. Protect adjoining surfaces from overspray.

If undercoating is necessary use Craig & Rose Undercoat.

Prime all bare steel and iron with Craig & Rose Metal Primer.

Prime all plastic with Craig & Rose Plastic Primer.

Must be over-coated with Artisan clear coat to protect the dry film from abrasion and wear damage.

**BEFORE SPRAYING**

Shake can for at least three minutes before use and regularly during use. Lower temperatures and high humidity will slow the drying.

Avoid spraying when air or surface temperature is below 10°C or above 30°C.

**SPRAY APPLICATION**

Hold can upright 15 to 25cm from the surface. To ensure surface compatibility, test spray on an inconspicuous area.

Spray with smooth, even strokes parallel to the surface.

Apply with several light mist coats rather than one heavy coat. Allow for drying time of 20 minutes between each coat. Recoat: Spray three full coats with twenty minutes in between each coat.

Coverage: Up to 1m<sup>2</sup> per can, depending on surface and colour used.

Dry Time: Touch dry in 24 hours under normal conditions.

**AFTER SPRAYING**

Prevent blocking by turning the can upside down and spraying until clear gas emerges.

Also wipe front of nozzle clean.

Clean up overspray with water while wet and white spirits when dry.