

**PREPARATION**

The surface must be clean and dry, free from grease, rust and dirt. Protect adjoining surfaces from overspray.

Can be applied over any other base colour.

Make sure surface is as smooth as possible. Sand with extra fine P400-P600 sandpaper if required.

**BEFORE SPRAYING**

Shake can for at least three minutes before use and regularly during use. Lower temperatures and high humidity will slow the drying.

Avoid spraying when air or surface temperature is below 10°C or above 30°C.

**SPRAY APPLICATION**

Hold can upright 15 to 25cm from the surface. To ensure surface compatibility, test spray on an inconspicuous area.

Spray with smooth, even strokes parallel to the surface.

Apply with several light mist coats rather than one heavy coat. Allow for drying time of 60 minutes between each coat. Recoat: Spray one or more coats of Diamond Silver Effect to achieve the desired glitter density.

Dry Time: Touch dry in 60 minutes. 24 hours under normal conditions.

**AFTER SPRAYING**

Prevent blocking by turning the can upside down and spraying until clear gas emerges.

Also wipe front of nozzle clean.

Clean up overspray with water while wet and white spirits when dry.