

PREPARATION

The surface must be clean and dry, free from grease, rust and dirt. Protect adjoining surfaces from overspray.

Prime all bare steel and plastic with an appropriate primer.

BEFORE SPRAYING

Shake can for at least three minutes before use and regularly during use. Lower temperatures and high humidity will slow the drying.

Avoid spraying when air or surface temperature is below 10°C or above 30°C.

SPRAY APPLICATION

Hold can upright 15 to 25cm from the surface. To ensure surface compatibility, test spray on an inconspicuous area.

Spray with smooth, even strokes parallel to the surface.

The product is formulated to resist running and sagging. It should be applied in one or more light coats, rather than one heavy coat. Recoat: anytime after 20 minutes

Coverage: Up to 4.5m² per can, depending on surface and colour used.

Dry Time: Touch dry in 20 minutes under normal conditions.

AFTER SPRAYING

Prevent blocking by turning the can upside down and spraying until clear gas emerges.

Also wipe front of nozzle clean.

Clean up overspray with water while wet and white spirits when dry.