

# NEXT


## BRONX WIDE BEDSIDE

D43145

Assembly instructions

### Actual product size

H60 X W65 X D39cm



## Need Help ?

With: Assembly instruction

Missing or damaged parts

**IMPORTANT - RETAIN FOR FUTURE REFERENCE**

**CALL: 0333 777 8999**

### BEFORE YOU START

#### Number of people required to assemble


Two people are required to assemble this item



**Time to assemble : 30 minutes**



#### Tools required



not supplied

#### Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

#### Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to de-laminate.


Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

# NEXT

## BRONX WIDE BEDSIDE

D43145  
Assembly instructions

### GETTING TO KNOW YOUR PRODUCT













# NEXT





## BRONX WIDE BEDSIDE

### D43145



### Assembly instructions

Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	56x2cm		2	1
2	38x4cm		2	1
3	65x39cm		1	1
4	44.5x39cm		1	1
5	29.5x62.5cm		1	1
6	37x62cm		1	1
7	62x14.5cm		1	1
8	44.5x39cm		1	1
9	65x39cm		1	1
10	56.5x10.5cm		2	1

Ref	Dimensions	Visual	Qty	Ctn
11	30x10.5cm		2	1
12	30x10.5cm		2	1
13	57.5x29cm		2	1
14	61x14.5cm		2	1

## NEXT FITTINGS ASSEMBLE INSTRUCTIONS



Push connector into housing to join.



Make sure there is no gap between the panels.


## BRONX WIDE BEDSIDE

### D43145

### Assembly instructions

#### Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
Y35	Ø6 x 40mm	6	1
Y29	Ø6 x 14mm	4	1
D6	Ø8 x 30mm	N/A	1



#### Fixtures and fittings supplied ( not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
T4	N/A	2	N/A	
E48	N/A	2	N/A	
T38	N/A	4	1	

NEXT

BRONX WIDE BEDSIDE  
D43145  
Assembly instructions

1

Diagram illustrating the assembly of the bed frame. The side rails (1) are attached to the headboard and footboard (2) using T4 corner braces and Y29 screws. The inset shows a hand inserting a screw into a pre-drilled hole.

T4	N/A	2	
Y29	Ø6 x 14mm	4	

2

Diagram illustrating the assembly of the bed frame. The mattress support (3) is attached to the side rails (1) using T4 corner braces and Y35 screws. The inset shows a hand inserting a screw into a pre-drilled hole.


T4	N/A	2	
Y35	Ø6 x 40mm	6	

# NEXT


## BRONX WIDE BEDSIDE

D43145  
Assembly instructions

3



4




# NEXT


## BRONX WIDE BEDSIDE

D43145  
Assembly instructions

5



6




# NEXT


## BRONX WIDE BEDSIDE

D43145  
Assembly instructions

7



8





# NEXT

## BRONX WIDE BEDSIDE

D43145  
Assembly instructions

9




# NEXT

## BRONX WIDE BEDSIDE

D43145  
Assembly instructions


10



SLOTS ALIGNED

x2

11




x2

# NEXT BRONX WIDE BEDSIDE

D43145  
Assembly instructions


12

Note: Drawer will be permanently assembled once panel 14 is fitted.






x2

13





x2

E48	N/A	2			 not supplied
-----	-----	---	---	---	---


# NEXT BRONX WIDE BEDSIDE

D43145  
Assembly instructions


14



Left side



Right side




**NEXT**

## BRONX WIDE BEDSIDE

D43145

Assembly instructions

15



**A=B**

# NEXT BRONX WIDE BEDSIDE

## D43145

### Assembly instructions

16

We recommend the use of the wall attachment bracket/strap provided for safety reasons. Secure the other end of the strap to the wall with an appropriate screw and wall plug for your wall type (not provided).


To hide the strap behind the unit, drill the hole lower than the top of unit.



Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type.

If in doubt please consult a qualified trades person.

Please ensure you secure your product to the wall for your and your family's safety before you use it.



T38	N/A	4		
-----	-----	---	---	---

not supplied







# NEXT

## BRONX WIDE BEDSIDE D43145

17

To disassemble:

Step1: Remove the plastic wedge (T38) from the back panel (5), and remove the screws from the top panel(9) and bottom panel (3);





# NEXT BRONX WIDE BEDSIDE

D43145



18

Step2: Press down the back panel so it is clear of the panel (6) slot;



19

Step3: Slide the top panel front to unlock, then lift off;




# NEXT BRONX WIDE BEDSIDE

D43145


20

Step4: Slide the back panel (7) up to unlock, then slide the panel (6) front to unlock;



21

Step5: Lift the back panel (5) up, then slide the side panel (4) and side panel (8) front to unlock, then lift off.  
Follow the same sequence to remove the other panels;




# NEXT

## BRONX WIDE BEDSIDE

D43145

### Actual product size

H60 X W65 X D39cm



# NEXT

## BRONX WIDE BEDSIDE D43145

### Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

### Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

### Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

### You can write to us at

Home Customer Services  
Next Retail Ltd.  
Desford Road,  
Leicester,  
LE19 4AT

To view our full furniture range please visit [www.next.co.uk](http://www.next.co.uk)