7 IN 1 COMBO TABLE

Assembly and Use Instructions



91407-UK

Important Safety Information – read this page first


- It is important to read this entire manual before assembling and using the games table. Safe and effective use can only be achieved if the table is assembled, maintained and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.
- 2. Due to the presence of small parts, keep babies and children under 36 months, away from the games table.
- 3. Supervise at all times all children whilst the games table is being used.
- Use the games table on a solid, flat level surface with a protective cover for your floor or carpet.
 Please ensure sufficient space around the games table to allow the players room to move freely.
- 5. Before using the games table, check the component parts and the nuts and bolts are securely tightened. On a periodic basic, check thoroughly all fixings to ensure they are secure.
- 6. The safety level of the games table can only be maintained if it is regularly examined for damage and/or wear and tear.
- 7. Replace defective components immediately and keep the equipment out of use until repaired.
- 8. Warning: the games table shall be installed on a stable base and properly levelled. Always use the games table as indicated. If you find any defective components while assembling or checking the equipment, or if you encounter issues with the games table during use, stop using the games table, and check the issue. Do not use the games table until the issue has been rectified.
- 9. The games table has been tested and certified to BS EN71 Safety of Toys, suitable for domestic, home use only.
- 10. Care must be taken when lifting or moving the equipment so as not to injure your back. Always use proper lifting techniques and/or use assistance.
- 11. FAQ's: any questions, please contact our UK Helpline 01274 693888


WARNING: Misuse of this product may result in serious injury. Read these Assembly and Use Instructions and follow all warnings and instructions before using this games table.




WARNING: Not suitable for children under 36 months: Small parts


Please Keep Your Instructions. Before attempting assembly, please read through this instruction book to familiarize yourself with all the parts and assembly steps. We recommend that two adults assemble this game. First, carefully unpack every part and lay them out on a protective surface. Please refer to the Parts List below to check that all parts have been included. Please phone the UK Helpline should there be any issues.









1. Fit the Motor to the underside of the Games Table using the parts shown. Connect the adapter to



2. Turn the playing surface over and fix in place using 4x #12 screws. Fit the goal brackets to the ends of the table as shown.




3. Assemble the legs. Carefully lay out the main parts of the leg assemblies, taking time to ensure they are the right way round, and assemble using the parts shown. When assembling, loosely tighten the fixings, and when they are all located and loosely fitted, go back and tighten them all securely.




UK Helpline No. 01274 693888

4. Attach the leg assemblies to the Table as shown, taking care to align the central spindle to the table. We recommend 2 people cooperate to complete this stage




5. Assemble the leg braces. Carefully lay out the main parts, taking time to ensure they are the right way round, and assemble using the parts shown. Fit all the fixings first, only loosely and once all are fitted, go back and tighten them all securely.




UK Helpline No. 01274 693888

6. Attach the side brackets to the Table as shown, taking care to align the screws. Fit the net supports into the side brackets and carefully slide the side nets onto the supports as shown.



7. Assemble the net slide. Carefully lay out the main parts, taking time to ensure they are the right way round, and assemble using the parts shown. Fit all the fixings first, only loosely and once all are fitted, go back and tighten them all securely.



UK Helpline No. 01274 693888

8. To rotate the table, loosen and remove the two locking knobs. Carefully turn the table over, checking there are no children, hands or fingers near the table, and secure in place with both locking knobs before starting play. Always check the fittings are secure before using the table.

