

# **12 IN 1 COMBO TABLE**

## **Assembly and Use Instructions**



**91412-UK**

# Important Safety Information – read this page first

1. It is important to read this entire manual before assembling and using the games table. Safe and effective use can only be achieved if the table is assembled, maintained and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.
2. Due to the presence of small parts, keep babies and children under 36 months, away from the games table.
3. Supervise at all times all children whilst the games table is being used.
4. Use the games table on a solid, flat level surface with a protective cover for your floor or carpet. Please ensure sufficient space around the games table to allow the players room to move freely.
5. Before using the games table, check the component parts and the nuts and bolts are securely tightened. On a periodic basic, check thoroughly all fixings to ensure they are secure.
6. The safety level of the games table can only be maintained if it is regularly examined for damage and/or wear and tear.
7. Replace defective components immediately and keep the equipment out of use until repaired.
8. Warning: the games table shall be installed on a stable base and properly levelled. Always use the games table as indicated. If you find any defective components while assembling or checking the equipment, or if you encounter issues with the games table during use, stop using the games table, and check the issue. Do not use the equipment until the issue has been rectified.
9. The games table has been tested and certified to BSEN71 Safety of Toys, suitable for domestic, home use only.
10. Care must be taken when lifting or moving the equipment so as not to injure your back. Always use proper lifting techniques and/or use assistance.

**WARNING:** Misuse of this product may result in serious injury. Read these Assembly and Use Instructions and follow all warnings and instructions before using this games table.
















































**WARNING:** To be used under the direct supervision of an adult



**WARNING:** Not suitable for children under 36 months: Small parts

# ASSEMBLY INSTRUCTIONS

Please Keep Your Instructions. Before attempting assembly, please read through this instruction book to familiarize yourself with all the parts and assembly steps. We recommend that two adults assemble this game. First, carefully unpack every part and lay them out on a protective surface. Please refer to the Parts List below to check that all parts have been included. Please phone the UK Helpline should there be any issues.

1  SIDE APRON 2EA	2  END APRON 2EA	3  SOCCER PLAYFIELD 1EA	4  SUPPORT BRACE 2EA	5  TT/HOCKEY PLAYFIELD 1EA	6  LEG 4EA	7  M6X30MM BOLT 16EA	8  M6 WASHER 16EA
9  3.5X10.5MM WASHER HEAD SCREW 8EA	10  3.5X35MM WASHER HEAD SCREW 12EA	11  4X20 TM 26EA	12  NUT 26EA	13  ALLEN WRENCH 1EA	14  3 HOLES PLAYER ROD 4EA	15  2 HOLES PLAYER ROD 2EA	16  5 HOLES PLAYER ROD 2EA
17  4EA	18  PLAYER(BLUE) 11EA	19  PLAYER(RED) 11EA	20  STOP RING 4EA	21  HAND GRIP 8EA	22  END CAP 8EA	23  RUBBER BUMPER 16EA	24  CABINET FOR BILLIARD 1EA
25  SHUFFLE BALL 1 SET	26  SOCCER BALL 3EA	27  BOWLING PLAY BOARD 1EA	28  HORSE SHOES & RING TOSS 1 SET	29  BILLIARD BALLS 1SET	30  CUE STICK 2EA	31  CHALK 2EA	32  TRIANGLE 1EA
33  HOCKEY PUSHER 2EA	34  HOCKEY PUCK 2EA	35  FELT PAD 2EA	36  BOWLING PIN 1SET	37  CHESS SET 1SET	38  CHECKER SET 1SET	39  GOAL BOX 2EA	40  BACKGAMMON SET 1SET
41  PLAYING CARD 1DECK	42  TABLE TENNIS BALL 3EA	43  TABLE TENNIS PADDLE 2EA	44  NET & POST SET 1SET	45  Player Rod Bushing 16 SETS	46  BALL ENTRY 2 SETS	47  HOCKEY GOAL WITH SCORER 2EA	

1) Open the carton of your new games table near where you will play. Select a clear level floor. This table requires at least two adults for assembly.

2) Remove all the contents from inside the carton and verify that you have all listed parts as shown on the Parts List. We suggest that you use the bottom carton as a clean flat working area to protect the game. Carefully cut or tear the four carton corners so that the bottom is now your work area.


# ASSEMBLY INSTRUCTIONS

**FIG.1.**

3) Attach one End Apron (#2) between the Side Aprons (#1) using two of Washer Head Screws (#10) per Side. See FIG.1.

NOTE: Leave connections loose - Do not tighten screws securely at this time.


4) Slide the Playfield (#3) with graphics facing down as shown in FIG 1.If the field does not slide smoothly, check to be sure you have not over tightened any screws or the playfield is not caught by the slot.



**FIG.2.**

5) Repeat the step to attach the other End Apron to the Side Aprons (#1).

6) Place two Support Braces (#4) on Playfield (#3) as shown in FIG.2. Attach them using two of Washer Head Screw (#10) per side. See FIG.2.






# ASSEMBLY INSTRUCTIONS

**FIG.3.**


7) Attach the player rods (#14 - #16) into the side aprons as shown in FIG.3A. Attach rubber bumper (#23) to the player rod, followed by the players (#18 & #19) and another rubber bumper (#23). For the two goalie player rods an additional stop ring (#20) will be needed to be added between the goalie.

8) Attach Stop Rings (#20) and Players (#18 & #19) to the player rods using one 4x20TM(#11) and one Nut(12) See FIG.3B.



**FIG.4.**


9) Attach Goal Boxes (#39) to End Aprons using four Washer Head Screws W (#9) per Goal Box. See FIG.4.



# ASSEMBLY INSTRUCTIONS

## FIG.5.



11) Put Hand Grips (#21) and End Caps (#22) on the player rods in order. NOTE: To make the Handles easier to attach, spray a little window cleaner on the rod ends prior to installation and tap on gently with a mallet, taking care not to damage the handles. See FIG.5.



## FIG.6 & 7.

12) Attach the four legs (#6) to the cabinet (#24), using four Bolts (#7) and four Washers (#8) per leg. Screw the leg leveller (#17) to the legs as shown. See Fig 6.

13). Lift the table assembly from the floor with two strong adults, turn it over, and set table on its legs in the location where you will play. Go back and make sure that all connections are tight. See Fig 7.




# ASSEMBLY INSTRUCTIONS

## FIG.8 & 9.

14) Place the table game elements together in the order shown. See Fig 8.

15) Stick the felt pads to the Hockey Pushers as shown. See Fig 9.



**YOU ARE NOW READY TO PLAY!**