

BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

1. COLOUR

Make sure you're happy with the colour
No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3. PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions .

TIPS FOR RETURNS

Not completely happy with the product? No problem. We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



Check everything is there (the 'parts page' is a handy checklist).

Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.

Wrap all the big components back up in the original protective packaging.

Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T



Leave anything assembled - all components should be dismantled and separately packed.

Put loose fixtures and fittings straight into the box.

Throw it back in the box carelessly – as it may get damaged.

next
HOME

Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.

next

BLAKE HOUSE BED


118554015

Assembly instructions

IMPORTANT - KEEP FOR FUTURE REFERENCE

Actual product size

H89 x W101 x D198cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

CALL: 0333 777 8999

BEFORE YOU START

This bed conforms to BS 8509:2008+A1:2011

Warnings

WARNING: Do not place this child's bed near heat sources windows and other furniture.

WARNING: Do not use this item if any components are missing or damaged.

WARNING: Assembly to be carried out by a competent adult only.

WARNING: Once assembled this bed is not designed to be disassembled and reassembled.

WARNING: Not suitable for children under four years.

Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, blind cords, curtain pulls or other strings or cords and should be placed either tight to any wall or have a gap of 300mm between the wall and the side of the bed

Any additional or replacement parts are obtained from the manufacturer or distributor

Gloss finishes are prone to light surface scratches and it is therefore very important that you care for this item correctly.

During assembly children should be kept away from the product due to possible risk of injury.

This product is suitable for children in the age range of 4-12 years.

Installation shall be carried out exactly according to the manufactures instructions – otherwise a safety risk can occur if incorrectly installed.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

This size of the mattress to be used with the bed is 900x1900 mm.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Check fixings regularly to ensure they remain tight.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

For general cleaning, periodically dust with a soft clean lint-free cloth or a soft micro fibre cloth (ie, e-cloth brand or similar). Please note some cloths (including yellow dusters) contain abrasive fibres which can lightly scratch the surface, if in doubt please try your cloth in an inconspicuous area of the furniture first to assess its suitability. A sample of a suitable cloth for cleaning is included within the hardware pack.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to de-laminate.


Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

Do not stand or jump on this product..

Number of people required to assemble


Two persons are required to assemble this item.

Time to assemble




30 MIN

2 PERSON
BUILD



Tools required



not supplied

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians


If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at







Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT








To view our full furniture range please visit www.next.co.uk

GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement

Ref	Dimensions	Visual	Qty	Ctn
1	191 x 39,8 cm		1	3
2	191 x 39,8 cm		1	3
3	95,4 x 40 cm		1	2
4	95,5 x 40 cm		1	2
5	90,9 x 28,2 cm		2	2
6	95,3 x 90,9 cm		2	3

Ref	Dimensions	Visual	Qty	Ctn
7	68,4 x 30 cm		1	1
8	68,4 x 30 cm		1	1
9	54,7 x 30 cm		1	1
10	54,7 x 30 cm		1	1
11	96,5 x 52 cm		1	2
12	95,5 x 10 cm		1	1
13	95,5 x 10 cm		2	1

Fixtures and fittings
supplied (actual size)


Ref	Dimensions	Qty
F08		2
W32	3,5x16mm	4
W16	4x20mm	16
W20	4x40mm	14



Fixtures and fittings supplied (not to scale)


Ref	Dimensions	Qty	Visual
F11	80,5x65x65mm	4	
K01	⌀ 4mm	1	

1




DON'T STOP UNTIL THE 2 O'CLOCK LOCK

TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITIONS SHOWN IN THE DIAGRAMS BELOW




START





CORRECT LOCK



2





4


5




W16	16	
F11	4	

6




W20	8	
-----	---	---


7




8




9



10




11






F08

2





12



W32	4	
W20	4	

13



W20	2	
-----	---	---

14

H89 x W101 x D198cm

