

next


SALVAGE CABIN BED

175296

Assembly instructions

Actual product size

H79.1 x W198 x D97.6cm



**IMPORTANT- RETAIN FOR FUTURE
REFERENCE- READ CAREFULLY.**

Need Help?

With: Assembly instructions
Missing or damages parts

CALL: 0333 777 8999


BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble



Tools required



not supplied

Do's

When you are ready to start, make sure that you have the right tools and plenty of space.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Please periodically check all fittings and re-tighten as necessary.

To clean your item, wipe with soft cloth slightly dampened with water. Then buff with a dry clean cloth.

Routinely check that the fittings are secure and tighten any fittings using the appropriate tools.

If any parts are missing please contact Next to obtain replacements. Under no circumstances should missing parts or hardware be substituted unless obtained from Next.


Don'ts

Do not drag or pull your furniture.











Do not use silicone based furniture polish. Silicone in furniture polishes can break down the lacquer finish.










Do not stand or jump on this product.

GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts

Ref	Dimensions	Visual	Qty	Ctn
1	191.8 x 92cm		1	1
2	192 x 12cm		2	1
3	192 x 51cm		1	1
4	192 x 5.8cm		1	1
5	79 x 97.5cm		1	2
6	58.3 x 97.5cm		1	2
7	46 x 51.2cm		1	1
8	46 x 51.2cm		1	1
9	94.1 x 45.9cm		1	2
10	47.4 x 46cm		2	1



Ref	Dimensions	Visual	Qty	Ctn
11	94.1 x 11cm		1	2
12	48 x 39.2cm		1	2
13	48 x 39.2cm		1	2
14	94.4 x 19.3cm		1	2
15	91.6 x 11.8cm		1	2
16	34 x 11.8cm		1	2
17	34 x 11.8cm		1	2
18	34 x 6cm		1	2
19	90.1 x 34.9cm		1	2

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
a	Ø5 x 50mm	2	1
b	Ø4 x 40mm	6	1
c	Ø8 x 38mm	N/A	2
d	Ø6 x 30 mm	N/A	2
d1	Ø10 x 50 mm	N/A	1
f	Ø15 x 12.7mm	N/A	2
f1	Ø15 x 9.5mm	N/A	1




Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
p	N/A	4	N/A	
q	N/A	4	N/A	

1

With edge banding




WHEN TIGHTENING THE CAM

TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITIONS SHOWN IN THE DIAGRAMS BELOW




START




MAXIMUM LOCK



PUSH THE TWO PANELS TOGETHER ALLOWING THE DOWEL TO ALIGN WITH THE HOLE





TURN THE CAM IN A CLOCKWISE DIRECTION




2




3




4




5




6




7




8





9




10




11




12




13




14



15




16





q x 4




PH2
not supplied



17




Door hinge adjustment instructions



A. Side to side adjustment by clockwise or anticlockwise adjustment .

B. Up and down adjustment by adjusting mounting plate slot.

C. Front to back adjustment by rotating screw clockwise or anticlockwise.




Note :
Lock the hinge
after adjustment !

next SALVAGE CABIN BED

175296

Actual product size

H79.1 x W198 x D97.6cm



WARNINGS

WARNING: Do not place this child's bed near heat sources, windows and other furniture.

WARNING: Do not use this child's bed, if any part is broken, torn or missing.

WARNING: Assembly by adults only

WARNING: Once assembled this bed is not designed to be disassembled and and reassembled. Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, blind cords, curtain pulls or other strings or cords and should be placed either tight to any wall or have a gap of 300mm between the wall and the side of the bed. This size of the mattress to be used with the child's bed is 900mm x 1900mm. This Child's bed is intended for children above 4 years old

WARNING: Not suitable for children under 4 year

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk