

# BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

## 1.COLOUR

Make sure you're happy with the colour  
No need to unpack everything, just check the first component.

## 2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

## 3.PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

## TIPS FOR RETURNS

Not completely happy with the product? No problem.

We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



- Check everything is there (the 'parts page' is a handy checklist). Check everything is the
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T



- Leave anything assembled - all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly – as it may get damaged.

next  
HOME

Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.



next


# Remy Tall Chest

24 66 65

Assembly instructions

## Actual product size

H132 x W47 x D39



**IMPORTANT – RETAIN THESE INSTRUCTIONS  
FOR FUTURE REFERENCE**

## Need Help?

With: Assembly instruction  
Missing or damaged parts

**CALL: 0333 777 8999**

### BEFORE YOU START

#### Warnings

Conforms to BSEN4875 & BSEN14749

Do not use chest if any part is broken, torn or missing.  
We suggest you retain these instructions for future reference.  
Gloss finishes are prone to light surface scratches and it is therefore very important that you care for this item correctly.  
Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.  
Please periodically check all fittings and re-tighten as necessary.  
Please do not sit or stand on your furniture.  
Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.  
Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.  
Assembly to be carried out by a competent adult only.  
During assembly children should be kept away from the product due to possible risk injury.  
Do not use this item if any components are missing or damaged.  
This product is suitable for children in the age range of children for which the product is designed (7-12 years).

#### Do's

We suggest you spend a short time reading through this leaflet before you start.  
When you are ready to start, make sure that you have the right tools and plenty of space.  
Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.  
Carefully check that you have all the parts before beginning assembly.  
Due to the size of this product we recommend that it is assembled in the room intended for use.  
Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.  
Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.  
For general cleaning, periodically dust with a soft clean lint-free cloth or a soft micro fibre cloth (ie, e-cloth brand or similar). Please note some cloths (including yellow dusters) contain abrasive fibres which can lightly scratch the surface, if in doubt please try your cloth in an inconspicuous area of the furniture first to assess its suitability. A sample of a suitable cloth for cleaning is included within the hardware pack.


#### Don'ts

Do not drag or pull your furniture.  
Do not rub or scrub the surface when cleaning.  
Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.  
Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.  
Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

#### Number of people required to assemble

Two persons are required to assemble this item.

#### Time to assemble




30 MIN

2 PERSON  
BUILD



#### Tools required



not supplied

#### Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

#### Home service technicians


If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

#### You can write to us at












Home Customer Services  
Next Retail Ltd.  
Leicester,  
LE19 4AT

To view our full furniture range please visit [www.next.co.uk](http://www.next.co.uk)

## GETTING TO KNOW YOUR PRODUCT












Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	117,2 x 37,5cm		1	1
2	117,2 x 37,5cm		1	1
3	30 x 14cm		5	1
4	30 x 14cm		5	1
5	46,5 x 23,4cm		5	1
6	43,8 x 10cm		1	1
7	38,9 x 14cm		5	1
8	47 x 37,5cm		1	1
9	47 x 39,1cm		1	1
10	118,6 x 45,2cm		1	1
12	40 x 29,9cm		5	1




**Fixtures and fittings  
supplied (actual size)**

Ref	Dimensions	Qty
J23		30
P13	3,5x13	1
G22	ø5	2
B1	ø8x28	52
T11		50
M11	ø15x12	10
M10	ø15x10	40
E2	6x20	4
S25	4x20	12
A14	M4x22	10

0 10 20 30 40 50 60 70 80 90 100 110 120







**Fixtures and fittings supplied (not to scale)**

Ref	Dimensions	Qty	Visual
U23		5	
N33		4	
J44		1	



1




x5



B1	ø8x28	40	
T11		20	

2

x5




M10	ø15x10	20		
-----	--------	----	--	--

# next Remy Tall Chest

24 66 65  
Assembly instructions


3

x5



4






x5





# next Remy Tall Chest






24 66 65  
Assembly instructions



5







T11	1	
B1	4	

6




T11	1	
B1	4	

7





B1

4




8



E2

6x20

4



S25



4x20

12



N33




4



# next Remy Tall Chest


24 66 65  
Assembly instructions

9




T11

8





10



M11

ø15x12



2





# next Remy Tall Chest

24 66 65  
Assembly instructions



11





M11 ø15x12 4




12



M11 ø15x12 4





13








J23

10



14

Installation shall be carried out exactly according to the manufacturer's instructions – otherwise a safety risk can occur if incorrectly installed.  
**WARNING** in order to prevent overturning this product must be used the wall attachment devices provided (J44, P13, G22).  
 Wall fixings are not included, please source suitable fixings for your wall type. If in doubt, please consult a qualified trades person.  
**WARNING:** Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.






P13	3,5x13mm	1	
G22	ø5	2	
	not supplied	1	
J44		1	



# next Remy Tall Chest

24 66 65  
Assembly instructions

15



A14	10	
U23	5	



16

