


NEXT

BRONX / BRONX GREY OTTOMAN

267922/U69947
Assembly instructions

Actual product size

H47 x W92 x D40cm



Need Help ?

With: Assembly instruction
Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start

When you are ready to start, make sure that you have the right tools and plenty of space

Unwrap all packaging materials and place the components on a clean surface to protect it from damage,
We recommend that the packaging is used to protect the surfaces during assembly

Carefully check that you have all the parts before beginning assembly

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use

Check fixings regularly to ensure they remain tight

Always ensure that protectors are used on the legs

To clean your item, please use a soft cloth slightly dampened with water and wipe clean. Then buff with a dry clean cloth

Don'ts

When moving furniture never drag the pieces across the floor, as this will cause damage to the joints or potential damage to the floor

Apply Adhesive substrates for example, sticky tape to the product

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the lacquer finish


Never allow any kind of liquid to remain on your furniture. Absorption can cause finishes to de-laminate and or stain

Never stand or lean back on your furniture

NEXT

BRONX / BRONX GREY OTTOMAN
267922/U69947
Assembly instructions











GETTING TO KNOW YOUR PRODUCT



NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	2 x 34cm		2	1
2	34 x 85.5cm		1	1
3	20 x 89.5cm		2	1
4	1.8 x 34cm		2	1
5	20.5 x 90cm		1	1
6	20.5 x 35cm		1	1
7	20.5 x 35cm		1	1
8	20.5 x 90cm		1	1
9	38.5 x 90cm		1	1
10	40 x 92cm		1	1


NEXT

BRONX / BRONX GREY OTTOMAN

267922/U69947
Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
B3	Ø15 x 12mm	18	2
B12	Ø7.5 x 33mm	18	2
D6	Ø8 x 30mm	N/A	2
U139	Ø4.5 x 15mm	4	1
U119	Ø4 x 14mm	8	1
Y8	Ø6 x 50mm	10	2
V35	Ø6 x 12mm	8	1
V53	Ø6 x 30mm	10	2




Fixtures and fittings supplied (not to scale)



Ref	Dimensions	Qty	Spare Qty	Visual
T1	N/A	2	N/A	
H38	N/A	1	N/A	
H39	N/A	1	N/A	
C19	N/A	2	N/A	
O1	Ø25mm	8	1	
J2	N/A	3	1	
A9	N/A	2	N/A	

NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

1




B12	Ø7.5 x 33mm	18			PH2 not supplied
-----	-------------	----	---	---	---------------------

NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

2




B3 Ø15 x 12mm

4



3



V35 Ø6 x 12mm

4



B3 Ø15 x 12mm


3






NEXT


BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions


4



V35	Ø6 x 12mm	4	
B3	Ø15 x 12mm	3	  not supplied

5




T1	N/A	2	
----	-----	---	---

NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

6




B3 Ø15 x 12mm

4



7



B3 Ø15 x 12mm


4



NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

8




A9

N/A

2



9



Y8

Ø6 x 50mm


10



T1

N/A


2





NEXT


BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

10



V53	Ø6 x 30mm	10	
T1	N/A	2	

11







NEXT

BRONX / BRONX GREY OTTOMAN


267922/U69947
Assembly instructions





12



C19	N/A	2	
U139	Ø4.5 x 15mm	4	  not supplied

13




H38	N/A	1	
H39	N/A	1	
U119	Ø4 x 14mm	4	  not supplied


NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947 Assembly instructions

14




15



U119

Ø4 x 14mm



4



not supplied

16

Adjust Hinge Position



WHEN LOOSENING THE CAM
TURN THE CAM IN A COUNTERCLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITION SHOWN IN THE DIAGRAMS BELOW


The diagram shows three stages of cam adjustment. The first is 'MAXIMUM LOCK' with an arrow pointing to the top-right. The second is 'TURN TO UNLOCK' with a dashed arrow showing a counter-clockwise rotation. The third is 'UNLOCKED' with an arrow pointing to the bottom.

O1	Ø25mm	8	
J2	N/A	3	

NEXT

BRONX / BRONX GREY OTTOMAN 267922/U69947

Actual product size
H47 x W92 x D40cm



NEXT

BRONX / BRONX GREY OTTOMAN
267922/U69947

Warnings

We suggest you retain these instructions for future reference

Keep fittings out of children's reach and keep children well away from construction area

This product should only be used on firm, level ground

Please periodically check all fittings and re-tighten as necessary

Please do not stand or lean back on your furniture

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause cracking of the wood and deterioration of the colour

Keep away from strong heat sources

Do not use this item if components are missing or broken

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk