

Usage Instructions For pre-lit trees

P060715 P060716 P060747 P060748 P060750 P060755 P060787 P060788 P060789

These instructions are for your safety.
Please read them thoroughly before use and retain for future reference.
No tools required for assembly.

Before You Start

- Decide on an appropriate location for your product (see positioning instructions below).
- Remove all plastic bags and dispose of safely out of the reach of children & animals.
- Check the light set before use for any loose or damaged wiring. If in any doubt do not use.

Positioning Instructions

- 1) Please refer to the cable label affixed to the product to establish its positioning suitability.
- 2) Do not position or place near heaters or any other direct sources of heat.

Assemble the base stand.

- 1) Open the stand to form an X shape, making sure that the screw holes line up at the top of the stand.
- 2) Insert the 3 bolts and screw in – **do not fully tighten the screws at this stage. All 7 trees**
- 1) Remove any protective plastic end caps from ends of the tree sections and store in the storage carton.
- 2) Insert the bottom section of the tree into the stand. **One person needs to hold the tree upright whilst the other person tightens the 3 bolts in the stand to hold the tree firmly in place (if applicable).**
- 3) Check that the tree is upright and not leaning. If so, undo the screws & repeat the operation.
- 4) Remove the band that holds the bottom branches together (if applicable). The branches should lower into place. Make sure that all of the branches are lowered completely. Do not use unnecessary force.
- 5) **Do not connect the plug to the power supply at this stage.**
- 6) Place the middle section on top of the bottom section & remove the band that secures the branches (if applicable). Make sure that all of the branches have lowered properly.
- 7) Connect the lead that is marked A, B & C to each of the sections on the tree, these will be A, B & C as well by locating the key or arrow on the male connector and the groove or arrow on the female connector and push both connectors together firmly. To secure the connection tighten the threaded collar securely. Now connect the transformer to the spare connection on the lead. Please note that on bigger trees the lead connectors could be A, B, C & D.
- 8) Place the top section on top of the middle section & remove the band that secures the branches.
- 9) Make sure that all of the branches have lowered properly.
- 10) Remember to keep the bands that were removed from the tree sections in the storage carton (if applicable). They will be reused when storing the tree.
- 11) You may now plug the tree into the power supply and stand back and admire your efforts.
- 12) Some trees are multi-function, if this tree is, there will be a push button on the transformer. Push the button once at a time, to toggle through functions. Functions are listed on the transformer.
- 13) Timer function, press the button twice on the transformer, the green light will come on indicating timer function is on. the lights will stay on for 6 hours and then switch itself OFF and stay on OFF mode for 18 hours.

Operating instructions

Plug transformer into wall socket and switch on.

The transformer has a multi-function control built in, every time you press the button, the function changes. To switch off, turn off at the socket.

Care & Use

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com

On a weekly basis. Please check that the tree is still firmly attached and supported by the base. Tighten the thumb screws if required.

Warnings

- Do not connect this product electrically to another product.
- Never allow any part of the set to meet a source of heat or flame.
- Do not operate this product in its packaging.
- Keep the product well ventilated. **DO NOT** cover the product with cloth, a tree skirt, paper or any other material.
- Take care not to damage the cable or fittings.
- If part of the light set or cable is damaged the product **MUST** be destroyed.
- Always position your tree, cable and extension leads so that they will not be a hazard to the elderly, pets and children.
- Do not position a Christmas tree or decoration near candles or any other sources of heat or naked flame.
- Always switch off decorative lights overnight or if unattended. Do not overload power socket or extension cables.
- This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.
- Please refer to the packaging or product rating label for product class, specifications, and rating.
- **Caution** – Artificial trees have parts which may pose a choking hazard if detached from the branches.
- Locate your tree on a level surface that will not be damaged by the tree or decorations that could detach.
- **DO NOT** pierce the cable when securing in place, bend or stand on the light chain, as this will damage the bulbs or wiring. Do not cover ventilation holes.
- Only operate this product with the transformer supplied.
- Do not connect this item directly to the mains or to anything other than the transformer supplied.
- Please ensure the transformer is plugged into the mains supply indoors and not outdoors or in damp conditions as serious injury could result.

Packing the tree away after use

When you have finished using, please repack as follows to avoid damage and to ensure that your tree can be used again. Dismantle the tree into sections, base, tree and power supply.

- Place all components into the original box using the protective material supplied.
- We recommend that you tether or cello tape the box to avoid any lost items.
- Before you place the tree into storage, **check that you have not forgotten any components.**
- Ensure the storage area is dry; avoid any damp, wet and humid areas.

Electrical ratings

Input 230-240V ~ 50HZ

Each tree operates on 31V AC 5.84W Transformer rating for each tree 31V AC 6W

LED BULB RATING – 3V 0.15A 0.06W



This Symbol indicates that this product is covered by legislation for waste electrical electronic products. When the product has reached the end of its life, please do not dispose of it with general household waste. Consider the environment and take it to a recognised recycling facility.



TRANSFORMER LIGHTSET

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com

Festive Productions Limited
Otters Brook
Ty Coch Way
Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,
Gothenburg, Sweden

01633627300
www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com