Instruction manual for White House and Berry FO tree

P051458-90cm, P051459-120cm, P051460-150cm,

These instructions are for your safety. <u>Please read them thoroughly before use and retain for future reference.</u>

No tools required for assembly.

Before You Start

- Decide on an appropriate location for your product (see positioning instructions below).
- Remove all plastic bags and dispose of safely out of the reach of children & animals.
- Check the light set before use for any loose or damaged wiring. If in any doubt do not use.

Positioning Instructions

1) Please refer to the cable label affixed to the product to establish its positioning suitability.
2) Do not position or place near heaters or any other direct sources of heat.
3) This product is not designed for permanent or long-term use.
4) DO NOT position this product where it may be covered by other items e.g. curtains, nets or bedding or tree skirts.

Tree assembly

<u>POT</u>

Prepare the tree pot. Fig 1 Insert tree into the hole of the base as fig.2.
Connect the output cable from the foot of the tree to the transformer, using the power cable provided as fig.3.
Shape tree by arranging branches to create a full and natural look.
Connect the transformer into mains supply & switch on at the wall socket. The tree will light up, it is a colour changing twinkling effect.

fig.1

fig.2

fig.3

<u>PLASTIC LEGS</u>

Carefully insert the supporting feet into the LED tree base hub along the corresponding groove, as fig 1.
Please ensure that each foot clicks firmly into place. See Fig 2
Connect the output cable from the foot of the tree to the transformer using the power cable provided as fig 3.
Shape tree by arranging branches to create a full and natu
Connect the transformer into mains supply.
The tree will light up; the colour will change and shimmer.

fig.1

fig.2

fig.3

Packing the tree away after use

When you have finished using, please repack as follows to avoid damage and to ensure that your tree can be used again.
Dismantle the tree into sections, base, tree and power supply. Place all components into the original box using the protective material supplied. We recommend that you tether or cello tape the box to avoid any lost items.
Before you place the tree into storage, **check that you have not forgotten any components.**

Festive Productions Limited **01633627300**
Otters Brook **www.festive.co.uk**
Ty Coch Way **AB Alrik Hedlund-412 21,**
Cwmbran, NP44 7EZ **Gothenburg, Sweden** **MADE IN CHINA**

<u>support@festive.co.uk</u> <u>Support-FPL@hedlundgruppen.com</u>

Ensure the storage area is dry; avoid any damp, wet and humid areas

Warning

This tree is intended for **INDOOR USE ONLY.**
IMPORTANT – DO NOT LOOK DIRECTLY INTO THE LED
This product contains **NON- REPLACEABLE LED**. Do not attempt to replace them.
Do not connect this product electrically to another product.
Never allow any part of the set to meet a source of heat or flame.
Do not operate this product in its packaging.
Keep the product well ventilated. **DO NOT** cover the product with cloth, a tree skirt, paper or any other material.
Take care not to damage the cable or fittings.
If part of the light set or cable is damaged the product **MUST** be destroyed.
Always position your tree, cable and extension leads so that they will not be a hazard to the elderly, pets and children.
Do not position a Christmas tree or decoration near candles or any other sources of heat or naked flame.
Always switch off decorative lights overnight or if unattended. Do not overload power socket or extension cables.
This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.
Please refer to the packaging or product rating label for product class, specifications and rating.
Caution – Artificial trees have parts which may pose a choking hazard if detached from the branches.
Locate your tree on a level surface that will not be damaged by the tree or decorations that could detach.
DO NOT pierce the cable when securing in place, bend or stand on the light chain, as this will damage the bulbs or wiring. Do not cover ventilation holes.
Only operate this product with the transformer supplied.
Do not connect this item directly to the mains or to anything other than the transformer supplied.
Please ensure the transformer is plugged into the mains supply indoors and not outdoors or in damp conditions as serious injury could result.

ELECTRICAL RATINGS

P051458	P051459	P051460
This set operates on-12V DC 3.2W	This set operates on-12V DC 3.3W	This set operates on-12V DC 3.4W
Transformer rating-12V DC 3.6W	Transformer rating-12V DC 3.6W	Transformer rating-12V DC 3.6W

LED bulb rating – 3v0.02A0.06w (bulbs are non-replaceable) FOR EACH TREE

This Symbol indicates that this product is covered by legislation for waste electrical electronic products. When the product has reached the end of its life, please do not dispose of it with general household waste. Consider the environment and take it to a recognised recycling facility.

TRANSFORMER LIGHTSET

Festive Productions Limited **01633627300**
Otters Brook **www.festive.co.uk**
Ty Coch Way **AB Alrik Hedlund-412 21,**
Cwmbran, NP44 7EZ **Gothenburg, Sweden** **MADE IN CHINA**

support@festive.co.uk Support-FPL@hedlundgruppen.com

Festive Productions Limited
Otters Brook
Ty Coch Way
Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,
Gothenburg, Sweden

01633627300
www.festive.co.uk

MADE IN CHINA

support@festive.co.uk

Support-FPL@hedlundgruppen.com