BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together. So, let's quickly run through these three steps:

1. COLOUR

Make sure you're happy with the colour No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3. PARTS PAGE


Finally, double check you have all the pieces by referencing the parts page of the instructions.

TIPS FOR RETURNS

Not completely happy with the product? No problem. We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO 🔽

- Check everything is there (the 'parts page' is a handy checklist).
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).






- Leave anything assembled all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly as it may get damaged.



Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.



COMPTON MULTI CHEST

300 449 019, 301 206 013

Assembly instructions

BEFORE YOU START

Warnings

next

Conforms to BSEN4875 & BSEN14749

Do not use chest if any part is broken, torn or missing

We suggest you retain these instructions for future reference.

Gloss finishes are prone to light surface scratches and it is therefore very important that you care for this item correctly.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Assembly to be carried out by a competent adult only.

During assembly children should be kept away from the product due to possible risk injury.

Do not use this item if any components are missing or damaged. This product is suitable for children in the age range of children for which the product is designed (7-12 years).

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

For general cleaning, periodically dust with a soft clean lint-free cloth or a soft micro fibre cloth (ie, e-cloth brand or similar). Please note some cloths (including yellow dusters) contain abrasive fibres which can lightly scratch the surface, if in doubt please try your cloth in an inconspicuous area of the furniture first to assess its suitability. A sample of a suitable cloth for cleaning is included within the hardware pack.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.q. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

Number of people required to assemble

Two persons are required to assemble this item.

Time to assemble



Tools required



Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at


Home Customer Services Next Retail Ltd. Desford Road, Leicester, LE19 4AT

To view our full furniture range please visit www.next.co.uk

next

COMPTON MULTI CHEST 300 449 019, 301 206 013

Assembly instructions



3

NEXE COMPTON MULTI CHEST 300 449 019, 301 206 013

Assembly instructions

Ref	Dimensions	Visual	Qty	Ctn	Ref	Dimensions	Visual	Qty	Ctn
1	101,6 x 5cm		1 2		14	92,1 x 9,8cm		1	2
2	101,6 x 5cm		1	2	15	93,9 x 3,6cm		1	2
3	101,6 x 38,4cm		1	1	16	87,2 x 14cm		1	2
					17	40,4 x 10cm		2	2
4	101,6 x 38,4cm		1	1	18	87,2 x 10cm		2	2
					19	100,7 x 38,4cn	ı .	1	2
5	30 x 14cm		1	2					
6	30 x 14cm		1	2	20	104 x 40,2cm		1	2
7	30 x 10cm		4	1					
8	30 x 10cm		4	1	21	41,5 x 29,9cm		2	2
9	93,3 x 29cm		1	1					
					22	88,3 x 29,9cm		3	2
10	46,5 x 22,5cm		2	2					
11	93,3 x 22,5cm		2	2	23	99,5 x 102cm		1	2
12	98,1 x 31,2cm		2	1					
					24	100,7 x 10cm	v	1	2
13	19,6 x 31,2cm		1	2					


COMPTON MULTI CHEST 300 449 019, 301 206 013


Assembly instructions

next

	es and fittings ied (actual size		o 	10 	20	30	40 	50	60	70	80 	90 	100 ,,,,,	110	120
Ref	Dimensions	Qty													
J23		26	2												
P13	3,5x13mm	2	411	mb											
G22	ø18-5	4			\geqslant										
K1	7x50mm	4													
P10	3x13mm	6	att	ma											
B1	ø8x28	1				0									

Fixtures and fittings supplied (not to scale)






next

COMPTON MULTI CHEST 300 449 019, 301 206 013

Assembly instructions



7

