

Birlea®

Assembly Instructions

**Thank you for
purchasing a
Birlea product**

For a chance to win a Love2Shop voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture. One winner will be selected at random each month.

*Terms & conditions may apply.

Are you happy with your purchase?

Yes: That's great, we would love to hear more from you. Please leave us a review on our Trustpilot link on the QR code here. Your feedback will be greatly appreciated.



No: If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer that you purchased your item from.

Please note that this items build time is around : 30mins



www.birlea.com

ASSEMBLY INSTRUCTIONS

HERRINGFORD 2 DOOR SIDEBORD

IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR HERRINGFORD 2 DOOR SIDEBORD.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ASSEMBLY:

Assembly should be carried out with this item laying flat, not standing upright.

Assemble on a soft, clean surface to prevent damages.

To erase the numbers printed on the pieces, use the rubber inside the accessories pack.

HEALTH & SAFETY:

DO NOT use this product if any parts are missing, damaged or worn.

DO NOT use this product unless all fixings are secured.

Always use on a level, even surface.


CARE & MAINTENANCE:

Periodically check all screws & fixings to ensure they are secure.


DO NOT push this product as this will cause damage.

Always lift this product with two people to repositions.

Keep any sharp objects away from this product.



Birlea®



Birlea®

Birlea Furniture Limited – Registered Office Unit 6a-1, Birlea Way, West Meadow Rise, Castle
Donington, Derbyshire, DE74 2HL, UK

Page 3 of 11

Parts List				Hardware List		
Part	Description	Box	QTY	Part	Description	QTY
1	Side Panel(Left)	1	1	A	Cam Bolt 	10
2	Side Panel(Right)	1	1	B	Cam Lock 	10
3	Top Panel	1	1	C	Wooden Dowel 	10
4	Bottom Panel	1	1	D	Screw 	4
5	Shelf Panel	1	1	E	Adjustable shelf peg 	4
6	Back Rail	1	1	F	Metal Plate 	4
7	Top Support Panel	1	1	G	Hinges 	4
8	Back Panel	1	1	H	Screw 	24
9	Back Panel	1	1	I	Screw 	20
10	Wooden Leg	1	4	J	Plastic Wedge Set 	8
11	Door Panel	1	2	K	Anti-tip metal plate 	2
				L	Allen Key 	1
				M	Handle Set 	2
				N	Screw 	2
				O	Foot Pad 	4

**** You will need a small mallet and a screwdriver for assembly.**

**** Some screws and wooden dowel may remain.**


**** Note : To secure the item to the wall.**

Birlea®


Birlea Furniture Limited – Registered Office Unit 6a-1, Birlea Way, West Meadow Rise, Castle Donington, Derbyshire, DE74 2HL, UK

STEP 1: Pre-assemble the side panels(1),(2) with hardware (A);
 Connect the side panels(1),(2) with back rail(6) and support bar(7) using hardware (B);
DO NOT use any power tools as this may damage the frame and will invalidate any claim.

AX6
BX6



STEP 2: Insert the back panel (8);
DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Birlea®

STEP 3: Attach the hardware (A,K) onto the top panel(3);

DO NOT use any power tools as this may damage the frame and will invalidate any claim.


AX4
KX2



STPE 4: Attach the top panel(3) with the frame using hardware (B,C,N);

DO NOT use any power tools as this may damage the frame and will invalidate any claim.


BX4
CX6
NX2



Birlea®

STEP 5: Insert the back panel (9);


DO NOT use any power tools as this may damage the frame and will invalidate any claim.



STEP 6: Attach the bottom panel (4) with the chest frame using hardware (C,D,L);

DO NOT use any power tools as this may damage the frame and will invalidate any claim.

CX4
DX4
LX1




Birlea®

Birlea Furniture Limited – Registered Office Unit 6a-1, Birlea Way, West Meadow Rise, Castle
Donington, Derbyshire, DE74 2HL, UK

STEP 7: Attach the leg metal plate(F) to the bottom panel(4) using hardware (I).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.


FX4
IX20



STEP 8: Attach the legs(10),and then attach the foot pad(O);

DO NOT use any power tools as this may damage the frame and will invalidate any claim.

OX4




Birlea®

Birlea Furniture Limited – Registered Office Unit 6a-1, Birlea Way, West Meadow Rise, Castle
Donington, Derbyshire, DE74 2HL, UK

STEP 9: Attach the hardware(J) on the back of the chest.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.

JX8




STEP10: Attach the hardware (M,G,H) onto the door panels(11);

DO NOT use any power tools as this may damage the frame and will invalidate any claim.

MX2

GX4

HX8




Birlea®

Birlea Furniture Limited – Registered Office Unit 6a-1, Birlea Way, West Meadow Rise, Castle
Donington, Derbyshire, DE74 2HL, UK

Page 9 of 11


STEP 11: Insert the shelf panel(5) before attaching the door panel (11) using hardware (E).
DO NOT use any power tools as this may damage the frame and will invalidate any claim.

EX4



STEP 12: Attach the door panel (11) to the chest frame using hardware(G,H);
DO NOT use any power tools as this may damage the frame and will invalidate any claim.

HX16




Birlea®

Birlea Furniture Limited – Registered Office Unit 6a-1, Birlea Way, West Meadow Rise, Castle
Donington, Derbyshire, DE74 2HL, UK

Page 10 of 11

STEP 13: Secure the Anti-tip brackets to the wall using suitable hardware.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



PLEASE NOTE that wall fixings are not supplied as different wall materials require different fixing devices. You must use fixings devices suitable for the type of wall you intend to mount product to. Ensure the head of any screw used has a diameter greater than the mounting hole and the fixing is safe and secure before use.



WARNING!

In order to prevent overturning this product must be used with the wall attachment device provided. Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over:-

- Use the wall attachment devices provided
- Never allow children to climb or hang on drawers or doors
- Do not overload the drawer beyond maximum recommended loading
- Place heaviest items in the lower drawers or shelves
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product
- Never open more than one drawer at a time
- Do not hang things from the doors

An attachment device is provided with your product, however you will need to source suitable fixings for your wall type. If in doubt consult a qualified trades person.

Always ensure that the wall to be drilled into is free from hidden electrical wire, water and gas pipe.

Birlea Furniture advise that the wall straps provided should be used to further enhance the safety of this product.

Additional Information:

- For complete product information, images and dimension diagrams please visit the website www.birlea.com
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on instagram.

Birlea®

Birlea Furniture Limited – Registered Office Unit 6a-1, Birlea Way, West Meadow Rise, Castle Donington, Derbyshire, DE74 2HL, UK