


NEXT

NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

Actual product size

H82 x W153.5 x D42.5 cm



Need Help ?

With: Assembly instruction
Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

NOMAD CURVE/WHITE CHEST

V22031/336622

Assembly instructions

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.



Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.


NEXT

NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions


GETTING TO KNOW YOUR PRODUCT



x4



x2





NEXT

NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	14x16.5cm		4	2
2	39x150cm		1	2
3	26.5x67.5cm		1	2
4	26.5x67.5cm		1	2
5	38.5x61.5cm		1	1
6	38.5x61.5cm		1	1
7	38.5x61.5cm		1	1
8	39x150cm		1	2
9	3x70cm		1	2
10	67.5x100.5cm		1	1
11	26.5x67.5cm		1	2
12	26.5x67.5cm		1	2




Ref	Dimensions	Visual	Qty	Ctn
13	25x38cm		1	1
14	25x38cm		1	1
15	14x42cm		2	2
16	14x35cm		2	1
17	14x35cm		2	1
18	6x33cm		6	1
19	34x43cm		2	2
20	16.5x43.5cm		4	2
21	16x35cm		4	1
22	16x35cm		4	1
23	34x44cm		4	2
24	22.5x50cm		1	1

NEXT

NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
25	22.5x50cm		1	1
26	22.5x50cm		1	1
27	22.5x50cm		1	1
28	22.5x50cm		1	1
29	22.5x50cm		1	1


NEXT

NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
V36	Ø6 x 15mm	16	2
Y8	Ø6 x 50mm	14	2
B12	Ø7.5 x 33mm	10	2
B3	Ø15 x 12mm	10	2
U139	Ø4.5 x 15mm	24	2
S42	Ø4 x 15mm	4	1
Y27	Ø6 x 40mm	4	1
U136	Ø4 x 12mm	8	1
P8	Ø4 x 20mm	6	N/A
Y10	Ø6 x 50mm	8	1
S41	Ø4 x 15mm	2	1
D6	Ø8 x 30mm	N/A	1



Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
T4	N/A	2	N/A	
M1	N/A	2	N/A	
M3	N/A	4	N/A	
R	N/A	4	N/A	


Ref	Dimensions	Qty	Spare Qty	Visual
L	N/A	4	N/A	
O1	N/A	2	1	
O2	N/A	8	1	
T39	N/A	2	N/A	

NEXT

NOMAD CURVE/WHITE CHEST


V22031/336622
Assembly instructions

1



M3	N/A	4	
Y10	Ø6 x 50mm	8	
T4	N/A	2	

2




M1	N/A	2	
S42	Ø4 x 15mm	4	


NEXT

NOMAD CURVE/WHITE CHEST


V22031/336622
Assembly instructions


3



B12	Ø7.5 x 33mm	10	  not supplied
-----	-------------	----	---

4






U139	Ø4.5 x 15mm	6	 
R	N/A	2	

NEXT


NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions


5



U139	Ø4.5 x 15mm	6		
L	N/A	2		

6




U139	Ø4.5 x 15mm	6		
L	N/A	2		

NEXT


NOMAD CURVE/WHITE CHEST


V22031/336622
Assembly instructions

7



8




U139	Ø4.5 x 15mm	6		
R	N/A	2		

NEXT

NOMAD CURVE/WHITE CHEST


V22031/336622
Assembly instructions


9



V36	Ø6 x 15mm	16	
T4	N/A	2	

10




Y27	Ø6 x 40mm	4	
T4	N/A	2	


NEXT

NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

11



12




NEXT


NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

13





14




Y8	Ø6 x 50mm	10	
T4	N/A	2	

15



P8	Ø4 x 20mm	4		 not supplied
----	-----------	---	---	---

16




O2	N/A	6		
B3	Ø15 x 12mm	8		 not supplied
O1	N/A	2		

NEXT


NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

17



Y8	Ø6 x 50mm	4	
T4	N/A	2	

18




NEXT

NOMAD CURVE/WHITE CHEST


V22031/336622
Assembly instructions

19



O2	N/A	2	
B3	Ø15 x 12mm	2	  not supplied

20



21

We recommend the use of the wall attachment bracket/strap provided for safety reasons.

Secure the other end of the strap to the wall with an appropriate screw and wall plug for your wall type (not provided).


To hide the strap behind the unit, drill the hole lower than the top of unit.

Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type.

If in doubt please consult a qualified trades person.

Please ensure you secure your product to the wall for your and your family's safety before you use it.




S41	Ø4 x 15mm	2	  not supplied
T39	N/A	2	

NEXT

NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

22




Ensure that it is aligned with
the 15-step screw position.

P8	Ø4 x 20mm	2	 not supplied
----	-----------	---	---

NEXT


NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

23



U136	Ø4 x 12mm	8		 not supplied
------	-----------	---	---	---


24



NEXT


NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

25



x2

26




x2

NEXT


NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

27



x2

28





x2

NEXT


NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

29


Note: Drawer will be permanently assembled once panel ②④ and panel ②⑤ are fitted.



30



SLOTS ALIGNED




x4

NEXT


NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

31




32



NEXT

NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions



33



x4

34

Note: Drawer will be permanently assembled once panel (26) and panel (27) are fitted.






NEXT

NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

35

Note: Drawer will be permanently assembled once panel (28) and panel (29) are fitted.







NEXT

NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

37




38



NEXT

NOMAD CURVE/WHITE CHEST V22031/336622 Assembly instructions

39







NEXT

NOMAD CURVE/WHITE CHEST

V22031/336622
Assembly instructions

40




NEXT

NOMAD CURVE/WHITE CHEST V22031/336622

Actual product size

H82 x W153.5 x D42.5 cm



NEXT

NOMAD CURVE/WHITE CHEST V22031/336622

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk