

# NEXT


## SLATTED LARGE SIDEBOARD

425177

Assembly instructions

### Actual product size

H75x W140x D39cm



## Need Help ?

With: Assembly instruction

Missing or damaged parts

**IMPORTANT - RETAIN FOR FUTURE REFERENCE**

**CALL: 0333 777 8999**

# NEXT

## SLATTED LARGE SIDEBOARD

425177

Assembly instructions

### BEFORE YOU START

#### Number of people required to assemble


Two people are required to assemble this item



**Time to assemble : 30 minutes**



#### Tools required



not supplied

#### Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

#### Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.


# NEXT

## SLATTED LARGE SIDEBORD

425177

Assembly instructions

### GETTING TO KNOW YOUR PRODUCT












# NEXT

## SLATTED LARGE SIDEBOARD



425177

Assembly instructions


Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	39x140cm		1	1
2	36.5x67.5cm		2	2
3	36.5x67.5cm		1	2
4	68x90cm		1	1
5	45.5x68cm		1	2
6	39x140cm		1	1
7	34.5x89.5cm		1	1
8	34.5x44.5cm		1	1
9	46.5x66.5cm		3	2

## NEXT FITTINGS ASSEMBLE INSTRUCTIONS



Push connector into housing to join.



Make sure there is no gap between the panels.

# NEXT


## SLATTED LARGE SIDEBOARD

425177

Assembly instructions

### Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
P3	Ø5 x 16mm	8	1
S41	Ø4 x 16mm	2	1
U139	Ø4.5 x 15mm	12	2
S42	Ø4 x 16mm	4	1



### Fixtures and fittings supplied ( not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
T39	N/A	2	N/A	
C16	N/A	6	N/A	
T38	N/A	10	2	
M1	N/A	1	N/A	
M11	N/A	1	N/A	


# NEXT

## SLATTED LARGE SIDEBORD


425177

Assembly instructions

1



2





# NEXT





## SLATTED LARGE SIDEBOARD


425177

Assembly instructions


3



S42	Ø4 x 16mm	4	  not supplied
M1	N/A	1	
M11	N/A	1	



4






# NEXT

## SLATTED LARGE SIDEBORD



425177

Assembly instructions

5



6



T38

N/A

10



NEXT


SLATTED LARGE SIDEBOARD  
425177  
Assembly instructions

6

We recommend the use of the wall attachment bracket/strap provided for safety reasons.  
Secure the strap to the wall with an appropriate screw and wall plug for your wall type (not provided).  
To hide the strap behind the unit ,drill the hole lower than the top of unit.

Attach the other end of the strap to the underside of the top panel with screw.  
Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires,water and gas pipes.  
NB:Wall fixings are not included-Please source suitable fixing for your wall type.  
If in doubt please consult a qualified trades person.

Please ensure you secure your product to the wall for your and your family's safety before you use it.



T39	N/A	2	
S41	Ø4 x 16mm	2	 


# NEXT

## SLATTED LARGE SIDEBOARD

425177

Assembly instructions


7




P3

Ø5 x 16mm

8



8



U139

Ø4.5 x 15mm

12



C16

N/A

6



X3

# NEXT




## SLATTED LARGE SIDEBORD

425177



Assembly instructions

9

### Install hinge




### Remove hinge






### Adjust Hinge Position




LATERAL



VERTICAL



FRONT- TO-BACK



# NEXT

## SLATTED LARGE SIDEBOARD







425177

Assembly instructions

10

To disassemble:




Step1: Remove the plastic wedges (T38) from the back panels and screws from the rear of the base panel (1);



Step2: Press down the two back panels so they are clear of the top panel slot;

11


Slide the top panel front to unlock, then lift off. Follow the same sequence to remove the other panels;



# NEXT

## SLATTED LARGE SIDEBOARD 425177

**Actual product size**  
H75x W140x D39cm



# NEXT SLATTED LARGE SIDEBOARD

425177

## Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

## Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

## Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

## You can write to us at

Home Customer Services  
Next Retail Ltd.  
Desford Road,  
Leicester,  
LE19 4AT

To view our full furniture range please visit [www.next.co.uk](http://www.next.co.uk)