

next


# CARTER WALL SHELF

422159

Assembly instructions

## Actual product size

H100 x D21x W105 cm



## Need Help ?

With: Assembly instruction  
Missing or damaged parts

**CALL: 0333 777 8999**

**IMPORTANT - RETAIN FOR FUTURE REFERENCE**

## BEFORE YOU START

### Warnings

We suggest you retain these instructions for future reference  
Keep fittings out of children's reach and keep children well away from construction area.  
This product should only be used on firm, level ground  
Please periodically check all fittings and re-tighten as necessary  
Please do not sit or stand on your table  
Avoid exposing the furniture to excessive heat or direct sunlight as this can cause cracking of the wood and deterioration of the colour  
Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

### Do's

We suggest you spend a short time reading through this leaflet before you start.  
When you are ready to start, make sure that you have the right tools and plenty of space.  
Unwrap all packaging materials and place the components on a clean surface to protect it from damage,  
We recommend that the packaging is used to protect the surfaces during assembly.  
Carefully check that you have all the parts before beginning assembly.  
Due to the size of the product we recommend that it is assembled in the room intended for use.  
Ensure the product is fully assembled as illustrated and all fixings fully tightened before use. Check fixings regularly to ensure they remain tight.  
Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

### Don'ts

When moving furniture never drag the pieces across the floor, as this will cause damage to the joints.  
Apply Adhesive substrates for example, sticky tape to the product  
Do not use silicone based furniture polish. Silicone in furniture polishes can break down the lacquer finish.


### Number of people required to assemble

Two people are required to assemble this item

### Time to assemble



### Tools required



supplied      not supplied      not supplied

### Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

### Home service technicians


If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

### You can write to us at




Home Customer Services  
Next Retail Ltd.  
Desford Road,  
Leicester,  
LE19 4AT

To view our full furniture range please visit [www.next.co.uk](http://www.next.co.uk)

GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	1000x208mm		3	1
2	1050x185mm		3	1
3	Drilling Template		1	1

**Fixtures and fittings  
supplied (actual size)**


Ref	Dimensions	Qty	Extra Fittings
A	M6 x 12	18	2



**Fixtures and fittings supplied ( not to scale)**

Ref	Dimensions	Visual	Qty
B	M4		1




1




▲ **DO NOT TIGHTEN SCREWS UNTIL ALL PIECES ARE IN POSITION.**

UNWRAP ALL PACKAGING MATERIALS AND PLACE THE COMPONENTS ON A CLEAN SURFACE TO PROTECT IT FROM DAMAGE.

**Please keep all arrows pointed to the front .**






2




▲ **DO NOT TIGHTEN SCREWS UNTIL ALL PIECES ARE IN POSITION.**

UNWRAP ALL PACKAGING MATERIALS AND PLACE THE COMPONENTS ON A CLEAN SURFACE TO PROTECT IT FROM DAMAGE.

**Please keep all arrows pointed to the front .**





3



▲ **DO NOT TIGHTEN SCREWS UNTIL ALL PIECES ARE IN POSITION.**


UNWRAP ALL PACKAGING MATERIALS AND PLACE THE COMPONENTS ON A CLEAN SURFACE TO PROTECT IT FROM DAMAGE.

**Please keep all arrows pointed to the front .**




4

▲ **CAREFULLY LIFT THE UNIT UPRIGHT**



5



Please use the template provided to mark on the wall the position of the fixing.


NB: Place the template over the product to ensure that the holes match the position of the holes before drilling into your wall.

Use a spirit level to check that the fixings are level.



not supplied

6



Drill six holes.



Move unit into desired position. Secure the unit to the wall with an appropriate screw and wall plug for your wall type(not provided).  
Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included. Please source suitable fixing for your wall type.

If in doubt please consult a qualified trades person.



7



Insert appropriate screws and tighten.

next

# CARTER WALL SHELF

442159

## Actual product size

H100 x D21x W105 cm

