

26-NX 组说-IP

客户名称	26-NX		
组说名称	BRONX OVAL 6 TO 8 EXTENDING DINING TABLE		
印刷规格	(8 张A4双面+ 張A4单面) 组说+ 2 張A4单面包装图		
订单号码	机种名称及颜色	合同号码	数量
	495144 BRONX OVAL 6 TO 8 EXTENDING DINING TABLE #SALVAGE OAK PP+1036-1LTF 45g国产纸 (A260101068)		
以上機種共用此份組說			

备注：

组说五金页标尺刻度要求1：1 印制

附1张A4单面 “开箱说明书” 放在组说最上面.

附1张A4单面"空心板说明说书"在"开箱说明书"之后；

附1张A4单面” TITUS拧紧说明书 “放在组说 “板件页” 和 “五金页” 中间，当 “板件页” 和 “五金页” 合并在一页时， “TITUS拧紧说明书” 放在合并的 “板件页” “五金页” 之后

2023.08.19 组说更新页码页11/12/13，档案更新人：Hannah

BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

1. COLOUR

Make sure you're happy with the colour

No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3. PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

TIPS FOR RETURNS

Not completely happy with the product? No problem.

We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



- Check everything is there (the 'parts page' is a handy checklist).
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T



- Leave anything assembled - all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly - as it may get damaged.


NEXT
HOME

Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.




Care instructions for hollow board & Honeycomb board during you assembling the product

The structures of hollow board & honeycomb board are as below:



The centre of Hollow board & Honeycomb board is hollow. To avoid damaging the hollow board/honeycomb board, we suggest you not step on the hollow board/honeycomb board or not put other part on the board on the end when you assemble the product.



NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

Actual product size

H76x W160x D90cm

H76x W200x D90cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.


Never allow any kind of liquid to remain on your furniture.
Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions









GETTING TO KNOW YOUR PRODUCT




NEXT


BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	63.5x144cm		1	2
2	63.5x144cm		1	2
3	47.5x95.5cm		1	1
4	9.5x47.5cm		2	1
5	9.5x112cm		2	1
6	80x90cm		1	1
7	80x90cm		1	1
8	40x90cm		1	1




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.



Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.




The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)

NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
D6	Ø8 x 30mm	N/A	2
B3	Ø15 x 12mm	N/A	1
B8	Ø8 x 38mm	N/A	1
Y8	Ø6 x 50mm	12	2
V53	Ø6 x 30mm	8	1
W42	Ø8 x 55mm	1	N/A
Z5	Ø4 x 12mm	16	2




Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
T4	N/A	2	N/A	
Q3	N/A	8	1	

NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

1




T4	N/A	2	
W42	Ø8 x 55mm	1	

NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

2



WHEN LOOSENING THE CAM

TURN THE CAM IN A COUNTERCLOCKWISE DIRECTION
UNTIL THE ARROW POINTS IN THE POSITION SHOWN
IN THE DIAGRAMS BELOW



MAXIMUM
LOCK




TURN
TO UNLOCK



UNLOCKED

3




NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE

495144
Assembly instructions

4







T4	N/A	2	
Y8	Ø6 x 50mm	12	

NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

5




Q3	N/A	8	
T4	N/A	2	
V53	Ø6 x 30mm	8	


NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

6



7



Packing Materials

Z5

Ø4 x 12mm


16



NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions


8



NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions


9



NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions


10



NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144 Assembly instructions

11





NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144

Actual product size

H76x W160x D90cm

H76x W200x D90cm



NEXT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE 495144

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at


Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE

REPACK INSTRUCTION 2-1

NEXT




Next Retail Ltd, Desford Road, Leicester, LE19 4AT

BRONX OVAL 6 TO 8 EXTENDING DINING TABLE

REPACK INSTRUCTION 2-2

NEXT



Next Retail Ltd, Desford Road, Leicester, LE19 4AT