

Item No	Colour
500-810-192	White
618-533-190	Charcoal

Need Help?

With: Assembly instructions
Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT RETAIN FOR FUTURE REFERENCE



BEFORE YOU START

IMPORTANT - RETAIN FOR FUTURE REFERENCE - READ CAREFULLY.

WARNINGS

We suggest you retain these instructions for future reference.

Keep fittings out of reach of childen and keep children well away from the construction area.

This product should only be used on firm level ground.

Do not use this bed if any part is broken, torn or missing.

Please periodically check all fittings and re-tighten as necessary.

Please do not jump or stand on your bed avoid exposing the furniture to excessive heat or direct sunlight as this can cause damage to the materials and deterioration of the colour

This Bed may be dismantled for storage or transportation.

Children are likely to play, bounce, jump and climb on beds, therefore the bed should not be placed too close to other furniture or windows, and should be placed either tight to any wall or have a gap of 300mm between the wall and the side of the bed

Do's

We suggest you spend a short time reading through this leaflet before you start

When you are ready to start, make sure that you have the right tools and plenty of space.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Unwrap all parts and place all the components onto a clean surface to protect them from damage

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use. Check fixings regularly to ensure they remain tight.

When moving your assembled bed it is suggested you lift the bed, never drag the bed, please check that the center rails is securely fixed in place

When adjusting the support legs ensure that the foot is set 5-10mm from the floor surface without the mattress in place. When in use the legs will create the required support for the product.

Never allow any kind of liquid to remain on your furniture. Absorption can cause materials to warp or finishes to de-laminate .

Wipe occasionally with a soft damp cloth, (do not use detergents these can damage the surface of the product), then dry with a clean soft cloth.

Don't s

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Do not stand or jump on this product

Number of people required to assemble

Two persons are required to assembled

Time of assemble



30 minutes

Tools required





not su

Missing parts

If you are missing any fixtures and fitting for your products, please contact our customer service team 0333 777 8999 and they will be happy to arrange for replacement to be sent to you free of charge.

How service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the products where possible. If you have a product for more than 28 days we will send and independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home customer services

Next Retail Ltd, Desford Road,


Leicester,

LE19 4AT


To View our full furniture range please visit www.next.co.uk



GETTING TO KNOW YOUR PRODUCT










Fixtures and fittings supplied (actual size)


Ref	Dimensions	Quantity	* Extra Fittings	
Α	8 x 60 mm	8	1	
В	Ø35 x 17 mm	8	1	
			1	
			1	
С	10 x 50 mm	8	1	



Fixtures and fittings supplied (not to scale)

Re	f	Dimensions	Visual	Qty
D)	N/A		1







3 *⊕*) **B** 10x 50 mm B x 8



5 100 cm 110cm 201cm