


NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759

Assembly instructions

Actual product size
H220 x W200 x D63 cm



Need Help ?

With: Assembly instruction
Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item




Time to assemble : 90 minutes



Tools required



not supplied



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.


NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759

Assembly instructions

GETTING TO KNOW YOUR PRODUCT









NEXT









SLOANE WHITE 2M SLIDING WARDROBE

559759

Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	6.5x196.5cm		2	2
2	57 x 196.5cm		1	1
3	57 x 220cm		1	3
4	55 x 204cm		1	3
5	54.5x56.5cm		1	2
6	60x220cm		1	3
7	62.5x 197.5cm		2	3
8	9.5x196.5cm		1	2
9	9.5x196.5cm		1	2
10	6 x 138cm		1	2
11	54.5 x 138cm		1	2

Ref	Dimensions	Visual	Qty	Ctn
12	6 x 196.5cm		1	2
13	62.5x197.5cm		1	3
14	57x196.5cm		1	2
15	2.5x55cm		1	2
16	2.5x136.5cm		1	2
17	11.5x52.5cm		2	1
18	11x40cm		2	1
19	11x40cm		2	1
20	6x38cm		4	1
21	38.5x53cm		1	1
22	38.5x53cm		3	1








NEXT

SLOANE WHITE 2M SLIDING WARDROBE



559759

Assembly instructions


Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
23	16.5x 56cm		2	2
24	8x52.5cm		2	1
25	8x38cm		2	1
26	23.5x52.5cm		2	1
27	23x40cm		2	1
28	23x40cm		2	1
29	28x56cm		2	2
30	101x216cm		1	4
31	5.5x9.5cm		1	1
32	101x216cm		1	5


NEXT FITTINGS ASSEMBLE INSTRUCTIONS




Push connector into housing to join.




Make sure there is no gap between the panels.




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.




Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.



The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
B3	Ø15x 12mm	N/A	2
B8	Ø8x 38mm	N/A	2
D6	Ø8x30mm	N/A	2
D17	Ø10x30mm	4	1
S35	Ø4x14mm	6	1
Y8	Ø6x50mm	2	1
U139	Ø4.5 x 15mm	24	2
V87	Ø6x70mm	5	1
V59	Ø6x35mm	2	1
U134	Ø4x14mm	38	2



Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
N16	N/A	3	N/A	
T38	N/A	18	2	
N30	LED light	2	N/A	
T6	N/A	2	N/A	
L31	N/A	1	N/A	
L32	N/A	1	N/A	
L33	N/A	1	N/A	
L34	N/A	1	N/A	
T13	N/A	1	N/A	
M39	Brush	1	N/A	

Ref	Dimensions	Qty	Spare Qty	Visual
L	N/A	4	N/A	
R	N/A	4	N/A	
N18	N/A	3	N/A	
R35	N/A	1	N/A	
R36	N/A	1	N/A	
R37	N/A	1	N/A	
R38	N/A	1	N/A	
M40	N/A	1	N/A	
M32	Straightener Cover	4	N/A	


NEXT

SLOANE WHITE 2M SLIDING WARDROBE


559759

Assembly instructions

3



4




NEXT

SLOANE WHITE 2M SLIDING WARDROBE


559759

Assembly instructions


5




6



7



8





NEXT

SLOANE WHITE 2M SLIDING WARDROBE



559759


Assembly instructions

9




Bending




S35	Ø4 x 14mm	1		 not supplied
-----	-----------	---	---	---

10

Open the panel (6) by 5 angle.





11






Y8	Ø6 x 50mm	1	
T6	N/A	2	

12




Bending




S35	Ø4 x 14mm	1		 not supplied
-----	-----------	---	---	---


13

Open the panel (6) by 5° angle.




14




Y8	Ø6 x 50mm	1	
T6	N/A	2	

15

Open the panel (6) by 5° angle.



16



Remove the protective film from the magnetic attraction plate.

V87	Ø6 x 70mm	2	
T6	N/A	2	




Open the panel (3) by 5 angle.





19

Before you install the doors, please push all the soft close to the same position as the diagram as below.




Screwdriver (not supplied)



20






Bending



S35	Ø4 x 14mm	1		 not supplied
-----	-----------	---	---	---

21

Note:
Ladder Required



V87	Ø6 x 70mm	3	
T6	N/A	2	


NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759


Assembly instructions

22



$$A = B$$

23



T38

N/A

18




24

We recommend the use of the wall attachment bracket/strap provided for safety reasons. Move unit into desired position. Secure the 3X"L" metal brackets to the wall with an appropriate screw and wall plug for your wall type (not provided).

Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type.

If in doubt please consult a qualified trades person.










N18

N/A

3




25




U134	Ø4x14mm	2		 not supplied
M40	N/A	1		

26

Set the LED lights to automatic sensing mode follow the last page.



Place the lamp tube position as show in the picture.



N30	LED light	2	
-----	-----------	---	--


NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759

Assembly instructions


27



SLOTS ALIGNED

X2

28



SLOTS ALIGNED

X2


NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759



Assembly instructions

29





X2

30




31


Note: Drawer will be permanently assembled once panel (23) is fitted.




32



Fabric



Choose two Jewelry sections from the 2 options below according to your need.




NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759


Assembly instructions

33



X2

34



X2


NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759


Assembly instructions

35




X2

36




X2

Note: Drawer will be permanently assembled once panel (29) is fitted.



X2


37




38

1.Pull runners out.

2.Pull plastic tabs inwards.



step:1.pull out runner




step:2.unlock

39


3. Place drawers on runner making sure hooks at back of runners.

4. Locate pin under drawer.


5. Lock drawer in position.




step:3.Locate




step:4.All the way



step:6.Locate adjustment pin in hole




step:5.Pull runner forward




step:7.Lock

40


6. Adjust drawer height if needed.




OK



Need to adjust as below



Anti-clockwise is up




Clockwise is down


NEXT

SLOANE WHITE 2M SLIDING WARDROBE
559759
Assembly instructions

41





U134	Ø4x14mm	18					
L31	N/A	1		L32	N/A	1	
L33	N/A	1		L34	N/A	1	



43



If the door panel is bent, adjust the straightener as shown in the picture.



T13	N/A	1	
M32	Straightener Cover	2	

44


If the door panel is bent, adjust the straightener as shown in the picture.



T13	N/A	1	
M32	Straightener Cover	2	

45

Please remove the adhesive from the brush and start applying it 15mm away from the edge.



M39	Brush	1	
-----	-------	---	---

46

Install from the middle !

Note:
Ladder Required

Ladder

750mm



Place the slider onto the correct runner at the front.


47



Push the door into the right runner.

48

After the door panel is installed, if you find that the door panel is not properly aligned left and right, you can make fine adjustments by adjusting the "+" and "-" signs to make the door panel perfectly coincide with the carcass.




T6

N/A

2





49



50


Install from the middle !

Note:
Ladder Required



Place the slider onto the correct runner at the back.


51



Push the door into the right runner.

52

After the door panel is installed, if you find that the door panel is not properly aligned left and right, you can make fine adjustments by adjusting the "+" and "-" signs to make the door panel perfectly coincide with the carcass.



T6


N/A

2





53

After the door panel is installed, if you find that the inner and outer door gap is too narrow, please adjust the "+" and "-" signs to prevent panel collision follow the step 52.






After hanging it up, if you find that it is deformed, please adjust it according to the following steps.



Clockwise
To avoid bending



Anti-clockwise
To avoid cupping



NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759

Assembly instructions


To disassemble:

Step1: Loosen the hook of the bracket above the door panel as shown in the picture.

As shown in the picture, push the door panel to the middle.


Turn the screw in the '-/anti-clockwise' direction to lose the hook.

Notice: when re-installing the door panel, please tighten the screw in the '+ clockwise' direction first to tighten the hook.



Step2: Remove the door from the slide rail as below.

Step3: Remove the inner panel in the same way.



pull out the bottom.
Raise up the door till it removed.






NEXT

SLOANE WHITE 2M SLIDING WARDROBE

559759

Assembly instructions





Step4: Remove the plastic wedge (T38) from the back plates, and remove the screws from the rear of the panel(7) and the panel(8) and the panel(9) and the panel(13);



Step5: Press down the back panel so it is clear of the top panel slot;

Step6: Remove the screws from the panel(12);


Step7: Slide the top panel front to unlock, then lift off. Follow the same sequence to remove the other panels.



NEXT

SLOANE WHITE 2M SLIDING WARDROBE 559759

Actual product size
H220 x W200 x D63 cm



NEXT

SLOANE WHITE 2M SLIDING WARDROBE 559759

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Name and Address:NEXT RETAIL LTD.LE19 4AT

Identification and model Number:AB9717 SLOANE MIRROR 2M SLIDING WARDROBE

Date of Manufacture:

Contract number:

Nominal thickness of Glass:3mm,Mirror

Country of Origin:China

If a glass component is chipped or broken replace with glass of the type described on this label.Consult with the retailer with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number,batch number and date of manufacture.

Missing parts

If you are missing any fixtures and fittings for your product.
Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement,refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk

NEXT

SLOANE WHITE 2M SLIDING WARDROBE 559759

Contents and specification:

- 1x sensor LED wardrobe which doesn't need to be plugged in to function.
- This product contains 1x battery which are non-replaceable.
- Rechargeable by USB port 0.8m USB charging cable included (USB plug is needed to charge but not included)
- Integrated LED lamp/strip - bulbs not required.
- Average run time: 6 hours (keep lighting)
- Wattage: 1.63W
- Light output: 93.52 lumens
- Colour temperature: 3000K/4000K/6000K
- The light will only go through the 3 stage touch when in contact with the switch on the top of the LED
- This product has a charging indicator light. When charging the light will show red. Once charging is complete, the light will change to white. In order to maintain the longevity of the product, please do not overcharge or leave on the charge for 24 hours.
- Constant On Mode: The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
- Night Sensing Mode: The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. The light will automatically turn off when human left the sensing range for after 25 seconds. The light will keep lighting if human stay in the sensing range.
- The sensing range of the light is 120° from the center point of the probe, within a 3 meter area. However, improper installation or obstructions near the sensing probe may affect the sensing effect.
- Ensure that all packaging is disposed of carefully and responsibly.
- Keep all plastic wrapping materials away from children to avoid danger of suffocation

NEXT

MODEL NUMBER:AB9717

BULB TYPE:NOT REQUIRED

VOLTAGE:2.6-5V.MAX 388 MA.1.63W

BATCH NO:03/2025



**UK
CA**



**LE19 4AT
D02 ED70**

Manual -LED


Please fully charge the battery before using it for the first time.

Description of Modes and Their Functions


 Constant On Mode	The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
 Night Sensing Mode	- The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. - The light will automatically turn off when human left the sensing range for after 25 seconds. - The light will keep on if human stay in the sensing range.

Instructions for buttons

Push button switch	- Press button: Cycle through the light colors. (ON mode) - Holding button: Adjusts the brightness. (ON mode)
Toggle switch	- AUTO: Night Sensing mode. - ON: Constant ON mode. - OFF: Turn off the lamps.



Sensing range and its precautions



- The sensing range of the light is 120° from the center point of the probe, within a 3 meter area.
- However, improper installation or obstructions near the sensing probe may affect the sensing effect.

Charging instructions

- Charging voltage: DC5V/1A
- Charging port: Type-C
- Charging indication: Red light on- charging / Green light on- fully charged

Precautions

- Please fully charge the battery before using it for the first time.
- Please do not use charging devices with output voltage greater than 5V/1A to charge the lamp.
- Please use a safety-certified mobile phone charging adapter to charge the light.
- Do not use while charging.
- Keep away from fire. Do not use this light in a damp or high-temperature environment. Do not allow children to use or come into contact with this light. Do not attempt to repair or replace any parts by yourself.

If the contents of the manual can not solve the problem for you, please contact the merchant in time, thank you for your support and trust.