


next

HAMPTON 1.5M WARDROBE

Assembly instructions

Actual product size

H202.5 X W150 X D62cm



606696 HAMPTON 15M CHALK
643157 HAMPTON 15M STONE

IMPORTANT - RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly instructions
Missing or damaged parts

CALL: 0333 777 8999

BEFORE YOU START

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from the construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect them from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.


Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster.

PRODUCT SUPPLIED WITH WALL FIXING STRAPS


Number of people required to assemble

Two persons are required to assemble this item.

Time to assemble



Tools required



not supplied

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians


If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd,
Desford Road,
Leicester,
LE19 4AT













To View our full furniture range please visit www.next.co.uk

GETTING TO KNOW YOUR PRODUCT




GETTING TO KNOW YOUR PRODUCT

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn	Ref	Dimensions	Visual	Qty	Ctn
1	150x62cm		1	3	8	189.1x58 cm		1	2
2	69.6x51cm		2	3	9	189.1x52.2cm		1	2
3	191x96cm		2	2	10	185.4x70cm		1	4
4	69.3 x4cm		2	3	11	185.4x70cm		1	4
5	69.6x20cm		2	3	12	150x60cm		1	1
6	69.4x29cm		2	3					
7	189.1x58 cm		1	2					

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty
A	7 x 16mm	8
B	16 x 14mm	20
C	3 x 16mm	20
D	3 x 17mm	4
H	30 x 24mm	1
I	4 x 30mm	1
K	2 x 50mm	1



Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Visual	Qty
E	N/A		2
F			4
G			2
J	N/A		4


1

WHEN TIGHTENING THE CAM


TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITIONS SHOWN IN THE DIAGRAMS BELOW



START




MINIMUM
LOCK





MAXIMUM
LOCK


PUSH THE TWO PANELS TOGETHER ALLOWING THE DOWEL TO ALIGN WITH THE HOLE




TURN THE CAM IN A CLOCKWISE DIRECTION




2




3




4




5






6




7




8





9




10





11






12





13





14






15



16




17




18

ALIGNMENT OF WARDROBE:



1. Move wardrobe to final position
2. Adjust gaps between door and side to be even top to bottom and on both/all doors (use door adjustment drawings)
3. Check door top & bottom are aligned with the frame. If not add wedges under front and rear legs (on side that bottom edge of doorgap is to small) until correct, then snap off extra part of wedges.



INCORRECT




CORRECT




Set gap at top & bottom of doors to be equal (use door adjustment diagram)

Set gap at top & bottom of doors to be equal (use door adjustment diagram)









J x 4

N/A



19



Actual product size
H202.5 X W150 X D62cm

