

BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

1. COLOUR

Make sure you're happy with the colour
No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3. PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

TIPS FOR RETURNS

Not completely happy with the product? No problem.
We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



- Check everything is there (the 'parts page' is a handy checklist).
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T



- Leave anything assembled - all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly – as it may get damaged.

next
HOME

Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.

next

PORTIA DRESSING TABLE

644481

Assembly instructions

Actual product size

H80.5xW100xD40.5cm



Need Help?

With: Assembly instructions
Missing or damaged parts

IMPORTANT- RETAIN FOR FUTURE REFERENCE

CALL:0333 777 8999

BEFORE YOU START

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from the construction area.

This product should only be used on firm, level ground.

For self-assembled products, please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

For self-assembled products, we recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of the product we recommend that it is unpacked in the room intended for use.

If the glass is chipped or broken, stop using the product and consult the supplier.

When cleaning glass panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these substances scratch glass panel.

The glass used in this product is toughened and complies with BS EN 12150, BS EN 12521, BS EN 4875 and BS EN 14749.

The glass used in this product is toughened and complies with BS EN 12150-1:2000, clause 8.3 & 8.4

Don'ts

Do not drag or pull your furniture

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

PRODUCT SUPPLIED WITH WALL FIXING STRAPS

Don'ts(Continue)

Do not place very hot or very cold items on the glass surface, unless adequately thick table mats or coasters are used to prevent such items from coming into contact with the glass.

Do not use glass as a chopping surface. Do not strike the glass with hard or pointed items.

Number of people required to assemble

2 persons to assembly

Time to Assemble



15 minutes

Tools required



not supplied



not supplied

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians


If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at





Home Customer services
Next Retail Ltd,
Desford Road
Leicester
LE19 4AT

To view our full furniture range please visit
www.next.co.uk

GETTING TO KNOW YOUR PRODUCT









Component supplied

Ref	Dimensions	visual	Qty
1	100x40.5x16cm		1
2	67x38x20cm		2
3	79x1.9x1.9cm		1
4	78x1.5x1.5cm		1


Fixture and Fittings supplied(actual size)

mm 10 20 30 40 50 60 70 80 90 100


REF	DIMENSIONS	QTY	Spare Part *	
A	65X25MM	1	0	
B	12X25MM	8	1	
C	16X1MM	8	1	
D	13X2MM	8	1	
E	12X14MM	8	1	
F	65X23MM	1	0	

* Just to let you know we have included a small quantity of fixings in case of mishap, so don't worry if you've got a few left when you've finished.

1



2



65X25MM Ax1	12X25MM Bx4	16X1MM Cx4	13X2MM Dx4

next

PORTIA DRESSING TABLE


644481

Assembly instructions

3



4




65X25MM Ax1	12X25MM Bx4	16X1MM Cx4	13X2MM Dx4	12X14MM Ex8	65X23MM Fx1

5



If your floor is not level, the feet on the unit should be adjusted to prevent it from rocking. Place the unit in its final position and unscrew any feet that are not in full contact with the floor. The unit should then be checked for level in left-right and front-back directions with a spirit level and further adjustments made as required.

NOTE: If the unit is not levelled, the drawers may not function correctly.




6


To remove drawers:



1





2




3

7


To replace drawers:




1




2




3




4






6




5




8




Once the item is in its final position, correct the fit of the drawers by sliding the adjusters under the drawer box:
Press down the slider, moving it outward will raise that side of the drawer, and moving it inward will lower it.



1




2



9

We recommend the use of the wall strap provided for safety reasons. Wall fixing are not included please source suitable fixing for your wall type. If in doubt, please consult a qualified tradesperson. **WARNING:** Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



next

PORTIA DRESSING TABLE

644481

Assembly instructions

Actual product size

H80.5xW100xD40.5cm

