BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

1.COLOUR

Make sure you're happy with the colour No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3.PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

TIPS FOR RETURNS

Not completely happy with the product? No problem. We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



- Check everything is there (the 'parts page' is a handy checklist).heck everything is the
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T




- Leave anything assembled all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly as it may get damaged.



71 03 66

Assembly instructions



IMPORTANT - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

Missing or damaged parts

CALL: 0333 777 8999



Assembly instructions

BEFORE YOU START

Warnings

Conforms to BSEN4875 & BSEN14749

Do not use chest if any part is broken, torn or missing We suggest you retain these instructions for future reference. Gloss finishes are prone to light surface scratches and it is therefore very important that you care for this item correctly. Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary. Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage. Assembly to be carried out by a competent adult only.

During assembly children should be kept away from the product due to possible risk injury.

Do not use this item if any components are missing or damaged. This product is suitable for children in the age range of children for which the product is designed (7-12 years).

Number of people required to assemble

Two persons are required to assemble this item.

Time to assemble





Tools required



Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

For general cleaning, periodically dust with a soft clean lint-free cloth or a soft micro fibre cloth (ie, e-cloth brand or similar). Please note some cloths (including yellow dusters) contain abrasive fibres which can lightly scratch the surface, if in doubt please try your cloth in an inconspicuous area of the furniture first to assess its suitability. A sample of a suitable cloth for cleaning is included within the hardware pack.

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services Next Retail Ltd. Leicester, LE19 4AT

To view our full furniture range please visit www.next.co.uk

Don'ts


Do not drag or pull your furniture.
Do not rub or scrub the surface when cleaning.
Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate. Do not place hot items (e.q. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

next

Phoenix Triple Robe

71 03 66





Assembly instructions

Components supplied. Please use this guide if you reguire replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	175,5 x 55,3cm		1	3
2	175,5 x 55,3cm		1	3
3	40 x 14cm		2	1
4	40 x 14cm		2	1
5	38,8 x 26,3cm		2	1
6	176,6 x 40cm		1	2
7	176,6 x 40cm		1	2
8	175,5 x 55,3cm		1	3
9	175,5 x 1,7cm		1	3

Ref	Dimensions	Visual	Qty	Ctn
nei	Difficusions	Visuai	Qty	Ctil
10	37,9 x 55,2cm		3	1
11	37,9 x 53cm		2	2
12	37,9 x 10cm		2	1
13	33 x 14cm		2	1
14	119,9 x 55,3cm		1	1
15	119,9 x 57cm		1	1
16	34,1 x 39,9cm		2	1
17	145,2 x 39cm		2	2
18	51,4 x 38,7cm		1	2
19	124,9 x 38,7cm		1	2
20	31,1 x 39cm		2	2
21	37,1 x 3cm		2	1

ixture Suppli	es and fittings ed (actual size))
Ref	Dimensions	
J23		29
P13	3,5x13	2
G22	ø5	4
B1	ø8x28	52
T11		48
M11	ø15x12	32
M10	ø15x10	16
W1	5x16	8
P14	3,5x30	12
F7		4
S3	3,5x13	4
P17	4x20	6
S9	4x16	12



Assembly instructions

Fixtures and fittings supplied (not to scale)


Ref	Dimensions	Qty	Visual
U49	160	2	
U49	500	2	
J44		2	
X5		6	
F10	ø45x15	6	




71 03 66

Assembly instructions


TITUS TIGHTENING INSTRUCTIONS




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.




Make sure there is no gap between the panels.





Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.



The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)











next


Phoenix Triple Robe












next

Phoenix Triple Robe

71 03 66






Assembly instructions

17

Installation shall be carried out exactly according to the manufacturer's instructions – otherwise a safety risk can occur if incorrectly installed. WARNING in order to prevent overturning this product must be used the wall attachment devices provided (J44, P13, G22). Wall fixings are not included, please source suitable fixings for your wall type. If in doubt, please consult a qualified trades person. WARNING: Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



P13	3,5x13mm	2	«tttttt()
G22	ø5	4	
	not supplied	2	
J44		2	



