

NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE



764628

Assembly instructions

Actual product size

H75x W160x D93cm

H75x W200x D93cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628

Assembly instructions

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.


Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628
Assembly instructions

GETTING TO KNOW YOUR PRODUCT










NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628
Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	37x71cm		2	2
2	37x71cm		2	2
3	1.5x8cm		4	1
4	16x50.5cm		4	1
5	8x139cm		2	2
6	80x93cm		1	1
7	80x93cm		1	1
8	40x89cm		1	1

NEXT


TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628

Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
B24	Ø8 x 40mm	8	N/A
Y23	Ø6 x 20mm	24	2
Z7	Ø4 x 16mm	24	2
B25	Ø35 x 17mm	8	N/A
U87	Ø4 x 12mm	8	1
D17	Ø10 x 30mm	N/A	1



Fixtures and fittings supplied (not to scale)


Ref	Dimensions	Qty	Spare Qty	Visual
T1	N/A	2	N/A	
T7	N/A	1	N/A	
F16	N/A	4	N/A	

NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE


764628
Assembly instructions

1




x2


2



X



✓



x2


T1	N/A	2	
Y23	Ø6 x 20mm	12	

NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE


764628
Assembly instructions

3




x2


4



X



✓



x2


T1	N/A	2	
Y23	Ø6 x 20mm	12	

NEXT



TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628
Assembly instructions


5






x2

U87	Ø4 x 12mm	8	
F16	N/A	4	

6



x2

B24	Ø8 x 40mm	8	   not supplied
-----	-----------	---	---


NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628

Assembly instructions

7




B25

Ø35 x 17mm

8



8




NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE


764628

Assembly instructions

9



10



T7

N/A

1




NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE



764628

Assembly instructions

11




The wheel need to get stuck in the rail.



Z7

Ø4 x 16mm

16






NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628

Assembly instructions

12



Z7

Ø4 x 16mm

8



not supplied


NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628

Assembly instructions

13




NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE

764628

Assembly instructions

14



When extending the middle top panel:
Step 1: Unlock
Step 2: Pull to the end
Step 3: Push back and lock



NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE


764628

Assembly instructions

15



Step 1



Step 2

When closed the middle top panel:



Step 1: Unlock

Step 2: Pull out slowly to have a gap

Step 3: Push back when hear the sound
of the mechanism unlocking

Step 4: Push back

Step 5: Lock




NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE


764628

Assembly instructions


16





Step 3



Step 4



Step 5





NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE 764628

Actual product size

H75x W160x D93cm

H75x W200x D93cm



NEXT

TAYTUM 6 TO 8 EXTENDING DINING TABLE 764628

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk