

CHARLES
BENTLEY

EST. 1860



Acacia Bistro Set

INSTRUCTION MANUAL

ASSEMBLY MANUAL




Please read and understand the following instructions.


We recommend retaining these instructions for future use.

Failure to follow the instructions, improper installation, adjustment, alteration or lack of maintenance can cause injury or property damage.

Do not allow children or pets near the assembly area.


PARTS - TABLE

Parts		
CODE	PART	QTY
A		1
B		1
C		1


Fixings & Tools		
CODE	PART	QTY
AA	 M6 x 20mm	16
BB	 M6 x 55mm	1
CC		16
DD	 M6 x 20mm	8
EE		4
FF		1

ASSEMBLY INSTRUCTIONS - TABLE


Step 1



Step 2







Step 3



PARTS - CHAIR

Parts

CODE	PART	QTY
A	 LEFT SIDE	1
B	 RIGHT SIDE	1
C		1
D		1


CODE	PART	QTY
E		1
F		1
G		1

Fixings & Tools


CODE	PART	QTY
H	 M6 x 65mm	4
I	 M8 x 60mm	4
J	 M7 x 65mm	2
K		2
M		4
N		8
P	 M6 x 40mm	1
Q		2
R		1

ASSEMBLY INSTRUCTIONS - CHAIR


Step 1




Step 2




Step 3




Step 4



Step 5



Step 6



CARE INSTRUCTIONS

WARNINGS AND ADVICE

- For domestic and outdoor use only.
- Do not exceed the maximum weight.
- When you are ready to begin assembly, make sure you have the right tools, plenty of space, and carefully check that you have all the parts required.
- Unwrap all packaging material and place the components on a clean surface. We recommend using the packaging to protect the surfaces during assembly.
- Periodically check all fittings and retighten as necessary. We recommend retaining the assembly tools, you may need them in future to re-tighten the bolts, or to dismantle the furniture.
- This product should only be used on a firm, level ground.
- Do not stand or climb on the product and supervise young children whilst in use.

STORAGE

Winter Storage

During the colder months or periods of heavy rain, it's best to store your furniture in a dry, sheltered area whenever possible. If outdoor storage is necessary, use a durable, weatherproof cover. Avoid leaving the cover on continuously for long periods, as trapped moisture and lack of airflow can harm the furniture's material and finish. To prevent this, periodically remove the cover and allow the furniture to breathe. This simple step helps maintain its appearance and longevity throughout the winter.

Summer Storage

To keep your furniture in top condition during the warmer months, protect it from prolonged sun exposure, extreme heat, and sudden weather changes. Use a waterproof and UV-resistant cover that fits snugly and securely over the furniture. This helps prevent fading, warping, and other sun-related damage.

WOOD CLEANING & MAINTENANCE

- **Cleaning** Regular cleaning is crucial to removing dirt, dust, and other contaminants that can accumulate on the furniture's surface. Use a mild dish soap and warm water solution, applying it with a soft cloth or sponge. Avoid using abrasive cleaners or detergents, as they can damage the coating.
- **Drying** After cleaning, it's essential to dry the furniture thoroughly. Use a clean, dry cloth to wipe down the surface, paying attention to areas where water collects.
- **Wood Protection** The wood has an oiled finish; a regular re-application of furniture oil must be applied to maintain good condition. The frequency will depend on weather conditions but should be done at least once a year. After being outside for some months, small dark spots may appear which is natural. You can use fine abrasive paper to sand off the spots and reapply furniture oil.
- **Moving the Product** When moving the product, never drag it across the floor, as this may cause damage to the joints and the floor.

FABRIC CARE

- To surface clean the fabric, wipe with mild soap and water, dry thoroughly.
- Wipe up any spills immediately and always refer to the care label sewn to the cushion.
- Do not use bleach, acid, solvents or abrasive cleaners on this item.
- Do not scrape the sofa with any sharp tool.

Washing instructions

The cushion covers are removable, we advise following the below instructions to wash them:

- Hand wash, if you wish to machine wash use a gentle cycle
- Wash on a low temperature
- Do not tumble dry
- Air dry, do not place on a radiator

NB: Please be aware repeated washing of the covers will deplete the fire retardancy of the fabric by washing away the protective coating.

CHARLES
BENTLEY

EST. 1860

Treat your home to something special!

Bring comfort, style and relaxation to your home. From elegant outdoor dining to beautiful lounge sets and casual everyday furniture – we help you create your dream indoor & outdoor space.

For inspirational, elegant, and stylish home and garden furniture ideas **visit [CharlesBentley.com](https://www.charlesbentley.com) today!**



GLGFACBIST26

[charlesbentley.com](https://www.charlesbentley.com)

Charles Bentley & Son Ltd. Loughborough, LE11 5TP, UK

For EU Enquiries Contact: Authorised Rep Compliance Ltd., Ground Floor, 71 Lower Baggot Street, Dublin, D02 P593, Ireland
www.authorisedrepcompliance.com