

next


## FLYNN 6DRW WDE

884292 / 902605 / 949476

Assembly instructions

### Actual product size

H95 x W117.4 x D39.2cm



## Need Help?

With: Assembly instructions  
Missing or damaged parts

**IMPORTANT— RETAIN FOR FUTURE REFERENCE**

**CALL: 0333 777 8999**

## BEFORE YOU START

**\*\*IMPORTANT\*\*** : Assembly to be carried out by a competent adult only - Do not use this item if any components are missing or damaged

### Warnings

## IMPORTANT: RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

Installation shall be carried out exactly according to the manufacturers instructions otherwise a safety risk can occur if incorrectly installed.

**WARNING** In order to prevent overturning this unit must be used with the wall attachment device provided.

Keep fittings out of children's reach and keep children well away from the construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home.

Recommended Child age for this furniture is age 3-12 years.

5 kg max load per slim drawer + 10.5 kgs max load for wide drawer.

### Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

### PRODUCT SUPPLIED WITH WALL FIXING STRAP

#### Number of people required to assemble

Two person is required to assemble this item.

#### Time to assemble




1 hour

#### Tools required



not supplied



not supplied

#### Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster.

#### Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

#### Home service technicians


If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

#### You can write to us at











Home Customer Services  
Next Retail Ltd,  
Desford Road,  
Leicester,  
LE19 4AT











To View our full furniture range please visit [www.next.co.uk](http://www.next.co.uk)

## GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	93 x 37.4cm		1	.
2	93 x 37.4cm		1	.
3	115.3 x 90cm		1	.
4	113.8 x 6.5cm		2	.
5	74.8 x 4cm		1	.
6	117.4 x 39.2cm		1	.
7	74.8 x 6.5cm		1	.
8	35.8 x 4cm		1	.
9	35.8 x 6.5cm		1	.
10	86.4 x 36cm		1	.

Ref	Dimensions	Visual	Qty	Ctn
11	20 x 1.87cm		3	1
12	71 x 34.9cm		3	1
13	77.7 x 28.5cm		3	1
14	35 x 16cm		6	1
15	35 x 16cm		6	1
16	69.8 x 16cm		3	1
17	30.8 x 16cm		3	1
18	32 x 34.9cm		3	1
19	38.7 x 28.5cm		3	1
20	15 x 1.87cm		3	1

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Quantity
A	8 x 36mm	38
B	15 x 12.5mm	14
C	15 x 10.5mm	24
D	3.5 x 15mm	42
E	4 x 30mm	36
F	8 x 30mm	48
G	6 x 11mm	24
H	3.5 x 25mm	4
L	Ø10 x 1.5mm	12
M	Ø5 x 15mm	2




Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Visual	Qty
N	N/A		6
O	N/A		12


Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Visual	Qty
Q	N/A		1
R	N/A		6
S	N/A		6


## TITUS TIGHTENING INSTRUCTIONS




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.





Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.




The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)



1




2




3





**WHEN FITTING CAMS**  
ENSURE STARTING POSITION IS CORRECT  
BEFORE YOU INSERT CONNECTING CAM-PILLAR



4





5









6




7






8





9



10






11

**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**


TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE  
ARROW POINTS IN THE POSITIONS SHOWN IN THE  
DIAGRAMS BELOW




START



CORRECT  
LOCK



12



13

**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**


TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE  
ARROW POINTS IN THE POSITIONS SHOWN IN THE  
DIAGRAMS BELOW



START



CORRECT  
LOCK




14

**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**


TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE  
ARROW POINTS IN THE POSITIONS SHOWN IN THE  
DIAGRAMS BELOW





START



CORRECT  
LOCK



15




16

**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**



TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITIONS SHOWN IN THE DIAGRAMS BELOW




START




CORRECT LOCK



17





18








19



20




21



## Wall fixing - if in doubt seek professional advice


### Wood

If fixing to wood make sure that it isn't chipboard as screws can easily pull away from the core structure





### Brick or Masonry

Use an appropriate wall plug provided you are sure your wall is sound.



### Cavity wall



Special toggle wall plugs are needed. Seek expert advice.




STEP 33



22





23





24

**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**  
TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE  
ARROW POINTS IN THE POSITIONS SHOWN IN THE  
DIAGRAMS BELOW





25


**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**  
TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE  
ARROW POINTS IN THE POSITIONS SHOWN IN THE  
DIAGRAMS BELOW



26



27




**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**


TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE  
ARROW POINTS IN THE POSITIONS SHOWN IN THE  
DIAGRAMS BELOW




START




CORRECT  
LOCK






28





29




Important:  
The cabinet MUST  
be 'square' when the  
back is attached.





30



31




32



## Wall fixing - if in doubt seek professional advice


### Wood

If fixing to wood make sure that it isn't chipboard as screws can easily pull away from the core structure





### Brick or Masonry

Use an appropriate wall plug provided you are sure your wall is sound.




### Cavity wall

Special toggle wall plugs are needed. Seek expert advice.







33




x6






34



x6




35




x6


36




x3



x3



37




x3

**DON'T STOP UNTIL THE 2 O'CLOCK LOCK**


TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITIONS SHOWN IN THE DIAGRAMS BELOW




START




CORRECT LOCK




x3




38




x3




x3




39




x3



40



x3




x3

Ø10 x 1.5mm


L x 12




41




x3



x3



42





**Actual product size**

H95 x W117.4 x D39.2cm

