CHARLES BENTLEY

Charles Bentley
Pre-Lit Faux Christmas Tree

Assembly Instructions

SKU: HMXTREEPL



Please Read All Instructions Thoroughly Before Starting Assembly

Contents

This product includes:

1x Pre-lit Christmas tree
1x Metal stand
1x Eye bolt
3x Screws


Assembly Instructions

WARNING! Adult assembly required. Follow the instructions below to set up your tree. Every carton should contain a top, middle, and bottom section. Remove all packaging before beginning.

1. Before you start to assemble your tree, choose an appropriate location – avoid moving the tree after it is assembled.

2. Assemble the tree stand and place on a level surface (see figure 1).

Figure 1




3. Insert the pole with tapered end of the tree bottom into the metal stand and tighten the 3 screws on the stand.

4. Insert the middle section of the tree into the bottom section, and push down into position.

5. Insert the top section of the tree into the middle section, and push down into position (see figure 2).

Figure 2



6. Connecting the strings with power: Please find the power supply cord on the bottom section. If there is no power supplier cord, follow the following method: Carefully connect the plug to the end-connector by A to A, and B to B.

7. Gently lower all main branches on the 3 tree sections (see figure 3). Take care not to place unnecessary pressure on the brackets when assembling. The branches on your tree can be adjusted to give the desired amount of fullness. For best results, straighten and separate all branch tips, then bend them slightly upward (see figure 4).

Figure 3




Figure 4



8. Plug tree lights into a power outlet. Your tree is now ready to decorate!

Product Safety

Please take time to read these instructions thoroughly and follow each step carefully for safe and easy operation. Keep this manual for future reference.

Warnings:

- For domestic indoor use only.
- Please check the assembly instructions carefully to familiarize yourself with the correct procedure.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.
- Check that you have all the component parts against the list provided.
- Keep fittings out of children's reach and keep children and pets well away from construction area.
- Take care when lifting heavy items and use the correct lifting techniques required for safe lifting.
- Keep away from heat: make sure your tree is at least three feet away from any heat source, like an air duct, fireplace or space heater.
- If lights are added, make sure to turn off before leaving home or going to sleep.
- Check all bolts for tightness before use.
- Please periodically check all fittings and re-tighten as necessary.
- This product should only be used on firm, level ground. Make sure the legs remain in contact with the ground at all times.

Storage Instructions

1. Disconnect power from the lights.
2. Always unplug electrical decorations before replacing bulbs or fuses.
3. Remove all ornaments and decorations.
4. Over time, examine extension cords and lights for signs of damage.
5. Starting from the top, carefully remove branches. Press the tips back up against the stem.
6. Place the branch sections back into the carton, putting the longest one on the bottom.
7. Carefully place all tree sections into shipping box and tape shut.
8. When not in use, please store your tree in a cool, dry place away from sunlight. Exposing your tree to excessive heat or humidity may damage your tree.

Limited Warranty:
Charles Bentley warrants to the original purchaser that this item is free from defects in workmanship and materials for a period of 1 year from the date of purchase and is maintained with care and used only for personal and residential purposes. Should any manufacturing defect arise within this warranty period, Charles Bentley will repair or replace (at our option) any defective merchandise upon proof of purchase; however, transportation and delivery costs, as well as payments to a third party for assembly or disassembly of the item, remain the responsibility of the purchaser. Exclusions: Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse , or improper assembly are not covered.

Manufacturers address: Yuanzhou Town, Bo Luo County, Huizhou City, China.

CHARLES BENTLEY

EST. 1860

Find Us On



Contact: customerservices@charlesbentley.com

Please Retain Instructions For Future Use

CHARLES BENTLEY & SON LTD
NORTH ROAD, LOUGHBOROUGH, LEICESTERSHIRE, LE11 1QJ