

26-NX 組說-IL

客戶名稱	26-NX		
組說名稱	EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE		
印刷規格	( 3張A4雙面+ 1張A4單面) 組說+ 1張A4單面包裝圖		
訂單號碼	機種名稱及顏色	合同號碼	數量
	【FSC E05】E73607 铁 环普 EVIE COFFEE NEST #I25024K国产纸+I25024K PVC (A260101503)		
	【FSC E05】E96808 铁 环普 EVIE COFFEE NEST BLK #I25054K国产纸+G95515-106 PVC (A260101505)		
	【FSC E05】AA3517 铁 环普 (外箱普印/有向上箭头标) EVIE COFFEE NEST GL #RB2901-12G+2901E (A260101572)		
以上機種共用此份組說			

组说第5页标尺刻度要求1：1 印制

附1張A4單面“开箱说明书”放在組說最上面.

附1張A4單面空心板說明書放在“开箱说明书”下面

# BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

## 1. COLOUR

Make sure you're happy with the colour

No need to unpack everything, just check the first component.

## 2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

## 3. PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

## TIPS FOR RETURNS

Not completely happy with the product? No problem.

We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



- Check everything is there (the 'parts page' is a handy checklist).
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T



- Leave anything assembled - all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly - as it may get damaged.


**NEXT**  
HOME

Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.




## Care instructions for hollow board & Honeycomb board during you assembling the product

The structures of hollow board & honeycomb board are as below:



The centre of Hollow board & Honeycomb board is hollow. To avoid damaging the hollow board/honeycomb board, we suggest you not step on the hollow board/honeycomb board or not put other part on the board on the end when you assemble the product.





# NEXT

EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE  
E73607 / E96808 / AA3517  
Assembly instructions

**Actual product size**

H45 x W75 x D37.5 cm

H35 x W65 x D65 cm



## Need Help ?

With: Assembly instruction

Missing or damaged parts

**IMPORTANT - RETAIN FOR FUTURE REFERENCE**

**CALL: 0333 777 8999**

# NEXT

EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE  
E73607 / E96808 / AA3517  
Assembly instructions


## BEFORE YOU START

### Number of people required to assemble

One people is required to assemble this item



### Tools required



not supplied

### Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recomemnt that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

### Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.


Never allow any kind of liquid to remain on your furniture.  
Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

# NEXT

EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE  
E73607 / E96808 / AA3517  
Assembly instructions



## GETTING TO KNOW YOUR PRODUCT



# NEXT

## EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE E73607 / E96808 / AA3517 Assembly instructions




Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	37.5x75cm		2	1
2	65x65cm		1	1

# NEXT

EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE  
E73607 / E96808 / AA3517  
Assembly instructions

1







# NEXT

EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE  
E73607 / E96808 / AA3517

**Actual product size**

H45 x W75 x D37.5 cm

H35 x W65 x D65 cm



# NEXT

EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE  
E73607 / E96808 / AA3517

## Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

## Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

## Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

## You can write to us at


Home Customer Services  
Next Retail Ltd.  
Desford Road,  
Leicester,  
LE19 4AT

To view our full furniture range please visit [www.next.co.uk](http://www.next.co.uk)

# EVIE / EVIE BLACK / EVIE GLOSS NEST OF 2 COFFEE TABLE

## REPACK INSTRUCTION

NEXT



Next Retail Ltd, Desford Road, Leicester, LE19 4AT