

BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

1. COLOUR

Make sure you're happy with the colour

No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3. PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

TIPS FOR RETURNS

Not completely happy with the product? No problem.

We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



- Check everything is there (the 'parts page' is a handy checklist).
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T



- Leave anything assembled - all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly – as it may get damaged.


NEXT
HOME

Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.




Care instructions for hollow board & Honeycomb board during you assembling the product

The structures of hollow board & honeycomb board are as below:



The centre of Hollow board & Honeycomb board is hollow. To avoid damaging the hollow board/honeycomb board, we suggest you not step on the hollow board/honeycomb board or not put other part on the board on the end when you assemble the product.



NEXT


BRONX DARK TALL VANITY DRESSING TABLE

AN3014

Assembly instructions

Actual product size

H175 x W100 x D50 cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.


NEXT

BRONX DARK TALL VANITY DRESSING TABLE

AN3014

Assembly instructions

GETTING TO KNOW YOUR PRODUCT







NEXT







BRONX DARK TALL VANITY DRESSING TABLE

AN3014



Assembly instructions

Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	50x175cm		1	1
2	46.5x52.5cm		1	1
3	38x46cm		1	1
4	46.5x52.5cm		1	1
5	12x46 cm		1	1
6	46.5x52.5cm		1	1
7	52.5x157.5cm		1	2
8	50x157.5cm		1	2
9	45x61cm		1	2
10	5x96cm		1	2
11	40x47.5cm		1	1
12	9.5x40cm		1	1
13	50x157.5cm		1	2

Ref	Dimensions	Visual	Qty	Ctn
14	50x175cm		1	1
15	40.5x156cm		1	2
16	50x96cm		1	1
17	3x39cm		1	1
18	44x50.5cm		1	1
19	10.5x40cm		1	1
20	10.5x45.5cm		1	1
21	10.5x40cm		1	1
22	38.5x46cm		1	1
23	11.5x50cm		1	1
24	39.5x157cm		1	2
25	25x37.5cm		2	1


NEXT FITTINGS ASSEMBLE INSTRUCTIONS




Push connector into housing to join.




Make sure there is no gap between the panels.




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.



Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.




The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)

BRONX DARK TALL VANITY DRESSING TABLE

AN3014
Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
S41	Ø4 x 16mm	2	1
Y29	Ø6 x 12mm	2	1
V53	Ø6 x 30mm	15	2
V83	Ø6 x 60mm	2	1
B3	Ø15 x 12mm	9	1
B12	Ø7.5 x 33mm	9	1
S42	Ø4 x 16mm	4	1
U139	Ø4.5 x 15mm	16	2
Y8	Ø6 x 50mm	6	1
U143	Ø4 x 15mm	16	2
P3	Ø5 x 16mm	4	1



Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
N7	N/A	2	N/A	
T38	N/A	6	1	
T4	N/A	2	N/A	
O1	Ø21mm	15	2	
N30	LED light	1	N/A	

Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
M11	N/A	1	N/A	
M9	N/A	1	N/A	
C11	N/A	8	N/A	
E39	N/A	4	N/A	
T10	N/A	1	N/A	


NEXT

BRONX DARK TALL VANITY DRESSING TABLE

AN3014

Assembly instructions


1



B12


Ø7.5 x 33mm

9




not supplied

2




3

Remove the protective film from the magnetic attraction plate.



4



B3


Ø15 x 12mm

1



ALIGNED

5



T10	N/A	1	
B3	Ø15 x 12mm	2	  not supplied


6

WHEN LOOSENING THE CAM


TURN THE CAM IN A COUNTERCLOCKWISE DIRECTION
UNTIL THE ARROW POINTS IN THE POSITION SHOWN
IN THE DIAGRAMS BELOW




MAXIMUM
LOCK



TURN
TO UNLOCK



UNLOCKED



B3

Ø15 x 12mm

6





not supplied

NEXT


BRONX DARK TALL VANITY DRESSING TABLE
AN3014
Assembly instructions


7




T4	N/A	2	
Y8	Ø6 x 50mm	6	

8



T4	N/A	2	
V53	Ø6 x 30mm	3	

9



T4	N/A	2	
V53	Ø6 x 30mm	4	


NEXT

BRONX DARK TALL VANITY DRESSING TABLE


AN3014

Assembly instructions


10



11




12



T4	N/A	2	
Y29	Ø6 x 12mm	1	
V83	Ø6 x 60mm	2	

13




SLOTS ALIGNED

NEXT


BRONX DARK TALL VANITY DRESSING TABLE
AN3014
Assembly instructions

14



T4	N/A	2	
V53	Ø6 x 30mm	8	

15



T4	N/A	2	
Y29	Ø6 x 12mm	1	


NEXT

BRONX DARK TALL VANITY DRESSING TABLE


AN3014

Assembly instructions





16






17




A diagram showing a screw being inserted into a felt pad. The screw is labeled 'S42'. The felt pad is labeled 'FELT PAD'.



Packing Materials

S42	Ø4 x 16mm	4		 not supplied
M11	N/A	1		
M9	N/A	1		
N7	N/A	2		
S41	Ø4 x 16mm	2		 not supplied

19




O1	Ø21mm	15	
----	-------	----	---

NEXT

BRONX DARK TALL VANITY DRESSING TABLE


AN3014
Assembly instructions

20



$A=B$

21



T38

N/A

6



not supplied



22

We recommend the use of the wall attachment bracket/strap provided for safety reasons. Move unit into desired position. Secure the 2X"L" metal brackets to the wall with an appropriate screw and wall plug for your wall type (not provided).


Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type.


If in doubt please consult a qualified trades person.




23




24




P3	Ø5 x 16mm	4	
----	-----------	---	---

25

Set the LED lights to automatic sensing mode follow the last page.




Place the lamp tube position as show in the picture.




N30	LED light	1	
-----	-----------	---	---


26



27




28





29



Note: Drawer will be permanently assembled once panel (23) is fitted.



30





E39	N/A	1		 not supplied
-----	-----	---	---	---





How to remove drawer

Left side



Right side



NEXT

BRONX DARK TALL VANITY DRESSING TABLE
AN3014
Assembly instructions

32

Packing Materials


E39	N/A	1		 not supplied
U139	Ø4.5 x 15mm	8		 not supplied
C11	N/A	4		

33

Packing Materials


E39	N/A	2		 not supplied
U139	Ø4.5 x 15mm	8		 not supplied
C11	N/A	4		

X2




Install Hinge


Step.1:Lift up the hook




Step.2:Hook the hinge to the base




Step.3:Press inside




Remove Hinge



Adjust Hinge Position










U143	Ø4 x 15mm	16		 not supplied
------	-----------	----	---	---

36

To disassemble:




Step1: Remove the plastic wedge (T38) from the back plate, and remove the screws from the rear of the panel(11);



Step2: Press down the back panel so it is clear of the top panel slot;

37

Slide the top panel front to unlock, then lift off. Follow the same sequence to remove the other panels;




NEXT

BRONX DARK TALL VANITY DRESSING TABLE AN3014

Actual product size

H175 x W100 x D50 cm



NEXT

BRONX DARK TALL VANITY DRESSING TABLE AN3014

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Name and Address:NEXT RETAIL LTD.LE19 4AT

Identification and model Number: AN3014 BRONX DARK TALL VANITY DRESSING TABLE

Date of Manufacture:

Contract number:

Nominal thickness of Glass:4mm,Mirror

Country of Origin:China

If a glass component is chipped or broken replace with glass of the type described on this label.Consult with the retailer with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number,batch number and date of manufacture.

Missing parts

If you are missing any fixtures and fittings for your product.
Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement,refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk

NEXT

BRONX DARK TALL VANITY DRESSING TABLE AN3014

Contents and specification:

- 1x sensor LED desk which doesn't need to be plugged in to function.
- This product contains 1x battery which are non-replaceable.
- Rechargeable by USB port 0.8m USB charging cable included (USB plug is needed to charge but not included)
- Integrated LED lamp/strip - bulbs not required.
- Average run time: 6 hours (keep lighting)
- Wattage: 1.63W
- Light output: 93.52 lumens
- Colour temperature: 3000K/4000K/6000K
- The light will only go through the 3 stage touch when in contact with the switch on the top of the LED
- This product has a charging indicator light. When charging the light will show red. Once charging is complete, the light will change to white. In order to maintain the longevity of the product, please do not overcharge or leave on the charge for 24 hours.
- Constant On Mode: The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
- Night Sensing Mode: The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. The light will automatically turn off when human left the sensing range for after 25 seconds. The light will keep lighting if human stay in the sensing range.
- The sensing range of the light is 120° from the center point of the probe, within a 3 meter area. However, improper installation or obstructions near the sensing probe may affect the sensing effect.
- Ensure that all packaging is disposed of carefully and responsibly.
- Keep all plastic wrapping materials away from children to avoid danger of suffocation

NEXT

MODEL NUMBER: AN3014

BULB TYPE: NOT REQUIRED

VOLTAGE: 2.6-5V. MAX 388 MA. 1.63W

BATCH NO: 05/2025



**UK
CA**



**LE19 4AT
D02 ED70**

Manual -LED

Please fully charge the battery before using it for the first time.


Description of Modes and Their Functions

 Constant On Mode	The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
 Night Sensing Mode	- The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. - The light will automatically turn off when human left the sensing range for after 25 seconds. - The light will keep on if human stay in the sensing range.

Instructions for buttons

Push button switch	- Press button: Cycle through the light colors. (ON mode) - Holding button: Adjusts the brightness. (ON mode)
Toggle switch	- AUTO: Night Sensing mode. - ON: Constant ON mode. - OFF: Turn off the lamps.

Sensing range and its precautions



- The sensing range of the light is 120° from the center point of the probe, within a 3 meter area.
- However, improper installation or obstructions near the sensing probe may affect the sensing effect.


Charging instructions

- Charging voltage: DC5V/1A
- Charging port: Type-C
- Charging indication: Red light on- charging / Green light on- fully charged

Precautions

- Please fully charge the battery before using it for the first time.
- Please do not use charging devices with output voltage greater than 5V/1A to charge the lamp.
- Please use a safety-certified mobile phone charging adapter to charge the light.
- Do not use while charging.
- Keep away from fire. Do not use this light in a damp or high-temperature environment. Do not allow children to use or come into contact with this light. Do not attempt to repair or replace any parts by yourself.


If the contents of the manual can not solve the problem for you, please contact the merchant in time, thank you for your support and trust.



BRONX DARK TALL VANITY DRESSING TABLE(2-1)

REPACK INSTRUCTION


NEXT



Next Retail Ltd, Desford Road, Leicester, LE19 4AT

BRONX DARK TALL VANITY DRESSING TABLE(2-2) REPACK INSTRUCTION

NEXT



Next Retail Ltd, Desford Road, Leicester, LE19 4AT