

Nina Campbell
HOME


NINA CAMPBELL TEDWORTH TV UNIT

C38200 B57366

Assembly instructions

Actual product size

H53 x W158 x D40cm



Need Help?

With: Assembly instructions
Missing or damaged parts


CALL: 0333 777 8999

IMPORTANT — RETAIN FOR FUTURE REFERENCE


BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item.



Tools required



not supplied



not supplied

Missing parts

If you are missing any fixtures and fittings for your product, please contact our customer service team on **0333 777 8999**, and they will be happy to arrange for a replacement to be sent to you free of charge.


Home service technicians

If you have a fault with your product please contact our customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

PRODUCT SUPPLIED WITH WALL FIXING STRAPS

Time to assemble: 30mins

GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	39.5 x 158cm		1	1
2	16.5 x 4.3cm		4	1
3	16 x 4cm		2	1

**Fixtures and fittings
supplied (actual size)**


Ref	Dimensions	Qty	*Extra Fittings
AA	M8 x 85mm	4	
AB	M8/Ø12x38mm	4	
AP	M4x25mm	6	1



Fixtures and fittings supplied(not to scale)

Ref	Dimensions	Visual	Qty	*Extra Fittings
AC	12mm		1	
AD	M8 x 12mm		4	1
AE	Ø8mm		4	1
AF	Ø8 x 19mm		4	1
AQ	Ø20 x 3mm		4	1
AW	Ø6 x 16mm		2	
AS	130mm		3	


1




AA x 4 M8 x 85mm




AB x 4 M8/Ø12 x 38mm



2



AC x 1 12mm




AD x 4 M8mm




AE x 4 Ø8mm




AF x 4 Ø8 x 19mm



3




4




AQ x 4 Ø20 x 3mm





5



6



7






NINA CAMPBELL TEDWORTH TV UNIT

C38200 B57366

Assembly instructions

8


We recommend the use of the wall belt provided for safety reasons. Wall fixings are not included please source suitable fixings for your wall type. If in doubt, please consult a qualified tradesperson. **WARNING:** Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



NINA CAMPBELL TEDWORTH TV UNIT

C38200 B57366












Assembly instructions



NINA CAMPBELL TEDWORTH TV UNIT

C38200 B57366

Assembly instructions



We suggest you retain these instructions for future reference

Warnings

Assembly to be carried out by a competent adult only.

Keep fittings out of children's reach and keep children well away from the construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Do not use this item if any components are missing or damaged.

Nina Campbell
HOME


NINA CAMPBELL TEDWORTH TV UNIT

C38200 B57366

Assembly instructions

Actual product size

H53 x W158 x D40cm



Need Help?

With: Assembly instructions
Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT — RETAIN FOR FUTURE REFERENCE