


NEXT

HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

Actual product size

H202.5 X W200 X D62cm



Need Help ?

With: Assembly instruction
Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT - RETAIN FOR FUTURE REFERENCE

HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

BEFORE YOU START

Number of people required to assemble

Two people are required to assemble this item

Time to assemble: 30 minutes



Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use. Installation shall be carried out exactly according to the manufacturers instructions-otherwise a safety risk can occur if incorrectly installed.

Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish. Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to delaminate. Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster.

Missing parts

If you are missing any fixtures and fittings for your product, please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

PRODUCT SUPPLIED WITH WALL FIXING METAL BRACKETS

Warnings

We suggest you retain these instructions for future reference. Keep fittings out of children's reach and keep children well away from construction area. This product should only be used on firm level ground. Please periodically check all fittings and retighten as necessary. Please do not sit or stand on your furniture. Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour. Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage. In order to prevent overturning this product must be used with the wall attachment provided.

Home Service Technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range
please visit www.next.co.uk

Need Help ?

With: Assembly instruction
Missing or damaged parts


CALL: 0333 777 8999

IMPORTANT - RETAIN FOR FUTURE REFERENCE

HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

GETTING TO KNOW YOUR PRODUCT











HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

GETTING TO KNOW YOUR PRODUCT

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	200x62cm		1	3
2	94.6x51cm		2	3
3	191x96cm		2	2
4	94.3x4cm		2	3
5	94.6x20cm		2	3
6	94.3x29cm		2	3
7	189.1x58 cm		1	2

Ref	Dimensions	Visual	Qty	Ctn
8	189.1x58 cm		1	2
9	189.1x52.2cm		1	2
10	185.4x95cm		1	4
11	185.4x95cm		1	4
12	200x60cm		1	1









HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

Fixtures and fittings
supplied (actual size)

Ref	Dimensions	Qty
A	7 x 16mm	8
B	16 x 14mm	20
C	3 x 16mm	20
D	3 x 17mm	4
H	30 x 24mm	2
I	4 x 35mm	2
K	2 x 50mm	1
N	Ø12 mm	2
M	Ø18 mm	30

mm 10 20 30 40 50 60 70 80 90 100 110 120 130



Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Visual	Qty
E	N/A		2
F			4
G			2
J	N/A		4


Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Visual	Qty
L	N/A		2


HAMPTON 2M SLIDE DOOR E28138

Assembly instructions


TITUS TIGHTENING INSTRUCTIONS




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.



Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.



The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)

HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

1

WHEN TIGHTENING THE CAM


TURN THE CAM IN A CLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITIONS SHOWN IN THE DIAGRAMS BELOW



START




MINIMUM
LOCK





MAXIMUM
LOCK

PUSH THE TWO PANELS TOGETHER ALLOWING THE DOWEL TO ALIGN WITH THE HOLE




TURN THE CAM IN A CLOCKWISE DIRECTION




HAMPTON 2M SLIDE DOOR E28138
Assembly instructions

2




3




HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

4




5




HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

6






7




HAMPTON 2M SLIDE DOOR E28138
Assembly instructions

8






HAMPTON 2M SLIDE DOOR E28138
Assembly instructions

9



10



HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

Contents and specification:

- 1x sensor LED wardrobe which doesn't need to be plugged in to function.
- This product contains 1x battery which are non-replaceable.
- Rechargeable by USB port 0.8m USB charging cable included (USB plug is needed to charge but not included)
- Integrated LED lamp/strip - bulbs not required.
- Average run time: 6 hours (keep lighting)
- Wattage: 1.63W
- Light output: 93.52 lumens
- Colour temperature: 3000K/4000K/6000K
- The light will only go through the 3 stage touch when in contact with the switch on the top of the LED
- This product has a charging indicator light. When charging the light will show red. Once charging is complete, the light will change to white. In order to maintain the longevity of the product, please do not overcharge or leave on the charge for 24 hours.
- Constant On Mode: The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
- Night Sensing Mode: The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. The light will automatically turn off when human left the sensing range for after 25 seconds. The light will keep lighting if human stay in the sensing range.
- The sensing range of the light is 120° from the center point of the probe, within a 3 meter area. However, improper installation or obstructions near the sensing probe may affect the sensing effect.
- Ensure that all packaging is disposed of carefully and responsibly.
- Keep all plastic wrapping materials away from children to avoid danger of suffocation

NEXT

Model Number: L 1007

Build Type: NOT REQUIRED

Voltage: 2,8 - 4,2V

Batch No.: 03/2025



LE19 4AT
D02 ED70

HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

Manual -LED

Please fully charge the battery before using it for the first time.


Description of Modes and Their Functions

 Constant On Mode	■ The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
 Night Sensing Mode	■ The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. ■ The light will automatically turn off when human left the sensing range for after 25 seconds. ■ The light will keep on if human stay in the sensing range.

Instructions for buttons

Push button switch	■ Press button : Cycle through the light colors. (ON mode) ■ Holding button : Adjusts the brightness. (ON mode)
Toggle switch	■ AUTO : Night Sensing mode. ■ ON : Constant ON mode. ■ OFF : Turn off the lamps.

Sensing range and its precautions



- The sensing range of the light is 120° from the center point of the probe, within a 3 meter area.
However, improper installation or obstructions near the sensing probe may affect the sensing effect.


Charging instructions

- Charging voltage : DC5V/1A
- Charging port : Type-C
- Charging indication : Red light on- charging / Green light on- fully charged

Precautions


- 1、 Please fully charge the battery before using it for the first time.
- 2、 Please do not use charging devices with output voltage greater than 5V/1A to charge the lamp.
- 3、 Please use a safety-certified mobile phone charging adapter to charge the light.
- 4、 Do not use while charging.
- 5、 Keep away from fire. Do not use this light in a damp or high-temperature environment. Do not allow children to use or come into contact with this light. Do not attempt to repair or replace any parts by yourself.

If the contents of the manual can not solve the problem for you, please contact the merchant in time, thank you for your support and trust.



HAMPTON 2M SLIDE DOOR E28138
Assembly instructions



11



HAMPTON 2M SLIDE DOOR E28138



Assembly instructions

12




HAMPTON 2M SLIDE DOOR E28138
Assembly instructions

13





HAMPTON 2M SLIDE DOOR E28138
Assembly instructions

14




HAMPTON 2M SLIDE DOOR E28138
Assembly instructions

15





HAMPTON 2M SLIDE DOOR E28138
Assembly instructions



HAMPTON 2M SLIDE DOOR E28138
Assembly instructions



17



HAMPTON 2M SLIDE DOOR E28138



Assembly instructions

18



HAMPTON 2M SLIDE DOOR E28138
Assembly instructions

19



N x 2		Ø12 mm
H x 2		30 x 24mm
PH2 I x 2		4 x 35mm






HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

20

ALIGNMENT OF WARDROBE:

1. Move wardrobe to final position
2. Adjust gaps between door and side to be even top to bottom and on both/all doors (use door adjustment drawings)
3. Check door top & bottom are aligned with the frame. If not add wedges under front and rear legs (on side that bottom edge of doorgap is to small) until correct, then snap off extra part of wedges.



HAMPTON 2M SLIDE DOOR E28138

Assembly instructions





21

WARNING: In order to prevent overturning this unit must be used with the wall attachment device/s provided. We recommend the metal bracket provided for safety reasons. Wall fixings are not included please source suitable fixings for your wall type.

If in doubt, please consult a qualified tradesperson.

WARNING: Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.

Installation shall be carried out exactly according to the manufacture's instructions - otherwise a safety risk can occur if incorrectly installed.



HAMPTON 2M SLIDE DOOR E28138

Assembly instructions

Actual product size
H202.5 X W200 X D62cm

