

BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

1. COLOUR

Make sure you're happy with the colour
No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3. PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

TIPS FOR RETURNS

Not completely happy with the product? No problem.
We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.

DO



- Check everything is there (the 'parts page' is a handy checklist).
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T



- Leave anything assembled - all components should be dismantled and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box carelessly – as it may get damaged.

next
HOME

Then just give us a call on 0333 777 8999 and we'll sort out a pick up time for you.

next


COMPTON CABIN BED

362620, E51841

Assembly instructions

Actual product size

H96 x W194 x D108



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - READ CAREFULLY - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

BEFORE YOU START

IMPORTANT – READ CAREFULLY – RETAIN FOR FUTURE REFERENCE

WARNINGS

This product complies with BS EN 747:2012+A1:2015

WARNING: Routinely check that the upper safety rail and ladder attachment is secure and tighten any fittings using the appropriate tools.

All assembly fittings shall always be tightened properly. Screws shall not be loose because a child can squeeze parts of the body, or clothing (e.g. strings, necklaces, ribbons for babies, dummies, etc.) could get caught. There would be danger of strangulation.

WARNING: High beds and the upper bed of bunk beds are not suitable for children under six years due to the risk of injury from falls.

WARNING: Bunk beds and high beds can present a serious risk of injury from strangulation if not used correctly. Never attach or hang items to any part of the bunk bed that are not designed to be used with the bed, for example, but not limited to ropes, strings, cords, hooks, belts and bags.

WARNING: Children can become trapped between the bed and the wall, a roof pitch, the ceiling, adjoining pieces of furniture (e.g. cupboards) and the like. To avoid risk of serious injury the distance between the top of the safety barrier and the adjoining structure shall not exceed 75mm or shall be more than 230mm.

WARNING: Do not use the bunk bed/high bed if any structural part is broken or missing;

Do not leave items such as ropes, strings, cords, harnesses and belts attached to or hung to the bunk/high bed due to the risk of strangulation. Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, and should be placed either tight to any wall or have a gap of 300mm between the wall and the side of the bed

Do's

Always follow the assembly instructions provided with this product.

When you are ready to start, make sure that you have the right tools and plenty of space

Due to the size of the product we recommend that it is assembled in the room intended for use

Unwrap all packaging materials and place the components on a clean surface to protect it from damage

We recommend that the packaging is used to protect the surfaces during assembly

Carefully check that you have all the parts before beginning assembly
The recommended size of the mattress is: 190cm x 90cm x 17cm
The bed/bunk bed is intended to be used with a mattress of **maximum** thickness 17cm. The bed frame is marked to show this height.
Please ensure that the mattress depth does not go past the permanent mark on the post/Upper Safety Barrier
Ventilation of the room is necessary in order to keep the humidity low and to prevent mould in and around the bed.
Regularly check that all assembly fittings are tightened correctly.
To clean your item, wipe with a soft cloth slightly dampened with water. Then buff with a dry clean cloth

Don'ts

Do not drag or pull your furniture


Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish

Do not stand or jump on this product

Number of people required to assemble


Two persons are required to assemble this item.

Time to assemble




45 MIN

2 PERSON
BUILD



Tools required



Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians


If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk

GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	96 x 96cm		1	3
2	96 x 96cm		1	3
5	58 x 40cm		1	1
6	58 x 40cm		1	1
7	190 x 58cm		1	2
8	190 x 96cm		1	3

Ref	Dimensions	Visual	Qty	Ctn
9	42 x 10cm		1	1
10	42 x 30cm		1	1
11	72 x 6cm		2	2
12	72 x 28cm		1	1
13	72 x 28cm		1	1
14	72 x 28cm		1	1
15	72 x 28cm		1	1
16	58 x 15cm		2	2
17	36 x 24cm		2	2
18	36 x 24cm		2	2
19	190 x 35cm		1	2
20	76 x 35cm		1	2
21	76 x 35cm		1	2

Fixtures and fittings supplied (actual size)


Ref	Dimensions	Qty
K1	7x50mm	22
K2	7x70mm	12
G19	6x70mm	18
G6	10x14mm	18
W2	5x16mm	4




Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Visual
G7	⬡ 4mm	2	


TITUS TIGHTENING INSTRUCTIONS




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.





Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.





The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)

1





K2	7x70mm	6	
----	--------	---	---

2




3




K1	7x50mm	4	
----	--------	---	---


4




5



6




7





K1	7x50mm	3	
----	--------	---	---

8





9




K1	7x50mm	1	
----	--------	---	---




10




K1	7x50mm	6	
----	--------	---	---

11




G19	6x70mm	3	
G6	10x14mm	3	
K1	7x50mm	4	

12




G19	6x70mm	3	
G6	10x14mm	3	
K1	7x50mm	4	

13




G19	6x70mm	8	
G6	10x14mm	8	

14




15






G19	6x70mm	4	
G6	10x14mm	4	
K2	7x70mm	6	

16



W2	5x16mm	4	
----	--------	---	--



Actual product size

H96 x W194 x D108

