
Assembly instructions

Actual product size

KING:H110.5 x W263 x D208 cm SUPER KING:H110.5 x W293 x D208cm



Delivery Box Sizes(CM): Height x Width x Depth

	KING*	SUPER KING*
Box 1	2250x480x195mm	2250x480x210mm
Box 2	1730x1255x155mm	2030x1255x155mm
Box 3	2100x835x205mm	2100x985x205mm

*Sizes available vary depending on Colour/Fabric

IMPORTANT - RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly instruction Missing or damaged parts

CALL: 0333 777 8999

BEFORE YOU START

Number of people required to assemble

Two people are required to assemble this item



Time to assemble: 60 minutes

Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recomement that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts


Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.


Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.



NEXT BRONX STORAGE SHELVING BED SUPER KING



Ref	Dimensions	Visual	Qty	Ctn
1	104.5x159cm		1	2
2	30x208cm		1	1
3	30x208cm		1	1
4	9.5x152cm		1	3
5	30x156cm		1	1
6	9.5x19.5cm		2	1
7	22x104.5cm		1	3
8	22x104.5cm		1	3
9	13x104.5cm		1	1
10	13x104.5cm		1	1
11	18x129.5cm		1	1

Ref	Dimensions	Visual	Qty	Ctn
12	18x129.5cm		1	1
13	5.5x129.5cm		1	1
14	5.5x129.5cm		1	1
15	4x159cm		1	2
16	4.5x47cm		2	1
17	37.5x47cm		2	1
18	30x47cm		2	1
19	47.5x73.5cm		2	3
20	22x110cm		1	2
21	22x110cm		1	2
22	18x47cm		4	1

Assembl instructions

Ref	Dimensions	Visual	Qty	Ctn
23	147x197cm		1	3
24	51.5x152cm		4	3
25	10.5x152cm		1	3
26	10.5x152cm		1	3
27	2x54.5cm		2	3
28	4x50 cm		2	1

NEXT BRONX STORAGE SHELVING BED SUPER KING

Assembl instructions

Ref	Dimensions	Visual	Qty	Ctn
1	104.5x189cm		1	2
2	30x208cm		1	1
3	30x208cm		1	1
4	9.5x182cm		1	3
5	30x186cm		1	1
6	9.5x19.5cm		2	1
7	22x104.5cm		1	3
8	22x104.5cm		1	3
9	13x104.5cm		1	1
10	13x104.5cm		1	1
11	18x144.5cm		1	1

Ref	Dimensions	Visual	Qty	Ctn
12	18x144.5cm		1	1
13	5.5x144.5cm		1	1
14	5.5x144.5cm		1	1
15	4x189cm		1	2
16	4.5x47cm		2	1
17	37.5x47cm		2	1
18	30x47cm		2	1
19	47.5x73.5cm		2	3
20	22x110cm		1	2
21	22x110cm		1	2
22	18x47cm		4	1

NEXT BRONX STORAGE SHELVING BED SUPER KING

Assembl instructions

Ref	Dimensions	Visual	Qty	Ctn
23	177x197cm		1	3
24	51.5x182cm		4	3
25	10.5x152cm		1	3
26	10.5x152cm		1	3
27	2x54.5cm		2	3
28	4x50 cm		2	1

NEXT


BRONX STORAGE SHELVING BED

E73787

Assembl instructions

Fixtures and fittings supplied (actual size)


Ref	Dimensions	Qty	Spare Qty
Y35	Ø8x65mm	4	1
Y10	Ø6 x 35mm	14	2
V87	Ø6 x 105mm	4	1
V36	Ø6 x 15mm	20	2
V98	Ø8 x 45mm	10	N/A
В3	Ø15 x 12mm	28	2
B15	Ø4 x 16mm	16	2
K12	Ø11.4x15mm	4	1
V97	Ø8 x 70mm	3	N/A
S41	Ø4 x 16mm	4	1
B12	Ø6 x 33mm	28	2
Y8	Ø6 x 50mm	8	1
V68	Ø8 x 30mm	8	1
D6	Ø8 x 30mm	N/A	2
D14	Ø10 x 30mm	N/A	1
В8	Ø8 x 38mm	N/A	2





Assembl instructions


Fixtures and fittings supplied (not to scale)

Fixtures and fittings supplied (not to scale)					
Ref	Dimensions	Qty	Spare Qty	Visual	
T4	N/A	2	N/A		
T13	N/A	1	N/A		
N24	N/A	4	N/A		
B23	N/A	13	N/A		
T41	N/A	1	N/A		
T52	N/A	2	N/A	·	
Т6	N/A	2	N/A		
N30	LED light	2	N/A		
B31	N/A	4	N/A		
Q3	N/A	23	2		
01	N/A	14	2		












Assembl instructions


N/A Q3 16 N/A 4 N24 Ø6 x 15mm V36 16 2 T4 N/A









12





13





14























25 Press and tighten.





Assembl instructions


27 26) 25) **x**1 10.5*152cm **x**1 10.5*152cm T13 N/A 1 (27) T41 N/A 1 x2 2*54.5cm B31 N/A























Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services Next Retail Ltd. Desford Road, Leicester, LE19 4AT

To view our full furniture range please visit www.next.co.uk

Contents and specification:

- 1x sensor LED desk which doesn't need to be plugged in to function.
- This product contains 1x battery which are non-replaceable.
- Rechargeable by USB port 0.8m USB charging cable included (USB plug is needed to charge but not included)
- Integrated LED lamp/strip bulbs not required.
- Average run time: 6 hours (keep lighting)
- Wattage: 1.63W
- Light output: 93.52 lumens
- Colour temperature: 3000K/4000K/6000K
- The light will only go through the 3 stage touch when in contact with the switch on the top of the LED
- This product has a charging indicator light. When charging the light will show red. Once charging is complete, the light will change to white. In order to maintain the longevity of the product, please do not overcharge or leave on the charge for 24 hours.
- Constant On Mode: The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
- Night Sensing Mode: The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. The light will automatically turn off when human left the sensing range for after 25 seconds. The light will keep lighting if human stay in the sensing range.
- The sensing range of the light is 120° from the center point of the probe, within a 3 meter area. However, improper installation or obstructions near the sensing probe may affect the sensing effect.
- Ensure that all packaging is disposed of carefully and responsibly.
- Keep all plastic wrapping materials away from children to avoid danger of suffocation

NEXT

MODEL NUMBER: E73787

BULB TYPE:MAX 1.63W LED

VOLTAGE: 2.6-5V dc, MAX.388 mA

BATCH NO:07/2025



Manual -LED

Please fully charge the battery before using it for the first time.

Description of Modes and Their Functions

- Onstant On Mode	■ The light stays on continuously, the sensing function does not work, and it does not turn off automatically.
Night Sensing Mode	 The light will automatically light up when both sensing human and in low lit environment, otherwise it won't automatically light up. The light will automatically turn off when human left the sensing range for after 25 seconds. The light will keep on if human stay in the sensing range.

Instructions for buttons

Push button switch	■ Press button: Cycle through the light colors. (ON mode) ■ Holding button: Adjusts the brightness. (ON mode)
	■ AUTO: Night Sensing mode.
Toggle switch	ON: Constant ON mode.
	■ OFF: Turn off the lamps.

Sensing range and its precautions



■ The sensing range of the light is 120° from the center point of the probe, within a 3 meter area.

However, improper installation or obstructions near the sensing probe may affect the sensing effect.

Charging instructions

- Charging voltage: DC5V/1A
- Charging port: Type-C
- Charging indication: Red light on- charging / Green light on- fully charged

Precautions

- 1. Please fully charge the battery before using it for the first time.
- 2. Please do not use charging devices with output voltage greater than 5V/1A to charge the lamp.
- 3. Please use a safety-certified mobile phone charging adapter to charge the light.
- 4. Do not use while charging.
- 5. Keep away from fire. Do not use this light in a damp or high-temperature environment. Do not allow children to use or come into contact with this light. Do not attempt to repair or replace any parts by yourself.

If the contents of the manual can not solve the problem for you, please contact the merchant in time, thank you for your support and trust.

Push button switch Toggle switch

Produced in China for Next Retail Ltd. E73787-2025-V1.