
FLYNN WARDROBE 3 DOORS AND 3 DRAWERS

F41152

Assembly instructions

Actual product size H190 x W117.4 x D50.2 cm



Need Help?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR OR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT F41152

FLYNN WARDROBE 3 DOORS AND 3 DRAWERS

Assembly instructions

BEFORE YOU START

Number of people required to assemble

Two people are required to assemble this item

Time to assemble: 90 minutes











Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate. Do not place hot items (e.g. hot drinks) directly on to the wood surface

Please make sure you use a placement or coaster.

PRODUCT SUPPLIED WITH WALL FIXING **BRACKET/S**

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Warnings

We suggest you retain these instructions for future reference. Keep fittings out of children's reach and keep children well away from the construction area.

This product should only be used on firm, level ground. Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture. Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour. Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Home service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible.

If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at


Home Customer Services Next Retail Ltd. Desford Road, Leicester, **LE19 4AT**

To View our full furniture range please visit www.next.co.uk

Need Help?

With: Assembly instruction Missing or damaged parts CALL: 0333 777 8999

FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS

F41152 Assembly instructions


Components supplied. Please use this guide if you require replacement parts.

| Ref | Dimensions | Visual | Qty | Ctn |
|-----|--------------|--|-----|-----|
| 1 | 48x188cm | The state of the s | 1 | 2 |
| 2 | 48x188cm | | 1 | 2 |
| 3 | 39x182.6cm | | 1 | 2 |
| 4 | 38.7x181.6cm | | 1 | 2 |
| 5 | 76x182.6cm | | 1 | 3 |
| 6 | 46.5x37cm | | 1 | 3 |
| 7 | 46.5x37cm | | 4 | 3 |
| 8 | 46.5x182cm | W. | 1 | 3 |
| 9 | 50x117cm | | 1 | 4 |
| 10 | 38.7x95cm | | 2 | 4 |
| 11 | 6.5x114cm | | 2 | 4 |


| parts. | | | | | | |
|--------|-------------|--------|-----|-----|--|--|
| Ref | Dimensions | Visual | Qty | Ctn | | |
| 12 | 46.5x75cm | | 1 | 1 | | |
| 13 | 77.7x28.5cm | | 3 | 1 | | |
| 14 | 70x16cm | | 3 | 1 | | |
| 15 | 6.5x75cm | | 2 | 1 | | |
| 16 | 71x35cm | | 3 | 1 | | |
| 17 | 35x16cm | 1: | 3 | 1 | | |
| 18 | 35x16cm | | 3 | 1 | | |
| 19 | 3.1x20cm | | 6 | 1 | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |




TITUS TIGHTENING INSTRUCTIONS




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.



Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.



The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)


Next Retail Ltd, Desford Road, Enderby, Leicester, LE19 4AT

FLYNN WARDROBE 3 DOORS AND 3 DRAWERS

F41152 Assembly instructions

Fixtures and fittings supplied (actual size)

| supplied (actual size) | | | | |
|------------------------|-------------|----------|--|--|
| Ref | Dimensions | Quantity | | |
| А | 8 x 36mm | 34 | | |
| В | 15 x 12.5mm | 22 | | |
| С | 15 x 10.5mm | 12 | | |
| D | 8 x 30mm | 36 | | |
| Е | 3.5 x 15mm | 34 | | |
| F | 6.3 x 11mm | 12 | | |
| G | 4 x 30mm | 24 | | |
| Н | Ø10 x 1.5mm | 5 | | |
| J | Ø5 x 15mm | 4 | | |
| K | 1,5 x 25mm | 10 | | |
| М | 20 x 12.5mm | 16 | | |
| N | 9 x 17mm | 16 | | |



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS

F41152 Assembly instructions

Fixtures and fittings supplied (not to scale)

| Ref | | Visual | Qty |
|-----|------------|--------|-----|
| Р | N/A | | 6 |
| Q | N/A | Sept. | 18 |
| R | 76x32x15mm | | 2 |
| S | N/A | | 2 |
| Т | N/A | | 4 |
| U | N/A | | 1 |
| V | N/A | (e e | 2 |
| W | Ø25×746mm | | 1 |
| X | N/A | | 1 |

Fixtures and fittings supplied (not to scale)


| Ref | Dimensions | Visual | Qty |
|-----|------------|--------|-----|
| Y1 | N/A | | 3 |
| Y2 | N/A | | 3 |
| X1 | N/A | | 7 |
| X2 | N/A | | 7 |

Fixtures and fittings supplied (actual size)


| Ref | Dimensions | Quantity | |
|-----|------------|----------|--|
| Е | 3.5 x 15mm | 14 | |




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152 Assembly instructions




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152 Assembly instructions

x3 Q N/A 6 8 19 G G 4 x 30mm


FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152 Assembly instructions




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS


F41152 Assembly instructions




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152 Assembly instructions




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS


F41152 Assembly instructions 23




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS

F41152

Assembly instructions

35

Warning


For floor standing units intended to be attached to the building: WARNING In order to prevent overturning this product must be used with the wall attachment device provided.


Move unit into desired position. Secure the "L" metal bracket to the wall with an appropriate screw and wall plug for your wall type (not provided).

Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type.

If in doubt please consult a qualified trades person.







Wall fixing - if in doubt seek professional advice

Cavity wall Wood **Brick or Masonry** If fixing to wood Use an appropriate Special toggle make su re that it wall plug provided you wall pluas are ## isn't chipboard as are sure your wall is needed. Seek screws can easily expert advice. pull away from the core structure Ε auu f 3.5 x 15mm 2 J Ø5 x 15mm not supplied R 2 76x32x15mm


FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152




FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152

Assembly instructions


41


HINGE ADJUSTMENT INSTRUCTIONS



a: Height adjustment Loosen screws 'A' on fixing


plates and move door up or down as required. Retighten screws 'A'.






b: Forward or backwards adjustment

Loosen screw 'B' on fixing plate and move Door in or out as required. Retighten screw 'B'.







c: Sideways adjustment

To move Door 'OUT' at hinge position, slacken screw 'C'.


To move Door 'IN' at hinge position, tighten screw 'C'.






Produced in Italy for Next Retail Ltd. F41152-2025-V1

FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152



FLYNN WARDROBE 3 DOORS AND 3 DRAWERS F41152

