


NEXT

WILSON II ACCENT CHAIR

Assembly instructions

Actual product size

H94xW77xD78CM



Item number	Fabric name-Leg	Fabric composition
N57549	Soft Velvet Fuschia Pink with Bronx Walnut with brushed gold tip leg	100% polyester
N57560	Multi Coloured Chenille with Oak Effect Leg with Brushed Gold Tip	100% polyester
115352	Casual Boucle Sage wth Oak Effect gold tip	100% polyester
115553	Casual Boucle Oyster with Oak Effect gold tip	100% polyester
E13264	Soft Velvet Burnt Orange with Walnut Effect brushed gold tip	100% polyester
F66224	Broken Geo Chenille Ochre, Pink & Blue with Oak leg with a gold cap	100% polyester
F80737	Opulent Velvet Leopard with Black leg with a gold cap	100% polyester
H20242	Soft Velvet Cranberry Red with Dark Bronx Oak Effect with gold cap	100% polyester

IMPORTANT RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly instructions
Missing or damaged parts

CALL: 0333 777 8999

WILSON II ACCENT CHAIR

Assembly instructions

BEFORE YOU START

Number of people required to assemble

One people are required to assemble this item

Time to assemble: 15 minutes



Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly. Ensure the product is fully assembled as illustrated and all fixings fully tightened before use. Check fixings regularly to ensure they remain tight. Always wipe dry after cleaning.

For the PU chairs, please lightly brush clean or lightly wipe with a slightly dampened cloth. Keep away from strong heat sources. Occasional overall cleaning should be carried out approximately once a month by using a slightly damp-ened soft cloth. Then buff with a dry clean soft cloth.

Don'ts

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.

Do not stand or lean back on your chairs.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the lacquer finish.

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Warnings

We suggest you retain these instructions for future reference. Keep fittings out of children's reach and keep children well away from construction area. This product should only be used on firm level ground. Please periodically check all fittings and re-tighten as necessary.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause cracking of the wood and deterioration of the colour.

Unwrap all packaging materials and place the components top of the carton box or on a clean floor to protect it from damage.

Home service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd,
Desford Road,
Leicester
Le194 AT


To view our full furniture range
please visit www.next.co.uk

Need Help?

With: Assembly instructions
Missing or damaged parts
CALL: 0333 777 8999

WILSON II ACCENT CHAIR
Assembly instructions

GETTING TO KNOW YOUR PRODUCT



Components supplied. Please use this guide if you require replacement parts.


Ref	Dimension	Visual	Qty
1	Seat: D78xW77xH73CM		1
2	Front Legs: 21x5.5x3.5CM		2
3	Back Legs: 21x5.5x3.5CM		2

WILSON II ACCENT CHAIR

Assembly instructions

Fixtures and fittings
supplied (actual size)


Ref	Dimension	Qty	Spare
A	M6x25mm	16	2
B	M6x80mm	1	0



WILSON II ACCENT CHAIR

Assembly instructions

1



WARNING!

Open the bottom of the chair and take the legs out.


2

Ax16




M6x25mm

Bx1




M6x80mm



WILSON II ACCENT CHAIR


Assembly instructions

3



In the end , zip up the non-woven cloth underneath the seat.

4



Then adjust balance of this chair,
tighten all the screws to 100%.

NEXT

WILSON II ACCENT CHAIR

Assembly instructions

Actual product size

H94xW77xD78CM

CAUTION: Maxium weight capacity of this chair is 130kg.

