


NEXT

REMI ELEGANT CHIC CHAIR W72736

Assembly instructions

Actual product size
H78.5×W58.5×D60cm




Need Help ?

With: Assembly instruction
Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT - RETAIN FOR FUTURE REFERENCE

GETTING TO KNOW YOUR PRODUCT



Components supplied. Please use this guide if you require replacement parts.

Ref	Dimension	Visual	Qty
1	Seat: H46xW58.5xD58.5CM		1
2	Front Legs: 42x4.6x2.6CM		2
3	Back left Legs: 59.5x4.7x2.5CM		1
4	Back right Legs: 59.5x4.7x2.5CM		1


REMI ELEGENT CHIC CHAIR W72736

Assembly instructions

Fixtures and fittings
supplied (actual size)

Ref	Dimension	Qty	Spare
A	M8 x 55mm	4	1
B	M8 x 60mm	4	1
C	12mm	8	1
D	22mm	8	1
E	8 x 85mm	1	0

mm 10 20 30 40 50 60 70 80 90 100 110 120 130




REMI ELEGANT CHIC CHAIR

W72736

Assembly instructions

1.




WARNING!


Open the bottom of the chair and take the legs out.


2.

A x 4	M8x55mm
	
C x 4	12mm
	
D x 4	22mm
	
E x 1	8x85mm
	



3.


B x 4	M8x60mm
	
C x 4	12mm
	
D x 4	22mm
	
E x 1	8x85mm
	



REMI ELEGENT CHIC CHAIR
W72736


Assembly instructions

4.



Then adjust balance of this chair
tighten all the screws to 100%.

5.



In the end , zip up the non-woven
cloth underneath the seat.

NEXT

REMI ELEGENT CHIC CHAIR W72736

Assembly instructions

Actual product size
H78.5×W58.5×D60cm

CAUTION: Maximum weight capacity of this chair is 130kg.

