


NEXT

AIRE CHAIR G31618/W12268

Assembly instructions

Actual product size
H74.7× W66× D59.5cm



Need Help ?

With: Assembly instruction
Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT - RETAIN FOR FUTURE REFERENCE

BEFORE YOU START

Number of people required to assemble

One person is required

Time to assemble: 15 minutes



Item No.	Fabric name - leg	Fabric composition
G31618	Opulent Chenille Light Camel Brown	100% polyester
W12268	CANNA-449A-Relaxed Chenille Chocolate	100% polyester

Do's

Before Use

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly

Upholstered products only – When your new product arrives, you may notice that some of the cushions or upholstered areas may have been creased or squashed during transit. This can be simply corrected by gently patting the area back into shape to re-distribute the filling and reshape the cover.

Don'ts

Do not stand or lean back on your furniture.

Avoid sharp objects such as toys, buckles, jewellery and pets to prevent fabric snagging.

Missing parts

If you are missing any fixtures and fittings for your product.. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Warnings

Always retain these instructions for future reference

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Periodically check all fittings, where applicable, and re-tighten as necessary

Avoid exposure to direct and prolonged periods of sunlight, as colours might fade in the sun.

Protect your upholstered furniture by drawing the curtains or blinds when you go out.

Do not position upholstery close to sources of intense heat, such as radiators.

Do not stand or jump on your furniture.

Avoid sitting on arms or edges which may cause distortion or damage the frame.

Dye transfer from garments and other soft furnishings such as denims and similar dark fabrics can't be removed.

Avoid allowing pets on upholstered products as their claws may cause damage to the leather or fabric. Checks, Stripes and Patterns – We do all we can to match fabrics wherever possible on our products, but it's not always feasible in production. Images online and in any promotional material are for guidance only and the finished products may vary slightly.

Home Service Technicians

If you have a fault with your product, please contact our customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range
please visit www.next.co.uk

Need Help ?

With: Assembly instruction
Missing or damaged parts

CALL: 0333 777 8999

Cleaning

To clean wooden or metal components, please use a soft cloth slightly dampened with water and wipe clean. Then buff with a dry clean cloth.

Vacuum lightly, or use a soft brush on a regular basis. Accumulated dirt will accelerate wear and dull the colours.

Cleaning spills

Act promptly. Carefully soak up any liquid spillages by blotting with a clean, dry, absorbent cloth. Stains can then be removed mostly by using water, but stubborn stains may need a mild household detergent.

Don't use stain remover without testing it on a swatch first.

For any solid spillages use a teaspoon or flat utensil to remove the solid from the surface and follow the same practice as for liquid to remove the stain residue.

Repeat the process until the stain is removed and allow to air dry.

Clean cushions in situ only. Do not remove cushion covers to clean.

DO NOT WASH COVERS USING A WASHING MACHINE.

Clean all parts of the sofa at the same time.

For more stubborn stains contact a professional cleaner

Velvet, Chenille and Pile Fabrics – These are wonderfully durable fabrics. However, they are prone to pile crushing, indentation marks and colour shading variation depending on the pile direction. Thankfully, getting them back to their original appearance is easy. Just softly brush the pile in the opposite direction to the nap.

Wool and Wool Effect – Pilling and bobbling are natural characteristics of these fabrics and can't be avoided. But they can be managed. To reduce or remove minor pilling, use a soft brush or a fabric pill remover.

Flat Weaves – Durable and tightly constructed, these fabrics often feel a little stiff to begin with. Don't worry. They'll loosen up with time and use. To speed up the process, use a soft brush or vacuum to buff and soften the fabric. For faux leather upholstered seating


For faux leather upholstered seating.

Faux Leathers – Faux leather should be cleaned by lightly brushing or lightly wiping with a slightly dampened cloth. Do not spot clean with upholstery cleaner, as this can damage the surface of the material.


Occasional overall cleaning of faux leathers should be carried out approximately once a month by using a slightly dampened soft cloth; then buff with a dry clean soft cloth

Over time the faux leather material will flatten on areas most used, producing some shading.

GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts.



Ref	Dimension	Visual	Qty	Ref	Dimension	Visual	Qty
1	Front Left Leg: 57.8 x 10 x 3.8CM		1	5	Connecting piece: 52 x 1.6 x 1.6CM		4
2	Front Right Leg: 57.8 x 10 x 3.8CM		1	6	Cushion: 50.5 x 53 x 15CM		1
3	Rear Left Leg: 57.8 x 10 x 3.8CM		1	7	Backrest: 55 x 66 x 17CM		1
4	Rear Right Leg: 57.8 x 10 x 3.8CM		1				

Fixtures and fittings
supplied (actual size)



Ref	Dimension	Qty	Spare
A	M6 x 18 mm	8	1
B	M6 x 20mm	8	1
C	M6 x 8mm	4	1
D	4 x 55mm	1	0
E	3 x 57mm	1	0





1.




2.





3.




4.



5.



6.



NEXT

AIRE CHAIR
G31618/W12268
Assembly instructions

G31618/W12268

AIRE CHAIR

Assembly instructions

Actual product size

H74.7×W66×D59.5cm

