

THE BRITISH HOME STORE



This product should be disposed of responsibly at the end of its life. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice (Waste Electrical and Electronic Equipment Directive)

**HELPLINE**

If you receive this item with parts broken or missing, please telephone:

0333 0050070

Please have ready your name, address, tel. no., product reference, where purchased and parts required. An answering service is in operation outside office hours and during busy periods.

We regret that we are unable to give advice on internal house wiring.

BHS, Gorse Mill, Gorse Street, Oldham, OL9 9RJ

[www.cascadehl.com/#contact](http://www.cascadehl.com/#contact)



EU AUTHORISED REPRESENTATIVE:  
AUTHORISED REP COMPLIANCE  
GROUND FLOOR  
71 LOWER BAGGOT STREET  
DUBLIN  
IRELAND  
D02 P593



[www.authorisedrepcompliance.com](http://www.authorisedrepcompliance.com)

**BHS**  
BRITISHHOMESTORE  
LONDON 1928

Eero Pendant  
39002593  
User Instructions

Please take time to read this leaflet carefully  
and retain it for future reference.

## SAFETY AND CARE ADVICE

For your safety, this product must be installed in accordance with local building regulations. If in any doubt, or where required by law, consult a competent person who is registered with an electrical self-certification scheme. Further information is available online or from your local authority.

This product has been designed for non-professional, domestic use only.

Dispose of all packaging components correctly and responsibly and in accordance with all local laws and regulations. Never leave packaging components within reach of children, as they can be a source of danger.

Before inserting or replacing a bulb, ensure the power is switched off and the bulb has cooled down.

Do not modify any product before or after installation. This may render the product unsafe.

This is a Class 1 product and does require an earth connection.

This fitting must be permanently wired to the electric system.

Always shut off the power to the circuit before starting installation.

## WARNINGS

This product is not intended for use by persons (including children) with reduced physical, sensory and mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the product by persons responsible for their safety.

Children should be supervised to ensure that they do not play with the product.

Do not place this fitting in a damp atmosphere.

## CARE AND MAINTENANCE

Always disconnect the power supply when servicing or cleaning.

Use a clean, soft, dry or slightly damp cloth for cleaning this product.

Do not use abrasive cloths or polishes, as this may cause damage to the product.

## NON-REPLACEABLE BULBS

This ceiling light is fitted with non-replaceable LED bulbs.  
Input: AC220 - 240V ~ 50Hz (This item has 33W Integrated LEDs)

## PARTS LIST

Pendant light x 1  
Mounting screws x 2  
Wall plugs x 2

## FIXING INSTRUCTIONS

This fitting must be connected to the supply earth. If your lighting circuit does not have an earth, ask a qualified electrician to provide an earth facility. Make sure that there is a joist or other solid mounting at the point of fixing. This is necessary to take the weight of the fitting.

Earthed items (Class 1): These are marked with this symbol: 


## ASSEMBLY

It is possible to adjust the drop of this fitting by following the diagrams below.

Re-adjust the suspension cable to the desired height.

Make sure the fitting is hung using the suspension wire.


Please keep all suspension wires the same length.



**To raise:** Push the wire up through the ceiling cup to the desired height.  
**To lower:** Press the wire grip into the housing to release the wire. Once at the desired height release the wire grip.  
**Coil excess wire inside the ceiling cup.**


**Step 1** Taking care not to damage any house wiring, detach the mounting strap from the fitting and affix to the ceiling using the screws supplied.

These screws should penetrate the joist by at least 2cm.



**Step 2** Using the connector block supplied, connect the wires as shown on the diagram shown right.

Check that you have correctly identified the house wires, that all connections are tight and that no loose strands have been left out of the connection blocks.



L (Live) = Brown  
N (Neutral) = Blue

 = Green/Yellow

**Step 3** Offer the ceiling cup up to the mounting strap and secure in place using the screws/washers.

**Step 4** This ceiling light is fitted with non-replaceable LED bulbs.  
Input: AC220 - 240V ~ 50Hz (This item has 33W Integrated LEDs)