

HALO ROUND SOLAR WALL LIGHT


USER GUIDE



Ensure your solar panel is South facing or as near as possible



Clean your solar panel from time to time



Do NOT place your solar panel in shaded areas



Do NOT charge behind glass

Thank you for choosing the Halo Solar Wall Light. Please read these instructions carefully before using your light.

Important notes

Always take care when installing your light. If you are at all unsure, please contact your retailer or a professional trades person for advice.

Installation

Remove all packaging and put to one side. Please carefully consider where you wish to install your light before making alterations to your property. It's particularly important that the solar panel receives as much sunlight as possible. Ensure that it is not obstructed by buildings, fences, trees, sheds, etc. or the shadows that these create. **If the solar panel is installed in a poor location, it may not perform to the best of its ability.**

To maximise the battery capacity, the light should be charged in direct sunlight for at least 10 - 12 hours before being used for the first time.

The light will turn ON/OFF automatically when left in the on position. Please note it is completely normal for the light to come on at different times as it depends on how fast it charges in their location.

How to Use

There is an ON/OFF button located at the back of the light. Push the button to the 'ON' position and place the light in a sunny location. **Please note there is a timer on the light and it will automatically turn off after 7 hours.**

This light features a USB-C charging port located on the top of the back fixture. To give your light an extra boost charge, bring your light inside and charge using a USB-C cable.

Lighting Modes

This light features power-saving mode which is the best for winter to double run times. Please follow the instructions below:

First press: Warm white colour at 100% brightness

Second press: Warm White colour at 50% brightness

Third press: Cool white colour at 100% brightness

Fourth press: Cool white colour at 50% brightness

Replacing the batteries

If the light has stopped working after it has been used for a long time, the battery may be beyond its life span (approximately 2-3 years). You may open the cover to change a new rechargeable battery.

The lifetime of the LED lights are over 100,000 hours and should never need changing.

Troubleshooting

Please ensure that there are no nearby light sources shining on the solar panel after dark. These could be bright indoor/outdoor lights from your property or neighbours, or streetlights.

If you are unsure, take the light inside and test it in a dark room.

If you are encountering any problems with your light often you can resolve this yourself by following our troubleshooting guide. If the light has its solar panel in a poor location it will struggle to work, but that doesn't mean there is a fault with the unit. Please remember that the light will arrive with some charge and will likely work for a few days even if the solar panel is poorly located. Please try the troubleshooting tips below before contacting your retailer.

Recharge Procedure

1. Double check the location of your solar panel to ensure it is in a clear location and as South facing as possible.
2. Turn the light off at the switch and leave it to recharge for 3-5 days ensuring one sunny day has passed.
3. After 3-5 days return to the light and turn it back on at the switch.
4. If your light still does not illuminate after dark, please contact your retailer.

Maintenance

Clean the surface of the solar panel and light lens with a soft, slightly moistened cloth. Do not use corrosive cleansing agents or chemical solutions as these may damage surfaces and impair operation. Keep the solar panel free of dirt, debris and snow.

Safety Instructions

The Solar Centre assumes no liability for any damage resulting from the use of this product, nor do we assume liability for any damage to property or personal injury caused by improper use or failure to observe these instructions.

Unauthorised conversion and/or modification of the unit may be dangerous and will invalidate your warranty. To avoid damage to sight, do not look directly at the light source. This device is not a toy and should be kept out of reach of children. Do not submerge the device in water or expose it to extreme temperatures (less than -25°C or higher than 50°C).

HALO ROUND SOLAR WALL LIGHT

MODEL NUMBER: SC2433

**SOLARCENTRE®
44-46 COLDHARBOUR LANE
HARPENDEN
HERTFORDSHIRE
AL5 4UN**

WWW.SOLARCENTRE.CO.UK

