# NEXT

### HAMPTON XL DRESSING AN3016, H19238

Assembly instructions

Actual product size H78.2 x W200 x D45 cm



## Need Help?

With: Assembly instruction Missing or damaged parts

CALL: 0333 777 8999

#### **IMPORTANT - RETAIN FOR FUTURE REFERENCE**

## HAMPTON XL DRESSING AN3016, H19238

#### Assembly instructions

#### **BEFORE YOU START**

Number of people required to assemble Two people are required to assemble this item Time to assemble: 15 minutes







#### Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use. Installation shall be carried out exactly according to the manufacturers instructions-otherwise a safety risk can occur if incorrectly installed.

#### Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish. Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to delaminate. Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster.

#### Missing parts

If you are missing any fixtures and fittings for your product, please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

PRODUCT SUPPLIED WITH WALL FIXING WALL STRAPS
IMPORTANT - RETAIN FOR FUTURE REFERENCE

#### Warnings

We suggest you retain these instructions for future reference. Keep fittings out of children's reach and keep children well away from construction area. This product should only be used on firm level ground. Please periodically check all fittings and retighten as necessary. Please do not sit or stand on your furniture. Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour. Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

#### **Home Service Technicians**

If you hove a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

#### You can write to us at

Home Customer Services Next Retail Ltd. Desford Road, Leicester, LE19 4AT


To view our full furniture range please visit **www.next.co.uk** 

## Need Help?

With: Assembly instruction Missing or damaged parts

CALL: 0333 777 8999

## **GETTING TO KNOW YOUR PRODUCT**




### **GETTING TO KNOW YOUR PRODUCT**

Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	200x45cm		1	1
2	64x35cm		1	1
3	63.6x35.9cm		1	1
4	75.7x69.9cm		1	2
5	75.7x69.9cm		1	3

supplied (actual size)  Ref Dimensions Qty  A Ø18mm 9  B 2.5x16mm 6	Fixtures and fittings supplied (actual size)		mm 1	0 2	0 <u>з</u>	0 4	0 5	60 G	0 7	0 8	0 9	0 10	00 1 <sup>2</sup>	10 12	20 1:	30	
	Ref	Dimensions	Qty														
B 2.5x16mm 6	А	Ø18mm	9				 	 	 	 	 	 		1 1 1 1 1 1 1 1	 	 	 
	В	2.5x16mm	6			 		 	 		 		 			 	 


### TITUS TIGHTENING INSTRUCTIONS




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.




Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.




The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)







### HAMPTON XL DRESSING AN3016, H19238


Assembly instructions






























**WARNING:** In order to prevent overturning this product must be used with the wall attachment

provided. Wall fixings are not included please source suitable fixings for your wall type. If in doubt, please consult a qualified tradesperson. WARNING: Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.

