

# NEXT

## FLORANCE BISTRO


Assembly instructions

Actual product size

Coffee Table: H27 x W60 x D60 cm

Single sofa: H81 x W80 x D80 cm

Single sofa: H81 x W80 x D80 cm



Item	Colour	Fabric
H39976	Boucle beige	100% Polyester

### Need Help ?

With: Assembly instruction

Missing or damaged parts

CALL: 0333 777 8999

**IMPORTANT - RETAIN FOR FUTURE REFERENCE**

# FLORANCE BISTRO


## Assembly instructions

### BEFORE YOU START

Number of people required to assemble

Two people are required to assemble this item

Time to assemble: 45 minutes



### Warnings

This product is for domestic and outdoor use only. We suggest you retain these instructions for future reference.

Keep fittings out of children's reach. Keep children away when constructing your furniture.

This product should only be used on firm level ground.

Do not sit on the table.

Do not jump or stand on the product.

### Do's

Do spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space. Due to the size of the product we recommend that it is assembled in the location intended for final use.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect any fabrics and surfaces during assembly.

Before beginning assembly carefully check that you have all the parts and fixings. Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.

Please retain the assembly tools. You will need them in the future to re-tighten the bolts, or if you want to dismantle the furniture for storage.

Please make sure that the product is clean and dry before putting it into storage.

### Do not

Do not position your product close to sources of intense heat, such as barbecues or patio heaters.

Do not sit on arms or the back of seating which may cause distortion or damage the frame.

Do not wash covers in a washing machine.

Do not use a jet or pressure washer to clean your furniture.

Avoid allowing pets on upholstered products as their claws may cause damage to the leather or fabric.

### Care & Maintenance

Check fixings regularly to ensure they remain tight.

Lift the assembled product when moving it; do not drag it as this can cause damage.

The frame of this product is suitable for all year outdoor use. It is however still recommended to cover products when not in use for long periods to keep it clean.

Cushions are resistant to light summer showers, the water resistant covers will prevent the fillings from getting wet.

However in heavy showers or long periods of wet weather they should be taken indoors or stored in a shed, garage or cushion box. Take cushions in at night or when it's raining as the dampness will cause mould to grow.

Fabrics have been tested for outdoor suitability; even so, please be aware that, over time, fabrics may fade a little after exposure to direct sunlight for long periods.

Regularly plump cushions to maintain their shape.

### Cleaning

Regularly clean with a vacuum cleaner or lightly brush with a soft bristled brush.

Covers should be cleaned with a damp soapy cloth or sponge. Soak up any spillages quickly by blotting with a clean, dry absorbent cloth.

Any remaining stains should be removed with using water, but stubborn stains may need a mild household detergent.

Solid spillages should be removed with a teaspoon or flat utensil, before following the instructions for spillages.

Repeat until the stain is removed and allow to air dry.

Clean cushions in situ only.

Do not remove cushion covers to clean. **DO NOT WASH.**

Clean all parts of the product at the same time.

For stubborn stains contact a professional cleaner.

When cleaning glass panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these substances can scratch the glass.

We recommend that the product is protected with mats & coasters when items are placed on to its surface. Never put hot dishes directly onto glass surfaces as this may mark the furniture. If the glass is chipped or broken, stop using the product and consult Next.

Do not place very hot or very cold items on the glass surface, unless adequately thick table mats are used to prevent such items from coming into contact with the glass. Do not use glass as a chopping surface. Do not strike the glass with hard or pointed items.

### Home service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

### You can write to us at

Home Customer Services  
Next Retail Ltd,  
Desford Road,  
Leicester,  
LE19 4AT

To View our full furniture range please visit [www.next.co.uk](http://www.next.co.uk)


## Need Help ?

With: Assembly instruction


Missing or damaged parts

CALL: 0333 777 8999

## GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	600x600mm		1	1
2	55x215mm		4	1

Ref	Description	Composition	Colour
1	Table top	Acacia	Teak Washed
2	Table leg	Steel frame with powder coating	Oyster


1




2




## GETTING TO KNOW YOUR PRODUCT



**Components supplied. Please use this guide if you require replacement parts.**

Ref	Dimensions	Visual	Qty	Ctn
1	694x800mm		1	2,3
2	55x200mm		4	2,3
3	640x520mm		1	2,3

Ref	Dimensions	Visual	Qty	Ctn
4	700x800mm		1	2,3
5	650x470mm		1	2,3

Fixtures and fittings  
supplied (actual size )


mm  
0 10 20 30 40 50 60 70 80 90 100 110 120

Ref	Dimensions	Qty	Spare Qty	Visual
A	M6x65mm	4	N/A	
B	M6x20mm	2	N/A	
C	Dia.16mm	6	N/A	


Fixtures and fittings supplied ( not o scale )

Ref	Dimensions	Qty	Spare Qty	Visual
D	#4	1	N/A	


Ref	Description	Composition	Colour
1	Single sofa - Frame	Steel frame with powder coating	Oyster
	Single sofa - Frame	Acacia	Teak Washed
	Single sofa - Rope	100% polyester	Off White
2	Single sofa - leg	Acacia	Teak Washed
3	Single sofa - back frame	Steel frame with powder coating	Oyster
4	Seat cushion - Fabric	100% polyester	Boucle Beige
	Seat cushion - Filling	80% Polypropylene & 20% polyester	White
5	Back cushion - Fabric	100% polyester	Boucle Beige
	Back cushion - Filling	40% Polypropylene & 60% polyester	White



3



4



# FLORANCE BISTRO

Assembly instructions

# NEXT

## FLORANCE BISTRO


Assembly instructions

Actual product size

Coffee Table: H27 x W60 x D60 cm

Single sofa: H81 x W80 x D80 cm

Single sofa: H81 x W80 x D80 cm



**IMPORTANT - RETAIN FOR FUTURE REFERENCE**