


NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions

Actual product size

H185 x W150 x D55 cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 1 hour



Tools required



Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage,
We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.
Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.



NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275

Assembly instructions

GETTING TO KNOW YOUR PRODUCT








NEXT






HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275

Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	8.5x10cm		4	1
2	53.5x148.5cm		1	2
3	5.5x8.5cm		1	1
4	49x51cm		1	1
5	53x172.5cm		1	3
6	49.5x72cm		2	2
7	51x143.5cm		1	3
8	53x172.5cm		1	3
9	51x121.5cm		1	1
10	46.5x49cm		3	1
11	51x121.5cm		1	1

Ref	Dimensions	Visual	Qty	Ctn
12	47.5x122.5cm		3	3
13	55x150cm		1	2
14	2.5x46cm		2	2
15	19x45cm		4	1
16	19x45cm		4	1
17	19.5x67cm		4	1
18	6x43.5cm		4	1
19	44x67.5cm		4	1
20	25x71.5cm		2	2
21	25x71.5cm		2	2
22	48x121cm		2	2

NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275

Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
W14	Ø8 x 30mm	1	1
S41	Ø4 x 15mm	2	1
U139	Ø4.5 x 15mm	36	2
U143	Ø4 x 15mm	12	2
Z25	Ø4 x 27mm	6	1
B8	Ø8 x 38mm	N/A	2
B2	Ø15 x 10mm	N/A	2
B3	Ø15 x 12mm	N/A	2
D3	Ø6 x 30mm	N/A	2
D6	Ø8 x 30mm	N/A	2



Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
T38	N/A	20	2	
N7	N/A	2	N/A	
T5	N/A	1	N/A	
E47	N/A	6	N/A	

Fixtures and fittings supplied (not to scale)




Ref	Dimensions	Qty	Spare Qty	Visual
C11	N/A	6	N/A	
O1	Ø21mm	46	2	
R	N/A	4	N/A	
L	N/A	4	N/A	

NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions

1



2




W14	Ø8 x 30mm	1	
T5	N/A	1	

NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions

3



4




NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions

5



6




NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions

7



8




NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions


9



10



11




NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions

12



13




NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions


14



Packing Materials

S41	Ø4 x 15mm	2	not supplied
N7	N/A	2	

15




NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE





H46506 / W53275
Assembly instructions

16



A=B

17




T38	N/A	20			<small>not supplied</small>
-----	-----	----	--	--	-----------------------------

18

We recommend the use of the wall attachment bracket/strap provided for safety reasons.
Move unit into desired position. Secure the 2X "L" metal brackets to the wall with an appropriate screw and wall plug for your wall type (not provided).




Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type.
If in doubt please consult a qualified trades person.






NEXT**HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE**
H46506 / W53275
Assembly instructions

19




R



U139	Ø4.5 x 15mm	12	
R	N/A	4	

20




U139	Ø4.5 x 15mm	12	
L	N/A	4	

NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions

21




O1	Ø21mm	30	
----	-------	----	--

NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE H46506 / W53275 Assembly instructions

22



x4

23




x4

NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE


H46506 / W53275
Assembly instructions

24




x4

25



x2






x2

NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE

H46506 / W53275
Assembly instructions




26



O1	Ø21mm	8	
Z25	Ø4 x 27mm	2	
E47	N/A	2	

x2


27




O1	Ø21mm	8	
Z25	Ø4 x 27mm	2	
E47	N/A	2	

x2


28



1. Pull runners out.
2. Pull plastic tabs inwards.



step:1.pull out runner




step:2.unlock

NEXT


HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE H46506 / W53275 Assembly instructions

29


- 3 .Place drawers on runner making sure hooks at back of runners.
- 4.Locate pin under drawer.
- 5.Lock drawer in position.




step:3.Locate




step:4.All the way



step:6.Locate adjustment pin in hole




step:5.Pull runner forward




step:7.Lock

30


6. Adjust drawer height if needed.




OK





Need to adjust as below





Anti-clockwise is up



Clockwise is down

NEXT**HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE**
H46506 / W53275
Assembly instructions**31**


U139	Ø4.5 x 15mm	12	
C11	N/A	6	

x2**32**

Z25	Ø4 x 27mm	2	
E47	N/A	2	


x2

33




Install Hinge

Step.1:Lift up the hook





Adjust Hinge Position

Step.2:Hook the hinge to the base Step.3:Press inside





Remove Hinge



NEXT

HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE H46506 / W53275 Assembly instructions


34



U143	Ø4 x 15mm	12	
------	-----------	----	--

NEXT**HUTTON NATURAL/SAGE 2 DOOR TRIPLE WARDROBE**
H46506 / W53275**Actual product size**

H185 x W150 x D55 cm



Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk