

NEXT


OSWIN STORAGE SHELF

H46963

Assembly instructions

Actual product size

H180x W93x D39cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

OSWIN STORAGE SHELF

H46963
Assembly instructions

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 60 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.
Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.


NEXT

OSWIN STORAGE SHELF

H46963

Assembly instructions

GETTING TO KNOW YOUR PRODUCT



















NEXT OSWIN STORAGE SHELF

H46963



Assembly instructions

Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	39x93cm		1	1
2	2x89cm		2	1
3	39x71cm		2	1
4	2x89cm		2	1
5	2x89cm		2	1
6	39x92.5cm		1	2
7	39x92.5cm		1	2
8	39x89cm		1	1
9	39x34.5cm		2	1
10	34x31.5cm		1	1
11	32x86.5cm		1	1
12	39x89cm		1	1
13	40x89cm		2	2

Ref	Dimensions	Visual	Qty	Ctn
14	39x93cm		1	1
15	39x90cm		1	2
16	39x90cm		1	2
17	32.5x43.5cm		2	1

NEXT FITTINGS ASSEMBLE INSTRUCTIONS



Push connector into housing to join.



Make sure there is no gap between the panels.

NEXT


OSWIN STORAGE SHELF

H46963

Assembly instructions


Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
Y29	Ø6 x 12mm	48	2
Y34	Ø6 x 25mm	10	2
S32	Ø4 x 12mm	2	1
U139	Ø4.5 x 15mm	8	1
U143	Ø4 x 15mm	8	1
D18	Ø6 x 10mm	N/A	1




Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
O1	Ø21mm	8	N/A	
C12	N/A	4	N/A	
N7	N/A	2	N/A	
T6	N/A	2	N/A	
T38	N/A	6	1	
T10	N/A	1	N/A	



Direction Switch
 ← Left: Clockwise (Tighten)
 → Right: Counterclockwise (Loosen)



Operation
 Swing handle within 15°-30° arc using ratchet mechanism.


NEXT


OSWIN STORAGE SHELF

H46963


Assembly instructions

1



Y34	Ø6 x 25mm	4	
N7	N/A	2	
S32	Ø4 x 12mm	2	  not supplied

2




Y29	Ø6 x 12mm	8	
-----	-----------	---	---

NEXT OSWIN STORAGE SHELF

H46963
Assembly instructions


3



Do not tighten the screws.

Y29	Ø6 x 12mm	7	
-----	-----------	---	---

4



Please tighten all the screws.

T10	N/A	1	
T6	N/A	2	
Y29	Ø6 x 12mm	7	


NEXT

OSWIN STORAGE SHELF

H46963

Assembly instructions


5



T10	N/A	1	
T6	N/A	2	
Y34	Ø6 x 25mm	2	

Please tighten all the screws.

6



Packing materials

T6	N/A	2	
----	-----	---	--


NEXT

OSWIN STORAGE SHELF





H46963

Assembly instructions

7



8



T6

N/A

2




NEXT

OSWIN STORAGE SHELF


H46963

Assembly instructions

9



10




Do not tighten the screws.

Y29	Ø6 x 12mm	2	
-----	-----------	---	---

NEXT OSWIN STORAGE SHELF

H46963
Assembly instructions

11



Y29


Ø6 x 12mm

2



Do not tighten the screws.

12



Y29

Ø6 x 12mm

4



Do not tighten the screws.


NEXT

OSWIN STORAGE SHELF

H46963

Assembly instructions


13




T10	N/A	1	
T6	N/A	2	
Y29	Ø6 x 12mm	10	

Please tighten all the screws.

14



T10	N/A	1	
T6	N/A	2	
Y34	Ø6 x 25mm	4	


NEXT

OSWIN STORAGE SHELF

H46963

Assembly instructions

15



T10	N/A	1	
T6	N/A	2	
Y29	Ø6 x 12mm	8	


NEXT

OSWIN STORAGE SHELF

H46963

Assembly instructions


16



NEXT OSWIN STORAGE SHELF

H46963
Assembly instructions

17



T38

N/A

6



NEXT OSWIN STORAGE SHELF




H46963
Assembly instructions

18

We recommend the use of the wall attachment bracket/strap provided for safety reasons. Move unit into desired position. Secure the 2X"L" metal brackets to the wall with an appropriate screw and wall plug for your wall type (not provided).

Warning: Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type. If in doubt please consult a qualified trades person.




O1	Ø21mm	8	
----	-------	---	--

NEXT OSWIN STORAGE SHELF

H46963
Assembly instructions

19



U139	Ø4.5 x 15mm	8		 not supplied
C12	N/A	4		


NEXT

OSWIN STORAGE SHELF

H46963


Assembly instructions

20




Install Hinge


Step.1:Lift up the hook




Step.2:Hook the hinge to the base




Step.3:Press inside



Remove Hinge



Adjust Hinge Position





NEXT

OSWIN STORAGE SHELF

H46963

Assembly instructions

21



U143	Ø4 x 15mm	8		 not supplied
------	-----------	---	---	---

NEXT


OSWIN STORAGE SHELF

H46963

Assembly instructions

22


To disassemble:



NEXT OSWIN STORAGE SHELF

H46963

Actual product size
H180x W93x D39cm



NEXT

OSWIN STORAGE SHELF H46963

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk