

NEXT


MARLOW/MARLOW BLACK EXTRA LARGE STORAGE COFFEE TABLE

H79758 / V15138

Assembly instructions

Actual product size

H40.5 x W100 x D100 cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage,
We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.



Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.
Absorption can cause wood to warp or finishes to de-laminate.












Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

GETTING TO KNOW YOUR PRODUCT




X2


Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	34x99.5cm		2	2
2	8x91cm		2	2
3	36.5x96.5cm		1	2
4	96x96.5cm		1	1
5	6x97cm		2	2
6	22.5x92cm		2	1
7	22x40cm		2	1
8	22x40cm		2	1
9	6x38cm		4	1
10	38.5x93cm		2	1
11	34x99.5cm		2	2

NEXT FITTINGS ASSEMBLE INSTRUCTIONS




Push connector into housing to join.



Make sure there is no gap between the panels.

**Fixtures and fittings
supplied (actual size)**

Ref	Dimensions	Qty	Spare Qty
B12	Ø7.5 x 33mm	12	2
B3	Ø15 x 12mm	12	2
U139	Ø4.5 x 15mm	12	2
V53	Ø6 x 30mm	8	1
B8	Ø8 x 38mm	N/A	1
D6	Ø8 x 30mm	N/A	2







Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
R	N/A	2	N/A	
L	N/A	2	N/A	
T1	N/A	2	N/A	


1

Packing Materials



X2

U139	Ø4.5 x 15mm	12	 not supplied	
R	N/A	2		
L	N/A	2		


2





X2

B12	Ø7.5 x 33mm	8	  not supplied
-----	-------------	---	---


3



X2

T1	N/A	2	
V53	Ø6 x 30mm	8	

4



WHEN LOOSENING THE CAM

TURN THE CAM IN A COUNTERCLOCKWISE DIRECTION UNTIL THE ARROW POINTS IN THE POSITION SHOWN IN THE DIAGRAMS BELOW




MAXIMUM
LOCK




TURN
TO UNLOCK



UNLOCKED



5



B3


Ø15 x 12mm

4



not supplied

6




B3

Ø15 x 12mm

4



7




X2


B12


Ø7.5 x 33mm

4




8




B3	Ø15 x 12mm	4		 not supplied
----	------------	---	---	---

9




10



SLOTS ALIGNED


X2

11




X2

12



X2


13



X2


14

Note: Drawer will be permanently assembled once panel 11 is fitted.




X2



15



1. Pull runners out.
2. Pull plastic tabs inwards.




step:1.pull out runner




step:2.unlock

16


- 3 .Place drawers on runner making sure hooks at back of runners.
4. Locate pin under drawer.
5. Lock drawer in position.




step:3.Locate




step:4.All the way



step:6.Locate adjustment pin in hole




step:5.Pull runner forward




step:7.Lock

17


6. Adjust drawer height if needed.




OK



Need to adjust as below



Anti-clockwise is up




Clockwise is down

NEXT

MARLOW/MARLOW BLACK EXTRA LARGE STORAGE COFFEE TABLE H79758 / V15138

Actual product size

H40.5 x W100 x D100 cm



Produced in China for Next Retail Ltd.
H79758 / V15138-2025-V1.

NEXT

MARLOW/MARLOW BLACK EXTRA LARGE STORAGE COFFEE TABLE H79758 / V15138

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk