

NEXT


CURTIS BENCH

Q78254/Q78256

Assembly instructions

Actual product size

W43.5cm X L125cm X H49cm



Fabric content

Q78254-100% polyester

Q78256-100% polyester

IMPORTANT - RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly Instructions

Missing or damaged parts

CALL: 0333 777 8999

Assembly instructions

BEFORE YOU START**Warnings**

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools, plenty of space.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Unwrap all packaging materials and place the components on a clean surface to protect them from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use. Check fixings regularly to ensure they remain tight.

When moving your assembled stool. It is best to lift the chair and never to drag it.

Never allow any kind of liquid to remain on your furniture. Absorption can cause materials to warp or finishes to de-laminate.

To clean your item, please use a vacuum or lightly brush clean.

Don'ts

Do not tighten screws until fully assembled.

Do not over tighten screws or bolts.

Do not drag or pull your furniture.

Do not use this product if parts are missing, damaged or worn.

Never use scourers, abrasives or chemical cleaners.

Number of people required to assemble

Two people are required to assemble this item

**Time to assemble****Missing parts**

If you are missing any fixtures and fittings for your product please contact our customer service team on **0333 777 8999** and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement,

home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair. If you have a fault with your product please contact our

You can write to us at


Home Customer Services
Next Retail Ltd,
Desford Road,
Leicester,
LE19 4AT,

To view our full furniture range please visit www.next.co.uk


NEXT


CURTIS BENCH
Q78254/Q78256

Assembly instructions



Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	Bench		1	1

Ref	Dimensions	Visual	Qty	Ctn
2	Feet		2	1


NEXT

CURTIS BENCH

Q78254/Q78256

Assembly instructions

Ref	Dimensions	Qty
A	M8x25	16
B	M8x19	16
C	M8	16
D	M5	1



NEXT

CURTIS BENCH

Q78254/Q78256

Assembly instructions

1

Diagram 1 illustrates the assembly of the Curtis Bench frame. The top part shows a perspective view of the frame with two vertical legs (2) and two horizontal rails (1). The bottom part is a circular inset showing a close-up of the corner joint where the legs and rails meet. In this inset, a horizontal rail (1) is being attached to a vertical leg (2) using four screws (Ax16) and four washers (Bx16). The screws are labeled A, B, C, and D. A hex key (Dx1) is shown inserted into the corner of the joint.


Ax16 M8x25mm 	Bx16 M8x19mm 	Cx16 M8 	Dx1 M5
-------------------------	-------------------------	--------------------	-------------------

NEXT

CURTIS BENCH

Q78254/Q78256

Assembly instructions




NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254 Assembly instructions


Actual product size

H76x W150x D100cm

DINING TABLE



SET ITEM: Q78254



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254 Assembly instructions

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage,
We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.


Never allow any kind of liquid to remain on your furniture.
Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254 Assembly instructions



GETTING TO KNOW YOUR PRODUCT



NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254 Assembly instructions

Components supplied. Please use this guide if you require replacement parts.


Ref	Dimensions	Visual	Qty	Ctn
1	100x150cm		1	1
2	72.5x80.5cm		2	1

NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254 Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
W23	Ø8 x 40mm	16	2




Fixtures and fittings supplied (not to scale)



Ref	Dimensions	Qty	Spare Qty	Visual
T5	N/A	2	N/A	

NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254 Assembly instructions

1




T5	N/A	2	
W23	Ø8 x 40mm	16	

NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254 Assembly instructions

2




NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254

Actual product size

H76x W150x D100cm



NEXT

CURTIS DINING TABLE WITH MONZA FAUX LEATHER DK GREY BENCHES LEFT Q78254

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk

NEXT


CURTIS SOFA

Q78256

Assembly instructions

Actual product size

W227cm X L180cm X H85cm



Fabric content

Q78256-100% polyester

IMPORTANT - RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly Instructions

Missing or damaged parts

CALL: 0333 777 8999

Assembly instructions

BEFORE YOU START**Warnings**

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools, plenty of space.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Unwrap all packaging materials and place the components on a clean surface to protect them from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use. Check fixings regularly to ensure they remain tight.

When moving your assembled stool. It is best to lift the chair and never to drag it.

Never allow any kind of liquid to remain on your furniture. Absorption can cause materials to warp or finishes to de-laminate.

To clean your item, please use a vacuum or lightly brush clean.

Don'ts

Do not tighten screws until fully assembled.

Do not over tighten screws or bolts.

Do not drag or pull your furniture.

Do not use this product if parts are missing, damaged or worn.

Never use scourers, abrasives or chemical cleaners.

Number of people required to assemble

Two people are required to assemble this item

**Time to assemble****Missing parts**

If you are missing any fixtures and fittings for your product please contact our customer service team on **0333 777 8999** and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement,

home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair. If you have a fault with your product please contact our

You can write to us at


Home Customer Services
Next Retail Ltd,
Desford Road,
Leicester,
LE19 4AT,

To view our full furniture range please visit www.next.co.uk

NEXT

CURTIS SOFA
Q78256

Assembly instructions



Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	Left side		1	1
2	Right side		1	1


Ref	Dimensions	Visual	Qty	Ctn
3	Feet		4	1

NEXT

CURTIS SOFA
Q78256

Assembly instructions

Ref	Dimensions	Qty
A	M8x25	32
B	M8x19	32
C	M8	32
D	M5	1



NEXT

CURTIS SOFA
Q78256

Assembly instructions

1

Diagram illustrating the assembly of the CURTIS SOFA (Q78256) using hardware Ax32, Bx32, Cx32, and Dx1.

The diagram shows two sofa sections (1 and 2) being joined. The inset details the connection of the sections using the following hardware:


- Ax32** M8x25mm: Bolt
- Bx32** M8x19mm: Washer
- Cx32** M8: Washer
- Dx1** M5: Bracket

The inset also labels the connection points A, B, C, and D.

Ax32 M8x25mm	Bx32 M8x19mm	Cx32 M8	Dx1 M5

Assembly instructions

2




NEXT

CURTIS SOFA

Q78256

Assembly instructions



NEXT


CURTIS SOFA

Q78254

Assembly instructions

Actual product size

W180cm X L227cm X H85cm



Fabric content

Q78254-100% polyester

IMPORTANT - RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly Instructions

Missing or damaged parts

CALL: 0333 777 8999

Assembly instructions

BEFORE YOU START

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools, plenty of space.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Unwrap all packaging materials and place the components on a clean surface to protect them from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use. Check fixings regularly to ensure they remain tight.

When moving your assembled stool. It is best to lift the chair and never to drag it.

Never allow any kind of liquid to remain on your furniture. Absorption can cause materials to warp or finishes to de-laminate.

To clean your item, please use a vacuum or lightly brush clean.

Don'ts

Do not tighten screws until fully assembled.

Do not over tighten screws or bolts.

Do not drag or pull your furniture.

Do not use this product if parts are missing, damaged or worn.

Never use scourers, abrasives or chemical cleaners.

Number of people required to assemble

Two people are required to assemble this item

**Time to assemble****Missing parts**

If you are missing any fixtures and fittings for your product please contact our customer service team on **0333 777 8999** and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement,

home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair. If you have a fault with your product please contact our

You can write to us at

Home Customer Services
Next Retail Ltd,
Desford Road,
Leicester,
LE19 4AT,


To view our full furniture range please visit www.next.co.uk

CURTIS SOFA



Q78254


NEXT

Assembly instructions



Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	Left side		1	1
2	Right side		1	1

Ref	Dimensions	Visual	Qty	Ctn
3	Feet		4	1


NEXT

CURTIS SOFA

Q78254

Assembly instructions

Ref	Dimensions	Qty
A	M8x25	32
B	M8x19	32
C	M8	32
D	M5	1




CURTIS SOFA

Q78254


NEXT

Assembly instructions

1



Ax32 M8x25mm



Bx32 M8x19mm



Cx32 M8




Dx1 M5



Assembly instructions

2



NEXT

CURTIS SOFA

Q78254

Assembly instructions

