



About this product:

Suitable for indoor use only

Operation Voltage: 5V~ 1A USB Type C Connection

Instructions for use:

(PLEASE RETAIN INSTRUCTIONS FOR FUTURE USE).

Please remove all the packaging before use.

Using the USB cable provided attach the Type C connector to the fitting, then attach the USB connector to a suitable USB port to operate this product and recharge it's battery.

This product has a touch dimmer button, the constant touch on the button will turn the light on and change the brightness of the light from minimum to maximum.

This product contain non-replaceable battery and LED lamps, if the LED lamp or battery reach the end of their life the whole product must be replaced.

Warnings:

This is a decoration product and NOT a toy, keep out of the reach of babies and children.

If the USB cable is damaged cannot be used and must be replaced by new USB cable with same connector type.



This Symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment.

FRONT



BACK