

NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions

Actual product size

H75.5 x W120 x D90 cm

H75.5 x W150 x D90 cm



Need Help ?

With: Assembly instruction

Missing or damaged parts

IMPORTANT - RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions

BEFORE YOU START

Number of people required to assemble


Two people are required to assemble this item



Time to assemble : 30 minutes



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.
Absorption can cause wood to warp or finishes to de-laminate.


Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster.

NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945
Assembly instructions

GETTING TO KNOW YOUR PRODUCT










NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945
Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	10x94cm		2	1
2	10x64.5cm		1	1
3	10x64.5cm		1	1
4	10x63cm		2	1

Ref	Dimensions	Visual	Qty	Ctn
5	60x90cm		1	1
6	60x90cm		1	1
7	30x90cm		1	1
8	12.5x72.5cm		4	1

NEXT


THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions

Fixtures and fittings supplied (actual size)

Ref	Dimensions	Qty	Spare Qty
Y27	Ø6 x 15mm	16	2
U123	Ø4 x 15mm	16	2
B12	Ø7.5 x 33mm	4	1
B3	Ø15 x 12mm	4	1
S59	Ø6 x 16mm	16	2
D6	Ø10 x 30mm	N/A	1



Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
T4	N/A	2	N/A	
Q3	N/A	8	1	
F17	N/A	2	N/A	
B23	N/A	8	1	

Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Qty	Spare Qty	Visual
T52	N/A	1	N/A	
F16	N/A	2	N/A	
M34	N/A	4	N/A	


NEXT


THORNE 4-6 EXTENDING DINING TABLE


V68945

Assembly instructions

1





B12	Ø7.5 x 33mm	4	 not supplied
S59	Ø6 x 16mm	8	
T4	N/A	2	

M34	N/A	4	
-----	-----	---	---

X2

2



F16	N/A	2	
U123	Ø4 x 15mm	4	 not supplied

NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions


3

WHEN LOOSENING THE CAM


TURN THE CAM IN A COUNTERCLOCKWISE DIRECTION
UNTIL THE ARROW POINTS IN THE POSITION SHOWN
IN THE DIAGRAMS BELOW




MAXIMUM
LOCK



TURN
TO UNLOCK



UNLOCKED



B3

Ø15 x 12mm

4



not supplied


NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions

4



T4	N/A	2	
S59	Ø6 x 16mm	8	

NEXT

THORNE 4-6 EXTENDING DINING TABLE


V68945

Assembly instructions


5

Please do not tighten all screws.



Step 3:
Align with the holes



Step 2:
Sliding the runner




Step 1:
Unlock



Y27

Ø6 x 15mm

16



NEXT


THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions

6

Please tighten all screws.



F17	N/A	2	
U123	Ø4 x 15mm	12	  not supplied
T4	N/A	2	


NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions

7



T52	N/A	1	
B23	N/A	8	
Q3	N/A	8	

NEXT


THORNE 4-6 EXTENDING DINING TABLE

V68945

Assembly instructions

8


Note: Please do not lift the table by the tabletop, It must be lifted using the apron underneath the tabletop.



NEXT

THORNE 4-6 EXTENDING DINING TABLE V68945 Assembly instructions

9




NEXT

THORNE 4-6 EXTENDING DINING TABLE

V68945
Assembly instructions

10




NEXT

THORNE 4-6 EXTENDING DINING TABLE V68945

Actual product size

H75.5 x W120 x D90 cm

H75.5 x W150 x D90 cm



NEXT

THORNE 4-6 EXTENDING DINING TABLE V68945

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit www.next.co.uk